



مدیران خودرو  
خدمات پس از فروش



# سیستم برق

## خودروی MVM530




مدیریت فنی و مهندسی  
تهیه کننده: محمد صادق قناعتیان  
ویرایش اول    کد: ELC-23-01


|                            |    |
|----------------------------|----|
| آینه های جانبی .....       | ۶۴ |
| سیستم هشدار دنده عقب ..... | ۶۵ |
| سانروف .....               | ۶۷ |
| برف پاک کن .....           | ۶۸ |


|                                  |    |
|----------------------------------|----|
| راهنمای نقشه خوانی .....         | ۳  |
| جعبه فیوز باتری .....            | ۴  |
| جعبه فیوز محفظه موتور .....      | ۶  |
| دسته سیم ها .....                | ۱۳ |
| اتصالات بدنه .....               | ۱۴ |
| سیستم استارت و شارژ .....        | ۲۰ |
| سیستم خنک کننده موتور .....      | ۲۲ |
| سطح روغن ترمز .....              | ۲۳ |
| سیستم ABS .....                  | ۲۴ |
| سیستم کولر .....                 | ۲۸ |
| سیستم ایربگ و کمربند ایمنی ..... | ۳۲ |
| شبکه CAN .....                   | ۳۶ |
| سیستم قفل مرکزی .....            | ۳۸ |
| BCM جلو .....                    | ۴۰ |
| پشت آمپر .....                   | ۴۵ |
| جراغ سقفی .....                  | ۴۸ |
| جراغ صندوق عقب .....             | ۴۹ |
| شیشه بالابر .....                | ۵۰ |
| BCM عقب .....                    | ۵۳ |
| سیستم ضد سرقت .....              | ۵۵ |
| سیستم روشنایی .....              | ۵۶ |
| بوق .....                        | ۶۳ |


## EXAMPLE





| Number | Item                | Description                                                                                                                                                            |
|--------|---------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1      | Power source        | This represents the condition when the system receives battery positive voltage.                                                                                       |
| 2      | Fuse                | The single line represents that this is a fuse.                                                                                                                        |
| 3      | Current rating      | This represents the current rating of the fuse.                                                                                                                        |
| 4      | Fuse location       | This represents the location of the fuse in the Power Fuse Box or Front Fuse and Relay Box.                                                                            |
| 5      | Connectors          | This represents connector E-101 is female and connector C-101 is male.                                                                                                 |
| 6      | Terminal number     | This represents the terminal number of a connector.                                                                                                                    |
| 7      | Component name      | This represents the name of a component.                                                                                                                               |
| 8      | Connector number    | This represents the connector number. The letter represents which harness the connector is located in.                                                                 |
| 9      | Splice              | The shaded circle represents that the splice is always on the vehicle.                                                                                                 |
| 10     | Optional splice     | The open circle represents that the splice is optional depending on vehicle application.                                                                               |
| 11     | Option abbreviation | This represents that the circuit is optional depending on vehicle application.                                                                                         |
| 12     | Ground (GND)        | This represents the ground connection. (See Ground Distribution in Section 16 Wiring). Ground connector number has no view face.                                       |
| 13     | Page crossing       | This arrow represents that the circuit continues to an adjacent page. The "A" corresponds with the "A" on the adjoining page of the electrical schematic.              |
| 14     | Data link           | This represents that the system branches to another system identified by cell data code.                                                                               |
| 15     | Option description  | This represents a description of the option abbreviation used on the page.                                                                                             |
| 16     | Connector views     | This represents the connector information. This component side is described by the connector symbols.                                                                  |
| 17     | Connector color     | This shows a code for the color of the connector:<br>B = Black<br>W = White<br>R = Red<br>G = Green<br>L = Blue<br>Y = Yellow<br>BR = Brown<br>O = Orange<br>GR = Gray |
| 18     | Shielded line       | The line enclosed by broken line circle represents shielded wire.                                                                                                      |


































**B-201 :**  
لنت ترمز چپ و راست  
راهنما  
قفل درب  
شیشه بالابر  
آئینه جانبی  
سوئیچ آئینه جانبی  
چراغ سقفی  
چراغ روی آئینه  
سانروف

**B-202 :**  
راهنما  
سانروف

## سنسورهای دنده عقب





رادیو

چراغ داشبورد

برق اضطراری و فنلک

کلید چراغ جلو

کلید مه شکن عقب


ایموبیلایزر


سوئیچ کلاچ

کلید فلاشر



کلید تنظیم نور پشت آمپر

پشت آمپر







# STARTING SYSTEM




## CHARGING SYSTEM






## COOLING SYSTEM



## BASE BRAKE SYSTEM












### Antilock Brake System (ABS) Module Connector Pin-Out Table

| PIN | CIRCUIT IDENTIFICATION | PIN | CIRCUIT IDENTIFICATION |
|-----|------------------------|-----|------------------------|
| 1   | —                      | 24  | —                      |
| 2   | ECM Supply             | 25  | —                      |
| 3   | CAN-H                  | 26  | FR RH SIG2             |
| 4   | —                      | 27  | FR RH SIG1             |
| 5   | —                      | 28  | —                      |
| 6   | Stop Lamp Switch       | 29  | —                      |
| 7   | —                      | 30  | —                      |
| 8   | —                      | 31  | Motor Supply           |
| 9   | —                      | 32  | Ignition               |
| 10  | —                      | 33  | —                      |
| 11  | —                      | 34  | —                      |
| 12  | FR LH SIG2             | 35  | —                      |
| 13  | FR LH SIG1             | 36  | —                      |
| 14  | —                      | 37  | —                      |
| 15  | —                      | 38  | —                      |
| 16  | Ground                 | 39  | —                      |
| 17  | —                      | 40  | —                      |
| 18  | CAN-L                  | 41  | RR LH SIG1             |
| 19  | —                      | 42  | RR LH SIG2             |
| 20  | —                      | 43  | RR RH SIG2             |
| 21  | —                      | 44  | RR RH SIG1             |
| 22  | —                      | 45  | Ground                 |
| 23  | —                      | 46  | —                      |

## PARKING BRAKE







| PIN | CIRCUIT IDENTIFICATION               | PIN | CIRCUIT IDENTIFICATION        |
|-----|--------------------------------------|-----|-------------------------------|
| 1   | Speed Signal                         | 19  | Sun Sensor                    |
| 2   | Wiper Signal                         | 20  | —                             |
| 3   | Coolant Valve Motor (+)              | 21  | To Illumination (night light) |
| 4   | Coolant Valve Motor (-)              | 22  | —                             |
| 5   | —                                    | 23  | Rear Window Defogger          |
| 6   | Blower Motor Adjust Speed Signal     | 24  | To ECM                        |
| 7   | Blower Motor Voltage Feedback        | 25  | —                             |
| 8   | Coolant Valve Motor Feedback         | 26  | K-Line                        |
| 9   | Sensor Signal GND                    | 27  | —                             |
| 10  | Motor Potentiometer Common GND       | 28  | —                             |
| 11  | Air Mix Door Motor Potentiometer (+) | 29  | Air Mix Door Motor (+)        |
| 12  | —                                    | 30  | Air Mix Door Motor (-)        |
| 13  | —                                    | 31  | Intake Door Motor ( $\pm$ )   |
| 14  | Coolant Temperature Sensor           | 32  | Intake Door Motor ( $\pm$ )   |
| 15  | In-Vehicle Sensor                    | 33  | Air Mix Door Motor (+)        |
| 16  | Mode Door Motor Feedback             | 34  | Air Mix Door Motor (-)        |
| 17  | Air Mix Door Motor Voltage Feedback  | 35  | Controller GND                |
| 18  | Outside Temperature Sensor           | 36  | IGN SIG                       |

## How To Enter HVAC Module Self Diagnostic Mode

The Automatic Temperature Control (ATC) module cannot be accessed with the X-431 scan tool. The following must be done in order to read the DTC information in the ATC module:

1. Push the up knob of the air volume, and push the mode control knob 3 times continuously.
2. The ATC display will now display any DTCs.

Turn the ignition switch on.

Adjust the temperature control knob on the panel, set the temperature at 29.5°.

While push the Upper air volume control knob switches, push the mode control knob 3 times continuously. The control panel will enter the self-check mode.

### Automatic Temperature Control System DTC List

| DTC | DTC DEFINITION                   |
|-----|----------------------------------|
| 01  | Inside Temperature Sensor Fault  |
| 02  | Outside Temperature Sensor Fault |
| 03  | Coolant Temperature Sensor Fault |
| 04  | Sun Sensor Fault                 |
| 05  | Blower Motor Fault               |
| 06  | Blend Door Fault                 |
| 07  | Mode Door Fault                  |
| 08  | Coolant Valve Modulation Fault   |

## Description

Available occupant restraints for this vehicle include both active and passive types. Active restraints are those which require the vehicle occupants to take some action to employ, such as fastening a seat belt; while passive restraints require no action by the vehicle occupants to be employed.

### Active Restraints

- Front Seat belts
- Rear Seat belts

### Passive Restraints

- Driver Airbag
- Passenger Airbag
- Seat Belt Tensioner

## Operation

### Active Restraints


The primary passenger restraints are the seat belts. Seat belts are referred to as an active restraint because the vehicle occupants are required to physically fasten and properly adjust these restraints in order to benefit from them.


### Passive Restraints

The passive restraints are referred to as a supplemental restraint system because they were designed and are intended to enhance the protection for the occupants of the vehicle only when used in conjunction with the seat belts. They are referred to as passive restraints because the vehicle occupants are not required to do anything to make them operate; however, the vehicle occupants must be wearing their seat belts in order to obtain the maximum safety benefit from the supplemental restraint system.

The supplemental restraint system electrical circuits are continuously monitored and controlled by a microprocessor and software contained within the Restraints Control Module (RCM). An airbag indicator in the Instrument Cluster illuminates for about seven seconds as a bulb test each time the ignition switch is turned to the ON or START positions. Following the bulb test, the airbag indicator is turned ON or OFF by the RCM to indicate the status of the supplemental restraint system. If the airbag indicator comes ON at any time other than during the bulb test, it indicates that there is a problem in the supplemental restraint system electrical circuits. Such a problem may cause airbags not to deploy when required, or to deploy when not required.

Deployment of the supplemental restraints depends upon the angle and severity of an impact. When an impact is severe enough, the microprocessor in the RCM signals the inflator of the appropriate airbag units to deploy their airbag cushions. The front seat belt tensioners are provided with a deployment signal by the RCM in conjunction with the front airbags.





Airbag Control Module Connector Pin-Out Table

| PIN | CIRCUIT IDENTIFICATION  | PIN | CIRCUIT IDENTIFICATION     |
|-----|-------------------------|-----|----------------------------|
| 1   | Driver Airbag           | 26  | —                          |
| 2   | Driver Airbag           | 27  | —                          |
| 3   | Passenger Airbag        | 28  | —                          |
| 4   | Passenger Airbag        | 29  | —                          |
| 5   | —                       | 30  | —                          |
| 6   | —                       | 31  | —                          |
| 7   | —                       | 32  | —                          |
| 8   | —                       | 33  | —                          |
| 9   | —                       | 34  | —                          |
| 10  | Driver Airbag Indicator | 35  | —                          |
| 11  | GND                     | 36  | —                          |
| 12  | Airbag Switch           | 37  | Airbag Switch              |
| 13  | —                       | 38  | —                          |
| 14  | —                       | 39  | —                          |
| 15  | —                       | 40  | —                          |
| 16  | —                       | 41  | —                          |
| 17  | —                       | 42  | —                          |
| 18  | —                       | 43  | —                          |
| 19  | —                       | 44  | —                          |
| 20  | —                       | 45  | —                          |
| 21  | —                       | 46  | K-Line                     |
| 22  | —                       | 47  | Passenger Airbag Indicator |
| 23  | —                       | 48  | Airbag Unlock Input        |
| 24  | —                       | 49  | —                          |
| 25  | BATT                    | 50  | —                          |

## Airbag System Disarming Procedure

### Airbag System Disarming Procedure

**WARNING!**

The steering column contains the driver's airbag. The airbag system is a sensitive, complex electro-mechanical unit. Before attempting to diagnose, remove or install the airbag system components, you must first disconnect and isolate the negative battery (ground) cable. Then wait two minutes for the system capacitor to discharge. Failure to do so could result in accidental deployment of the airbag and possible personal injury. The fasteners, screws, and bolts, originally used for the airbag components, have special coatings and are specifically designed for the airbag system. They must never be replaced with any substitutes. Anytime a new fastener is needed, replace with the correct fasteners provided in the service package or fasteners listed in the parts books.

1. Turn the ignition switch off.
2. Disconnect and isolate the negative battery cable.
3. Wait two minutes for the system capacitor to discharge.
4. The airbag system can now be serviced safely.

## CAN VEHICLE COMMUNICATIONS


### Description



Controller Area Network (CAN) vehicle communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting various vehicle modules with two communication lines (CAN-H and CAN-L). CAN vehicle communication consists of the following:


- Front Body Control Module (FBCM)
- Transaxle Control Module (TCM)
- Antilock Brake System (ABS) Module
- Instrument Cluster
- Engine Control Module (ECM)

### Operation

Control units on the CAN network transmit signals using the CAN communication control circuit. They receive only necessary signals from other vehicle modules to operate various functions. Each vehicle module passes an electric current to the termination potential difference between CAN-H and CAN-L.












The Front Body Control Module (FBCM) is designed to control and integrate many of the electronic features and functions of the vehicle. The microprocessor-based FBCM hardware and software monitors many hard-wired switch and sensor inputs as well as those resources it shares with other electronic modules in the vehicle through its communication over the Controller Area Network (CAN) bus. The internal programming of the FBCM microprocessor allows the FBCM to determine the tasks it needs to perform and their priorities. The FBCM programming then performs those tasks and provides features through both CAN bus communication with other electronic modules and hard-wired outputs to a number of relays. These relays provide the FBCM with the ability to control numerous high current accessory systems in the vehicle.

**A21-3600030MA : جلو****A21-3600050DA : عقب****A21-3600030KA : جلو****A21-3600050KA : عقب**

| FUSE NO. | AMPERAGE RATING | FUNCTION                    |
|----------|-----------------|-----------------------------|
| 1        | 5A              | Radio                       |
| 2        | 10A             | Parking Brake               |
| 3        | 10A             | Horn                        |
| 4        | 7.5A            | Battery Energy Conservation |
| 5        | 5A              | ATM (Transaxle)             |
| 6        | 7.5A            | Heated Side View Mirror     |
| 7        | 25A             | Front Fog Light             |
| 8        | 15A             | Power Door Lock             |
| 9        | —               | Not Used                    |
| 10       | —               | Not Used                    |
| 11       | —               | Not Used                    |
| 12       | 30A             | Power Window                |










| PIN | CIRCUIT IDENTIFICATION       | PIN | CIRCUIT IDENTIFICATION    |
|-----|------------------------------|-----|---------------------------|
| 1   | —                            | 50  | Tamper Input              |
| 2   | CAN Wake Up                  | 51  | Left Turn Input           |
| 3   | Hazard Input                 | 52  | —                         |
| 4   | Horn Input                   | 53  | —                         |
| 5   | Window Left Front DWN        | 54  | Brake Input               |
| 6   | Window Left Front DWN        | 55  | Washer Input              |
| 7   | —                            | 56  | Boot REL Input            |
| 8   | Reverse Input                | 57  | Driver WIN RL DWN         |
| 9   | —                            | 58  | Driver WIN RR UP          |
| 10  | DEFR SW ILLUM                | 59  | Driver WIN Right Front UP |
| 11  | IGN                          | 60  | High Beam CONST Input     |
| 12  | Front Fog IND Out            | 61  | Rear Fog Input            |
| 13  | DEFR IND                     | 62  | —                         |
| 14  | —                            | 63  | Lock Input                |
| 15  | Wiper INT AN                 | 64  | DEFR Input                |
| 16  | —                            | 65  | —                         |
| 17  | Low Beam Relay               | 66  | —                         |
| 18  | Rear Fog IND Out             | 67  | Radio (75) Fuse           |
| 19  | High Beam Relay              | 68  | Radio (75)                |
| 20  | Pass WIN Right Front DWN     | 69  | —                         |
| 21  | Passenger WIN Right Front UP | 70  | Dome Lights               |
| 22  | Rear Fog SW ILLUM            | 71  | Right Front Fog Output    |
| 23  | Key Lamp                     | 72  | Right Front Fog Output    |
| 24  | Front Fog SW ILLUM           | 73  | Left Turn Output          |
| 25  | CAN L                        | 74  | Front Park Output         |
| 26  | CAN H                        | 75  | IP ILLUM Output           |
| 27  | —                            | 76  | Siren Output              |
| 28  | SEC IND                      | 77  | Horn                      |
| 29  | INTER BCM                    | 78  | Right Front BAT Saver     |
| 30  | INTER BCM                    | 79  | SEC LED PWR               |
| 31  | K-Line                       | 80  | MIR DEFR                  |
| 32  | Vehicle Speed Input (RSD)    | 81  | Wiper Output              |
| 33  | Park Light Input             | 82  | Wiper Park                |
| 34  | Passenger WIN Input          | 83  | ACC (75) Wiper            |
| 35  | Hood Ajar                    | 84  | Right Turn Output         |
| 36  | —                            | 85  | —                         |
| 37  | Seat Belt Input              | 86  | —                         |
| 38  | —                            | 87  | —                         |
| 39  | Key Input                    | 88  | Lock Output               |

| PIN | CIRCUIT IDENTIFICATION     | PIN | CIRCUIT IDENTIFICATION        |
|-----|----------------------------|-----|-------------------------------|
| 40  | —                          | 89  | Unlock Output                 |
| 41  | Driver WIN RR DWN          | 90  | Spare Fuse VBAT               |
| 42  | Driver WIN Right Front DWN | 91  | —                             |
| 43  | Driver WIN RL UP           | 92  | —                             |
| 44  | Low Beam Input             | 93  | Window Right Front DWN Output |
| 45  | Front Fog Input            | 94  | Window Right Front UP Output  |
| 46  | —                          | 95  | Window Left Front DWN Output  |
| 47  | Unlock Input               | 96  | Window Left Front UP Output   |
| 48  | Airbag Unlock Input        | B   | BATT Power Supply             |
| 49  | —                          | G   | GND Power supply              |









### Clearing Service Monitor Lamp


Perform the following to clear the service monitor lamp:



1. Turn the ignition switch off.
2. Press down and hold the Mode switch.
3. Turn the ignition switch on.
4. Release the Mode switch.
5. Touch the Mode switch and the Clock switch simultaneously in 30 seconds with a touch time less than 2 seconds to clear the mileage maintenance identification.


| PIN | CIRCUIT IDENTIFICATION | PIN | CIRCUIT IDENTIFICATION  |
|-----|------------------------|-----|-------------------------|
| 1   | —                      | 17  | Airbag                  |
| 2   | GND Power Supply       | 18  | Parking Brake Switch    |
| 3   | Sensor GND             | 19  | —                       |
| 4   | —                      | 20  | —                       |
| 5   | Body GND               | 21  | Fuel Level Input        |
| 6   | —                      | 22  | —                       |
| 7   | Speed Input            | 23  | —                       |
| 8   | —                      | 24  | —                       |
| 9   | Oil Pressure Switch    | 25  | —                       |
| 10  | —                      | 26  | Brake Fluid Level Input |
| 11  | Power Supply           | 27  | Vehicle Speed Input     |
| 12  | IP ILLUM Input         | 28  | —                       |
| 13  | Key Input              | 29  | CAN - L                 |
| 14  | —                      | 30  | CAN - H                 |
| 15  | K-Line                 | 31  | CAN Wake Up             |
| 16  | Charge                 | 32  | Brake Pad Alarm Input   |













| PIN | CIRCUIT IDENTIFICATION | PIN | CIRCUIT IDENTIFICATION |
|-----|------------------------|-----|------------------------|
| 1   | —                      | 28  | —                      |
| 2   | —                      | 29  | —                      |
| 3   | —                      | 30  | —                      |
| 4   | Reverse RAD CLK        | 31  | —                      |
| 5   | Sensor GND             | 32  | —                      |
| 6   | INTER BCM              | 33  | Brake Light            |
| 7   | Trunk Ajar             | 34  | —                      |
| 8   | RR Door Ajar           | 35  | Trunk Release          |
| 9   | LR Door Ajar           | 36  | Left Turn Output       |
| 10  | Passenger RR WIN UP    | 37  | Right Turn Output      |
| 11  | Passenger LR WIN Down  | 38  | —                      |
| 12  | Passenger RR WIN Down  | 39  | —                      |
| 13  | Passenger LR WIN Up    | 40  | WIN RR UP Output       |
| 14  | —                      | 41  | WIN RR Down Output     |
| 15  | —                      | 42  | —                      |
| 16  | —                      | 43  | Defroster              |
| 17  | —                      | 44  | Battery Saver          |
| 18  | —                      | 45  | Fog Light              |
| 19  | Reverse RAD Data       | 46  | —                      |
| 20  | —                      | 47  | Reverse Light          |
| 21  | —                      | 48  | Park Light             |
| 22  | INTER BCM (2)          | 49  | —                      |
| 23  | —                      | 50  | —                      |
| 24  | —                      | 51  | WIN LR Down Output     |
| 25  | —                      | 52  | WIN LR UP Output       |
| 26  | —                      | B   | BATT Power supply      |
| 27  | —                      | G   | GND Power supply       |



| FUSE NO. | AMPERAGE RATING | FUNCTION                                  |
|----------|-----------------|-------------------------------------------|
| 1        | 25A             | Heated Rear Window                        |
| 2        | 15A             | Rear Fog Light                            |
| 3        | 15A             | Trunk Lid, Turning Light, Reversing Light |
| 4        | —               | Not Used                                  |
| 5        | —               | Not Used                                  |
| 6        | 30A             | Rear Power Window                         |





کنترل یونیت ایموبیلایزر



تگ سوئیچ



آنتن ایموبیلایزر



برد ریموت کنترل

Turn the ignition switch on.  
Replace the electronic chip.

- With the X-431 scan tool, choose A520 series.
  - Choose "immobilize".
  - Choose "input code".
  - Input the safety code.
  - Click the small keyboard.
  - Click "OK".
  - Choose "immobilizer adapt".
  - Choose "Key learning" immediately.
  - Click "OK".
- Try to start the engine.

Turn the ignition switch on.

Using the X-431 scan tool, program the vehicle security system

- With the X-431 scan tool, choose A520 series.
  - Choose "immobilize".
  - Choose "input code".
  - Input the safety code.
  - Click the small keyboard.
  - Click "OK".
  - Choose "immobilizer adapt".
    - Choose "read immobilizer to EMS" immediately.
    - Choose "read EMS to immobilizer".
    - Choose "key learning".
  - Click "OK".
- Try to start the engine.

