

PG

SECTION

POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

CONTENTS

POWER SUPPLY & GROUND CIRCUIT		
BASIC INSPECTION	3	
BATTERY	3	
How to Handle Battery	3	
Work Flow	4	
COMPONENT DIAGNOSIS	6	
POWER SUPPLY ROUTING CIRCUIT	6	
Wiring Diagram - BATTERY POWER SUPPLY	6	
Wiring Diagram - ACCESSORY POWER SUPPLY -	18	
Wiring Diagram - IGNITION POWER SUPPLY -	20	
Fuse	31	
Fusible Link	31	
Circuit Breaker	31	
HARNESS LAYOUT	32	
LHD	32	
LHD : How To Read Harness Layout	32	
LHD : Outline	33	
LHD : Main Harness	34	
LHD : Engine Room Harness	36	
LHD : Engine Control Harness	39	
LHD : Body Harness	45	
LHD : Room Lamp Harness	49	
LHD : Front Door Harness	50	
LHD : Rear Door Harness	52	
LHD : Back Door Harness	54	
RHD	54	
RHD : How To Read Harness Layout	55	
RHD : Outline	56	
RHD : Main Harness	57	
RHD : Engine Room Harness	59	
RHD : Engine Control Harness	62	
RHD : Body Harness	68	
RHD : Room Lamp Harness	72	
RHD : Front Door Harness	73	
RHD : Rear Door Harness	75	
RHD : Back Door Harness	77	
ELECTRICAL UNITS	78	
Terminal Arrangement	78	
SMJ (SUPER MULTIPLE JUNCTION)	79	
Terminal Arrangement	79	
HARNESS CONNECTOR	80	
Description	80	
STANDARDIZED RELAY	83	
Description	83	
FUSE BLOCK - JUNCTION BOX (J/B)	85	
Fuse, Connector and Terminal Arrangement	85	
FUSE, FUSIBLE LINK AND RELAY BOX	86	
Fuse and Fusible Link Arrangement	86	
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	87	
Fuse, Connector and Terminal Arrangement	87	
PRECAUTION	88	
PRECAUTIONS	88	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	88	
ON-VEHICLE REPAIR	89	
BATTERY	89	
Exploded View	89	
Removal and Installation	89	
BATTERY TERMINAL WITH FUSIBLE LINK	90	
Exploded View	90	
Removal and Installation	90	

SERVICE DATA AND SPECIFICATIONS	
(SDS)	92

SERVICE DATA AND SPECIFICATIONS	
(SDS)	92
Battery	92

www.carg geek.ir

BASIC INSPECTION

BATTERY

How to Handle Battery

INFOID:000000004897449


CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.


METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- At every routine maintenance, check the electrolyte level.
This also applies to batteries designated as "low maintenance" and "maintenance-free".



- When the vehicle is not going to be used over a long period of time, disconnect the battery cable from the negative terminal. (If the vehicle has an extended storage switch, turn it off.)



A

B

C

D

E

F

G

H

I

J

K

L

PG

N

O

P

BATTERY


< BASIC INSPECTION >

[POWER SUPPLY & GROUND CIRCUIT]

Work Flow

INFOID:000000004897450

OVERALL SEQUENCE



JPMIA0458GB

DETAILED FLOW

1. VISUAL INSPECTION

1. Check battery case for cracks or bends.
2. Check battery terminals for damage.

Are these inspection results normal?

YES >> GO TO 2.

NO >> Replace battery.

2. CAPACITY TEST

Check battery voltage.

Is the voltage 12.35 V or more?

YES >> GO TO 3.

NO >> GO TO 5.

BATTERY

[POWER SUPPLY & GROUND CIRCUIT]

< BASIC INSPECTION >

3. CHECK MAGICAL EYE

Check the color of magical eye.

Inspection results

Green >> GO TO 4.

White >> Check alternator and replace battery. Refer to CHG-2, "Work Flow".

4. DISCHARGE

1. Check battery type and determine the specified current using the table.

Type	Current (A)
L2	300
L3	300

2. Perform discharge using the load tester.

Is the voltage 10 V or more?

YES >> Ready for use.

NO >> Replace battery.

5. CHECK MAGICAL EYE

Check the color of magical eye.

Inspection results

Green or black >> GO TO 6.

White >> Check alternator and replace battery. Refer to CHG-2, "Work Flow".

6. CHARGE

1. Determine the charge current and charging time according to the battery type.

Type	Current (A)	CHARGING TIME (h)
L2	10	8 - 12
L3	10	8 - 12

2. Charge battery.

>> GO TO 4.


A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

POWER SUPPLY ROUTING CIRCUIT

[POWER SUPPLY & GROUND CIRCUIT]

< COMPONENT DIAGNOSIS >

- : With MFR engine
- : With CVT
- : Gasoline engine M/T models
- : Gasoline engine CVT models



Refer to the following.
 - SUPER MULTIPLE JUNCTION (SMJ)
 - FUSE BLOCK JUNCTION BOX (J/B)

JMMWAD101GI


A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

BATTERY POWER SUPPLY



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

JMMWAD103GI



POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

BATTERY POWER SUPPLY FUSE NO.8

- : With M9R engine
- : With Intelligent Key
- : Without Intelligent Key
- : With auto A/C



Refer to the following.
 -SUPER MULTIPLE JUNCTION (SMJ)

* : This connector is not shown in "Harness Layout" PG section.

JMMWA0104GI



POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

BATTERY POWER SUPPLY FUSE NO.9

IK : With Intelligent Key
 AU : For Australia



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

JMMWAD105G1



POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

BATTERY POWER SUPPLY FUSE NO.12

 : With TEL adapter



*: This connector is not shown in "Harness Layout" PG section.

JMMWA0106G1


POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >



[POWER SUPPLY & GROUND CIRCUIT]

BATTERY POWER SUPPLY FUSE NO.45

HA : With headlamp auto aiming



Connector No.	Terminal No.	Connect to
E28	3	HEADLAMP AIMING MOTOR LH
E47	3	HEADLAMP AIMING MOTOR RH
B43	2	AUTO LEVELIZER CONTROL UNIT
E45	1	FRONT COMBINATION LAMP RH



JMMWA0107GI

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P


POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

BATTERY POWER SUPPLY FUSE NO.49

- : With CVT
- : 4WD models
- : With VDC
- : With auto A/C
- : With manual A/C
- : With headlamp manual aiming
- : With heated seat
- : For the Middle East
- : Except for the Middle East



Refer to the following.
 -SUPER MULTIPLE JUNCTION (SMJ)



Connector No.	Terminal No.	Connect to
	3	HEADLAMP AIMING SWITCH
	4	HAZARD SWITCH
	9	AUDIO UNIT
	5	CONTROL DEVICE
	1	PARKING LAMP LH
	3	VDC OFF SWITCH
	10	DOOR MIRROR REMOTE CONTROL SWITCH
	7	4WD MODE SWITCH
	1	HIGH-LEVEL VENTILATOR SWITCH
	16	AUTO AMP.
	2	HEATER CONTROL PANEL
	1	HEATED SEAT SWITCH LH
	1	HEATED SEAT SWITCH RH
	3	DOOR LOCK AND UNLOCK SWITCH
	1	REAR HIGH-LEVEL VENTILATOR SWITCH
	6	AUTO LEVELIZER CONTROL UNIT
	2	REAR COMBINATION LAMP RH
	2	REAR COMBINATION LAMP LH

JMMWA0106G1

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P


JMMWA0109G1

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

BATTERY POWER SUPPLY FUSE NO.52





JMMWAD1103I

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]



JMMWA0111GI

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >


[POWER SUPPLY & GROUND CIRCUIT]

Wiring Diagram - ACCESSORY POWER SUPPLY -

INFOID:000000004897452

ACCESSORY POWER SUPPLY

◊ G : With gasoline engine
◊ M9 : With MFR engine



JMMWA01120E




POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

ACCESSORY POWER SUPPLY FUSE NO.5

 : With TEL adapter



* : This connector is not shown in "Harness Layout" PG section.

JMMWA0113G1

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

POWER SUPPLY ROUTING CIRCUIT


< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

Wiring Diagram - IGNITION POWER SUPPLY -

INFOID:000000004897453

IGNITION POWER SUPPLY



JMMWA0114GI


POWER SUPPLY ROUTING CIRCUIT

[POWER SUPPLY & GROUND CIRCUIT]

< COMPONENT DIAGNOSIS >

- (G) : With gasoline engine
- (HF) : With HF engine
- (XH) : Except HF engine
- (MB) : With M3R engine
- (C) : With CVT
- (M) : With MT
- (4T) : 4WD models with MT
- (XT) : Except 4WD models with MT

Refer to the following.
 (E4) - FUSE BLOCK
 JUNCTION BOX (JIB)



REFER TO BATTERY
POWER SUPPLY

FUSIBLE LINK
HOLDER

100A (C)
80A (D)
30A (E)
30A (LL)
50A (MT)

FUSE AND
FUSIBLE
LINK
BLOCK
(E4)

IGNITION
RELAY
(E5)

FRONT
WIPER
RELAY
(E6)

FRONT
WIPER
HICHER
RELAY
(E7)

COOLING
FAN
RELAY-1
(E8)

COOLING
FAN
RELAY-2
(E9)

RESISTOR
(E7)

IGNITION
POWER
SUPPLY
FUSE
NO.41, 42
(E10)

REAR
WINDOW
DEFOGGER
RELAY
(E11)

CPU

CPU

CPU

COMPRESSION
(E17)

FRONT WIPER
MOTOR
(E20)

Y/R Y

Y/B

DATA LINE
DATA LINE
To CAN
system

10A (E4)

14 R/B

35 W/L

29 P

28 L

23 Y/B

7

8 Y/B

6 B

5 B

54 (H/R)

52 W

49 B

W/L

7 R/B

2 R/B

XT

E1 (E1)

E2 (E2)

E3 (E3)

E4 (E4)

E5 (E5)

E6 (E6)

E7 (E7)

E8 (E8)

E9 (E9)

E10 (E10)

E11 (E11)

E12 (E12)

E13 (E13)

E14 (E14)

E15 (E15)

E16 (E16)

E17 (E17)

E18 (E18)

E19 (E19)

E20 (E20)

E21 (E21)

E22 (E22)

E23 (E23)

E24 (E24)

E25 (E25)

E26 (E26)

E27 (E27)

E28 (E28)

E29 (E29)

E30 (E30)

E31 (E31)

E32 (E32)

E33 (E33)

E34 (E34)

E35 (E35)

E36 (E36)

E37 (E37)

E38 (E38)

E39 (E39)

E40 (E40)

E41 (E41)

E42 (E42)

E43 (E43)

E44 (E44)

E45 (E45)

E46 (E46)

E47 (E47)

E48 (E48)

E49 (E49)

E50 (E50)

E51 (E51)

E52 (E52)

E53 (E53)

E54 (E54)

E55 (E55)

E56 (E56)

E57 (E57)

E58 (E58)

E59 (E59)

E60 (E60)

E61 (E61)

E62 (E62)

E63 (E63)

E64 (E64)

E65 (E65)

E66 (E66)

E67 (E67)

E68 (E68)

E69 (E69)

E70 (E70)

E71 (E71)

E72 (E72)

E73 (E73)

E74 (E74)

E75 (E75)

E76 (E76)

E77 (E77)

E78 (E78)

E79 (E79)

E80 (E80)

E81 (E81)

E82 (E82)

E83 (E83)

E84 (E84)

E85 (E85)

E86 (E86)

E87 (E87)

E88 (E88)

E89 (E89)

E90 (E90)

E91 (E91)

E92 (E92)

E93 (E93)

E94 (E94)

E95 (E95)

E96 (E96)

E97 (E97)

E98 (E98)

E99 (E99)

E100 (E100)

JMMWA015G1


A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

POWER SUPPLY ROUTING CIRCUIT

[POWER SUPPLY & GROUND CIRCUIT]

< COMPONENT DIAGNOSIS >

- : With gasoline engine
- : With M/T
- : With CVT



JMMWA01163I











POWER SUPPLY ROUTING CIRCUIT

[POWER SUPPLY & GROUND CIRCUIT]

< COMPONENT DIAGNOSIS >

IGNITION POWER SUPPLY

AS : For Australia
EA : Except for AS



* : This connector is not shown in "Harness Layout" PG section.

JMMWA0117Gf

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P


POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

IGNITION POWER SUPPLY FUSE NO.4

- : With gasoline engine
- : With M9R engine
- : With CVT
- : With M/T
- : With Intelligent Key
- : With auto A/C
- : Without auto A/C
- : With gasoline engine and ASCD
- : Except for the Middle East with auto A/C
- : With TEL adapter



Refer to the following.
 - SUPER MULTIPLE JUNCTION (SMJ)


JMMWA0118G1

POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

IGNITION POWER SUPPLY FUSE NO.4



*: This connector is not shown in "Harness Layout" PG section.

JMMWAD118GI



POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

IGNITION POWER SUPPLY FUSE NO.17

D : With diesel engine
AA : With auto A/C



Refer to the following.
(M77) -SUPER MULTIPLE JUNCTION (SMJ)

JMMWA0120GI





POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

IGNITION POWER SUPPLY FUSE NO.41,42

AA : With auto A/C
 OA : Without auto A/C



Refer to the following.
 (M77) -SUPER MULTIPLE JUNCTION (SMJ)

JMMWA0121GI

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P




POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

IGNITION POWER SUPPLY FUSE NO.55

: With CVT



Refer to the following.
 -SUPER MULTIPLE JUNCTION (SMJ)

JMMWA0122GI


POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

IGNITION POWER SUPPLY FUSE NO.58

: With gasoline engine



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P



POWER SUPPLY ROUTING CIRCUIT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

IGNITION POWER SUPPLY FUSE NO.59

- : 4WD models
- : With VDC
- : Without VDC



Refer to the following.
 -SUPER MULTIPLE JUNCTION (SMJ)

JMMWA0124G1

POWER SUPPLY ROUTING CIRCUIT


[POWER SUPPLY & GROUND CIRCUIT]

< COMPONENT DIAGNOSIS >

Fuse

INFOID:0000000004897454

- If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.



Fusible Link

INFOID:0000000004897455

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.


CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of malfunction.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.

Circuit Breaker

INFOID:0000000004897456

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNESS LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

HARNESS LAYOUT

LHD

LHD : How To Read Harness Layout


INFOID:000000004897457

The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness
- Engine Control Harness
- Body Harness
- Room Lamp Harness
- Door Harness

To use the grid reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.



CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
<ul style="list-style-type: none"> • Cavity: Less than 4 • Relay connector 				
<ul style="list-style-type: none"> • Cavity: From 5 to 8 				
<ul style="list-style-type: none"> • Cavity: More than 9 				
<ul style="list-style-type: none"> • Ground terminal etc. 	—			


HARNESS LAYOUT

[POWER SUPPLY & GROUND CIRCUIT]

< COMPONENT DIAGNOSIS >

LHD : Outline

INFOID:000000004897458



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

JMMWA0127GI


HARNESS LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

LHD : Main Harness

INFOID:000000004897459



JMMWA0129GI

HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

C3	M1	-/1	Fuse block (J/B)	C2	M38	-/2	EPS control unit	D4	M71	BR/3	G sensor (4WD models)
B4	M2	-/1	Fuse block (J/B)	B2	M40	W/40	Intelligent Key unit	D4	M72	B/4	YAW rate sensor (With VDC)
B4	M4	B/16	Data link connector	D2	M41	W/2	In-vehicle sensor (With auto A/C)	F2	M73	-/2	Glove box lamp
B3	M5	GR/6	VDC off switch (With VDC)	E3	M42	W/2	Intake sensor (With auto A/C)	G1	M74	B/2	Sunload sensor (With auto A/C)
B3	M6	W/4	Headlamp aiming switch	F2	M43	B/2	High-level ventilator door motor (Without auto A/C)	C1	M75	-	Body ground
B2	M7	W/10	Door mirror remote control switch	E2	M44	W/3	High-level ventilator door motor (With auto A/C)	A3	M77	SMJ	To E105
F3	M8	W/8	4WD mode switch (4WD models)	D2	M45	W/4	Hazard switch	A4	M78	B/2	To E106
G3	M11	W/24	To B1	D2	M46	W/20	Audio unit	B1	M80	-/2	Tweeter LH
A4	M13	W/24	To B3	E2	M48	W/12	Audio unit	G2	M81	W/16	To D41
A4	M14	W/8	To B4	D2	M49	W/12	Audio unit	G2	M82	W/10	To D42
F3	M15	W/8	To B5	E2	M52	-/4	High-level ventilator switch	D3	M88	-/8	Fan switch (Without auto A/C)
A2	M18	W/16	To D1	D3	M53	W/40	Auto AMP. (With auto A/C)	F4	M89	-/6	Door lock and unlock switch (Except for the Middle East)
A3	M19	W/10	To D2	D3	M54	GR/20	Heater control panel (Without auto A/C)	E2	M91	W/8	Indicator unit
G1	M22	-/2	Tweeter RH	E5	M55	BR/6	Heated seat switch LH (With heated seat)	F2	M97	Y/2	To M202
A1	M23	W/18	To B1	F4	M56	B/6	Heated seat switch RH (With heated seat)	D1	M99	W/6	To M301
C2	M24	W/2	Key switch	E4	M57	W/16	Control device (With CVT)	E2	M100	W/3	To M302
D2	M25	GR/6	Ignition knob switch, key switch and key lock solenoid (With Intelligent Key system)	F5	M59	Y/28	Air bag diagnosis sensor unit	E5	M103	B/1	Parking brake switch
D3	M26	W/4	NATS antenna amp.	E3	M60	B/2	Power socket	G2	M105	W/12	To D51
C2	M27	W/16	Combination switch	F5	M61	GR/2	Inside key antenna (Console) (With Intelligent Key system)	A3	M111	W/12	To D12
B2	M28	W/4	Steering lock unit (With Intelligent Key system)	F2	M63	-/2	Front passenger air bag module	G5	M113	-/4	Rear high-level ventilator switch (For the Middle East)
B2	M29	W/6	Ignition switch	E2	M64	-/1	Front passenger air bag module				
C3	M30	W/8	Steering angle sensor (With VDC)	F1	M65	B/40	BCM (Body control module)				
C3	M32	Y/6	Combination switch (Spiral cable)	E1	M66	-/12	BCM (Body control module)				
D3	M33	GR/8	Combination switch (Spiral cable)	F1	M67	-/8	BCM (Body control module)				
B2	M34	W/40	Combination meter	D2	M68	B/2	Intake door motor (Without auto A/C)				
F1	M35	-	Body ground	F2	M69	W/16	4WD control unit (4WD models)				
B1	M36	-	Body ground	E3	M70	GR/2	Inside key antenna (Instrument center) (With Intelligent Key system)				
C2	M37	-/8	EPS control unit								

JMMWA0130GI

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PG

HARNESS LAYOUT


< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

LHD : Engine Room Harness

INFOID:000000004897460

ENGINE COMPARTMENT



JMMAWA0133GI

HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

D2	(E1)	GR/2	: Fusible link holder (With gasoline engine)	B3	(E41)	B/2	: Washer pump
D3	(E2)	BR/2	: Fusible link holder (With gasoline engine)	A3	(E42)	-/2	: Headlamp washer pump
D3	(E3)	-/2	: Cooling fan motor	B2	(E43)	B/2	: Parking lamp RH
F3	(E4)	-	: Fuse and fusible link block	A2	(E45)	-/5	: Front combination lamp RH
F2	(E5)	-/3	: Horn relay	A2	(E47)	-/3	: Headlamp aiming motor RH
E3	(E6)	W/24	: To (E123)	B4	(E48)	-/2	: Front fog lamp RH
E3	(E7)	W/16	: To (E121)	C3	(E48)	B/3	: Refrigerant pressure sensor (With gasoline engine)
D3	(E8)	W/2	: To (E122)	B3	(E50)	-/3	: Refrigerant pressure sensor (With M9R engine)
F2	(E9)	B/2	: IPDM E/R (Intelligent power distribution module engine room)	D4	(E51)	-/2	: Horn
F2	(E10)	B/6	: IPDM E/R (Intelligent power distribution module engine room)	C4	(E52)	B/4	: OAT sensor
G3	(E11)	BR/12	: IPDM E/R (Intelligent power distribution module engine room)	F4	(E53)	-/4	: PTC relay-1 (With M9R engine)
F3	(E12)	W/12	: IPDM E/R (Intelligent power distribution module engine room)	F3	(E54)	-/4	: PTC relay-2 (With M9R engine)
F3	(E13)	W/16	: IPDM E/R (Intelligent power distribution module engine room)	E3	(E58)	L/4	: Turbocharger cooling pump relay (With M9R engine)
G3	(E14)	-/6	: IPDM E/R (Intelligent power distribution module engine room)	D3	(E57)	-/3	: Resistor
D2	(E16)	B/32	: ECM (With gasoline engine)	E2	(E58)	B/4	: Heated oxygen sensor 2
E2	(E18)	B/6	: Mass air flow sensor (With gasoline engine)	E4	(E59)	-/4	: Cooling fan relay-3
F2	(E20)	-/5	: Front wiper motor	C1	(E61)	B/3	: To (E200) (With M9R engine)
F4	(E21)	-	: Body ground	D2	(E63)	BR/2	: Fusible link holder (With M9R engine)
F3	(E22)	GR/2	: Front wheel sensor LH	D3	(E64)	GR/2	: Fusible link holder (With M9R engine)
G2	(E23)	-/2	: Side turn signal lamp LH	E2	(E121)	B/32	: ECM (With M9R engine)
E4	(E24)	B/2	: Parking lamp LH	F2	(E122)	B/2	: Turbocharger boost control solenoid valve (With M9R engine)
C3	(E25)	BR/3	: Intelligent Key warning buzzer (With Intelligent Key system)	E2	(E123)	-/5	: Mass air flow meter (With M9R engine)
E4	(E26)	-/5	: Front combination lamp LH	F4	(E126)	-/4	: PTC relay-3 (With M9R engine)
F4	(E28)	-/3	: Headlamp aiming motor LH	F4	(E131)	L/4	: AUX lock control relay-1 (For the Middle East)
F4	(E29)	-	: Body ground	G4	(E132)	BR/6	: AUX lock control relay-2 (For the Middle East)
E5	(E30)	-/2	: Front fog lamp LH	G3	(E133)	L/4	: AUX lock control relay-3 (For the Middle East)
E3	(E32)	L/4	: Headlamp washer relay	C2	(E200)	B/3	: To (E61) (With M9R engine)
C3	(E33)	Y/2	: Crash zone sensor	C2	(E201)	B/3	: Water in fuel sensor (With M9R engine)
D1	(E34)	-/26	: ABS actuator and electric unit (Control unit) (Without VDC)				
D2	(E35)	-	: Body ground				
D1	(E36)	-/26	: ABS actuator and electric unit (Control unit) (With VDC)				
E2	(E37)	GR/2	: Brake fluid level switch				
C2	(E38)	-	: Body ground				
C2	(E39)	GR/2	: Front wheel sensor RH				
C1	(E40)	-/2	: Side turn signal lamp RH				


JMMWA0134GI

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNESS LAYOUT

< COMPONENT DIAGNOSIS >
PASSENGER COMPARTMENT

[POWER SUPPLY & GROUND CIRCUIT]



JMMWA0135GI

HARNES LAYOUT


< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

LHD : Engine Control Harness

INFOID:000000004897461

HR ENGINE



JMMWA0015GI

HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

D2	(F2)	-	Fusible link holder	B2	(F41)	G/2	Intake valve timing control solenoid valve
D2	(F3)	-	Fusible link holder	D3	(F46)	G/3	Park/neutral position switch (With M/T Except 4WD models)
E3	(F7)	GR/32	ECM	C3	(F52)	-	Starter motor
E3	(F8)	BR/48	ECM	C4	(F53)	-	Starter motor
C3	(F9)	-	Engine ground	B3	(F83)	GR/1	Oil pressure switch
B2	(F12)	B/2	Knock sensor	B3	(F85)	B/3	Oil level sensor
C3	(F13)	W/2	Condenser	E3	(F121)	W/16	To (E7)
A3	(F14)	-	Alternator	E3	(F122)	W/2	To (E8)
A2	(F15)	B/3	Alternator	E3	(F123)	W/24	To (E6)
B3	(F17)	B/2	Compressor				
C3	(F20)	B/3	Crankshaft position sensor (POS)				
C2	(F26)	B/3	Camshaft position sensor (PHASE)				
D2	(F28)	GR/2	Engine coolant temperature sensor				
D2	(F29)	B/6	Electric throttle control actuator				
C2	(F30)	B/4	Heated oxygen sensor 1				
C2	(F32)	L/2	EVAP canister purge volume control solenoid valve				
B2	(F33)	GR/3	Ignition coil No. 1 (With power transistor)				
C2	(F34)	GR/3	Ignition coil No. 2 (With power transistor)				
C2	(F35)	GR/3	Ignition coil No. 3 (With power transistor)				
C2	(F36)	GR/3	Ignition coil No. 4 (With power transistor)				
B2	(F37)	GR/2	Fuel injector No. 1				
B2	(F38)	GR/2	Fuel injector No. 2				
C2	(F39)	GR/2	Fuel injector No. 3				
C2	(F40)	GR/2	Fuel injector No. 4				


JMMWA0016GI

HARNESS LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

MR ENGINE



JMMWA0017GI

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PG

HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

E2	(F2)	-	: Fusible link holder	B2	(F41)	G/2	: Intake valve timing control solenoid valve
E2	(F3)	-	: Fusible link holder	D3	(F46)	G/3	: Park/neutral position switch (With M/T, Except 4WD models)
E3	(F7)	GR/32	: ECM	E3	(F48)	B/2	: Park/neutral position switch (With M/T, 4WD models)
E2	(F8)	BR/48	: ECM	E3	(F51)	B/2	: Back-up lamp switch (With M/T, 4WD models)
C2	(F9)	-	: Engine ground	D4	(F55)	B/3	: Primary speed sensor (With CVT)
C2	(F10)	-	: Starter motor	C3	(F63)	GR/1	: Oil pressure switch
C3	(F11)	-	: Starter motor	C3	(F67)	B/2	: Oil level sensor
C3	(F12)	B/2	: Knock sensor	E3	(F121)	W/16	: To (E7)
C2	(F13)	W/2	: Condenser	E3	(F122)	W/2	: To (E8)
B3	(F14)	-	: Alternator	F3	(F123)	W/24	: To (E6)
B2	(F16)	B/3	: Alternator				
B3	(F17)	B/2	: Compressor				
E3	(F19)	B/3	: Secondary speed sensor (With CVT)				
E2	(F20)	B/3	: Crankshaft position sensor (POS)				
D3	(F21)	G/8	: Park/neutral position switch (With CVT)				
E4	(F24)	-/22	: CVT unit (With CVT)				
D4	(F25)	-/48	: TCM (Transmission control module) (With CVT)				
D1	(F26)	B/3	: Camshaft position sensor (PHASE)				
D2	(F28)	GR/2	: Engine coolant temperature sensor				
E2	(F29)	B/6	: Electric throttle control actuator				
D1	(F30)	B/4	: Heated oxygen sensor 1				
D2	(F32)	L/2	: EVAP canister purge volume control solenoid valve				
C1	(F33)	GR/3	: Ignition coil No. 1 (With power transistor)				
C2	(F34)	GR/3	: Ignition coil No. 2 (With power transistor)				
D2	(F35)	GR/3	: Ignition coil No. 3 (With power transistor)				
D2	(F36)	GR/3	: Ignition coil No. 4 (With power transistor)				
C1	(F37)	GR/2	: Fuel injector No. 1				
C2	(F38)	GR/2	: Fuel injector No. 2				
D2	(F39)	GR/2	: Fuel injector No. 3				
D3	(F40)	GR/2	: Fuel injector No. 4				

JMMWA0018G1

HARNESS LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

D3	(F4)	-	: Fusible link holder	C2	(F146)	-/2	: Fuel injector No. 3
D2	(F5)	B/1	: Fusible link holder	C2	(F147)	-/2	: Fuel injector No. 4
B3	(F14)	-	: Alternator	B3	(F148)	-/6	: Electric throttle control actuator (Throttle position sensor/Throttle control motor)
B3	(F15)	B/3	: Alternator	B2	(F149)	-/2	: Fuel rail pressure control valve
B3	(F17)	B/2	: Compressor	C1	(F150)	-/3	: Exhaust gas pressure sensor
B3	(F48)	-	: Starter motor	C3	(F151)	B/2	: EGR cooler bypass valve control solenoid valve
B4	(F50)	-	: Starter motor				
D4	(F51)	B/2	: Back-up lamp switch				
E3	(F54)	B/3	: Turbine revolution sensor				
B3	(F64)	B/2	: Oil pressure switch				
B3	(F67)	B/2	: Oil level sensor				
C4	(F91)	-/3	: Turbocharger boost sensor				
B2	(F95)	-	: Glow plug No. 1				
B2	(F96)	-	: Glow plug No. 2				
C2	(F97)	-	: Glow plug No. 3				
C3	(F98)	-	: Glow plug No. 4				
C3	(F99)	-/6	: EGR volume control valve				
E3	(F108)	-/8	: Glow control unit				
E3	(F121)	W/16	: To (E7)				
E3	(F122)	W/2	: To (E8)				
F3	(F123)	W/24	: To (E5)				
E2	(F131)	B/48	: ECM				
E2	(F132)	BR/48	: ECM				
D4	(F133)	B/2	: Engine coolant temperature sensor				
C2	(F134)	-/2	: Crankshaft position sensor				
D1	(F137)	-/2	: Turbocharger cooling pump				
D2	(F138)	-/3	: Camshaft position sensor				
C4	(F139)	-/3	: Fuel rail pressure sensor				
D2	(F140)	-/2	: Fuel temperature sensor				
D2	(F141)	B/6	: Air fuel ratio sensor				
D2	(F142)	-/2	: Exhaust gas temperature sensor 1				
D2	(F143)	-/2	: Fuel pump				
B2	(F144)	-/2	: Fuel injector No. 1				
C2	(F145)	-/2	: Fuel injector No. 2				

JMMWA0140GI

HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

B3	(B3)	W/24	:	To (M13)	E3	(B80)	-/4	:	Rear combination lamp LH
B3	(B4)	W/8	:	To (M14)	G4	(B81)	GR/2	:	Outside key antenna (Rear bumper)
B2	(B6)	W/4	:	To (D8)				:	(With Intelligent Key system)
A3	(B11)	W/18	:	To (E101)	D2	(B83)	W/4	:	Luggage room lamp
C2	(B14)	Y/12	:	Air bag diagnosis sensor unit	G4	(B84)	B/6	:	To (B201)
C3	(B16)	Y/2	:	Front LH side air bag module	B3	(B88)	W/8	:	To (D81)
C3	(B17)	Y/1	:	Front LH side air bag module	G4	(B90)	B/2	:	Rear fog lamp
C2	(B20)	W/3	:	Heated seat LH (With heated seat)	D2	(B92)	-/16	:	Sonar control unit (With sonar system)
C2	(B22)	W/2	:	Front seat belt buckle switch (Driver side)	E3	(B93)	-/2	:	Buzzer (With sonar system)
E2	(B28)	-	:	Body ground	F3	(B151)	GR/2	:	To (D201)
C4	(B31)	OR/2	:	Front LH seat belt pre-tensioner-2				:	Body sub-harness (With sonar system)
B3	(B34)	W/3	:	Front door switch (Driver side)	F4	(B201)	B/6	:	To (B84)
B4	(B35)	Y/2	:	Front LH seat belt pre-tensioner-1	F5	(B202)	-/3	:	Corner sensor (Rear LH)
B3	(B37)	Y/2	:	LH side air bag (Satellite) sensor	F5	(B203)	-/3	:	Center sensor (Rear LH)
E4	(B44)	GR/2	:	Rear wheel sensor LH	G4	(B204)	-/3	:	Corner sensor (Rear RH)
D3	(B45)	GR/2	:	Inside key antenna (Rear seat) (With Intelligent Key system)	G4	(B205)	-/3	:	Center sensor (Rear RH)
E4	(B46)	GR/2	:	To (B250)				:	Body sub-harness (4WD models)
E3	(B55)	-/2	:	Back-up lamp LH	D4	(B250)	GR/2	:	To (B49)
E1	(B56)	-/2	:	RH side curtain air bag module	E4	(B251)	GR/2	:	4WD solenoid
B3	(B57)	-	:	Body ground				:	
E2	(B58)	B/1	:	Rear window defogger				:	
D3	(B63)	W/4	:	Rear seat belt buckle switch LH and center				:	
D3	(B71)	W/3	:	Rear door switch LH				:	
E1	(B72)	-/2	:	LH side curtain air bag module				:	
E1	(B76)	-/2	:	High-mounted stop lamp				:	
G3	(B77)	W/8	:	To (D157)				:	
G3	(B78)	W/4	:	To (D158)				:	
G3	(B79)	W/2	:	To (D159)				:	

JMMWA0020GI

HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

F3	(B1)	W/24	:	To	(M11)
F3	(B5)	W/8	:	To	(M15)
E2	(B13)	Y/12	:	Air bag diagnosis sensor unit	
D3	(B18)	Y/2	:	Front RH side air bag module	
E3	(B19)	Y/1	:	Front RH side air bag module	
E3	(B21)	W/3	:	Heated seat RH (With heated seat)	
D3	(B23)	W/2	:	Front seat belt buckle switch (Passenger side)	
F3	(B27)	W/3	:	Front door switch (Passenger side)	
E3	(B28)	Y/2	:	Front RH seat belt pre-tensioner	
F3	(B30)	Y/2	:	RH side air bag (Satellite) sensor	
F2	(B33)	-	:	Body ground	
D3	(B38)	GR/5	:	Fuel level sensor unit (With M9R engine 4WD models)	
E4	(B39)	GR/4	:	Fuel level sensor unit (With M9R engine 2WD models)	
E4	(B40)	GR/4	:	Fuel level sensor unit and fuel pump (With gasoline engine)	
C3	(B41)	GR/2	:	Rear wheel sensor RH	
C4	(B43)	-/8	:	Auto levelizer control unit (With headlamp auto aiming)	
D2	(B48)	W/2	:	Occupant detection unit	
D3	(B53)	W/3	:	Rear door switch RH	
C3	(B59)	-/4	:	Rear combination lamp RH	
D3	(B64)	W/4	:	Rear seat belt buckle switch RH and center	
F3	(B88)	W/8	:	To	(D103)

JMMWA0142GI


HARNESS LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

LHD : Room Lamp Harness

INFOID:000000004897463



R1	W/18	:	To	M23
R2	W/3	:	Sunshade switch	
R3	W/4	:	Microphone	
R4	-/6	:	Map lamp	
R5	-/10	:	Sunshade motor assembly	
R7	W/3	:	Personal lamp LH	
R8	W/3	:	Personal lamp RH	
R13	-/3	:	Light & Rain sensor	
R15	-/6	:	Room lamp	

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

JMMWA0145GI

HARNES LAYOUT


[POWER SUPPLY & GROUND CIRCUIT]

< COMPONENT DIAGNOSIS >

LHD : Front Door Harness

INFOID:000000004897464

LH SIDE



- D1 W/16 : To (M18) (With Intelligent Key system)
- D2 W/10 : To (M19)
- D3 GR/8 : Door mirror (Driver side)
- D4 W/2 : Front door speaker LH
- D5 W/16 : Power window main switch
- D6 W/3 : Power window main switch
- D7 B/6 : Front power window motor (Driver side)
- D8 W/4 : To (BB)
- D9 B/6 : Front door lock actuator (Driver side)
- D10 L/2 : Front door request switch (Driver side)
(With Intelligent Key system)
- D11 GR/2 : Outside key antenna (Driver side)
(With Intelligent Key system)
- D12 W/12 : To (M11)
(Without Intelligent Key system)

JMMWA0148G1


HARNESS LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

RH SIDE

- (D41) W/16 : To (M81) (With Intelligent Key system)
- (D42) W/10 : To (M82)
- (D43) GR/8 : Door mirror (Passenger side)
- (D44) W/2 : Front door speaker RH
- (D45) W/8 : Front power window switch (Passenger side)
- (D46) -/2 : Front power window motor (Passenger side)
- (D48) B/6 : Front door lock actuator (Passenger side)
- (D49) L/2 : Front door request switch (Passenger side)
- (D50) GR/2 : (With Intelligent Key system)
Outside key antenna (Passenger side)
- (D51) W/12 : To (M109) (Without Intelligent Key system)



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

JMMWA0149GI

HARNESS LAYOUT


[POWER SUPPLY & GROUND CIRCUIT]

< COMPONENT DIAGNOSIS >

LHD : Rear Door Harness

INFOID:000000004897465

LH SIDE



- | | | | | |
|-----|-----|---|--------------------------|-------|
| D81 | W/8 | : | To | (B86) |
| D82 | -/2 | : | Rear power window motor | LH |
| D83 | W/8 | : | Rear power window switch | LH |
| D84 | W/2 | : | Rear door speaker | LH |
| D85 | B/6 | : | Rear door lock actuator | LH |


JMMWA003GI

HARNES LAYOUT

[POWER SUPPLY & GROUND CIRCUIT]

< COMPONENT DIAGNOSIS >

RH SIDE



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

JMMWA0034GI


HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

LHD : Back Door Harness

INFOID:000000004897466



Back door harness

- D151 W/8 : To D181
- D152 -/4 : Back door lock assembly
- D153 - : Body ground
- D154 -/2 : Back-up lamp RH
- D155 B/1 : Rear window defogger
- D156 -/3 : Rear wiper motor
- D157 W/8 : To B77
- D158 W/4 : To B78
- D159 W/2 : To B79
- D201 GR/2 : To B151

Back door No.2 harness

- D181 W/8 : To D151
- D182 -/2 : License plate lamp LH
- D183 -/2 : License plate lamp RH
- D184 GR/2 : Back door opener switch
- D185 GR/2 : Back door request switch
(With Intelligent Key system)

RHD

JMMWA0147GI

HARNESS LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

RHD : How To Read Harness Layout


INFOID:0000000004897467

The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness
- Engine Control Harness
- Body Harness
- Room Lamp Harness
- Door Harness

To use the grid reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.



CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
<ul style="list-style-type: none"> • Cavity: Less than 4 • Relay connector 				
<ul style="list-style-type: none"> • Cavity: From 5 to 8 				
<ul style="list-style-type: none"> • Cavity: More than 9 				
<ul style="list-style-type: none"> • Ground terminal etc. 	—			


HARNESS LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

RHD : Outline

INFOID:000000004897468



JMMWA0128G1


HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

RHD : Main Harness

INFOID:000000004897469



JMMAWA0131GI

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

F4	(M1)	-/1	Fuse block (J/B)	F2	(M38)	-/2	EPS control unit	D3	(M71)	BR/3	G sensor (4WD models)
F3	(M2)	-/1	Fuse block (J/B)	F2	(M40)	W/40	Intelligent Key unit	C3	(M72)	B/4	YAW rate sensor (With VDC)
F4	(M4)	B/16	Data link connector	D2	(M41)	W/2	In-vehicle sensor (With auto A/C)	B2	(M73)	-/2	Glove box lamp
F3	(M5)	GR/6	VDC off switch (With VDC)	D3	(M42)	W/2	Intake sensor (With auto A/C)	F1	(M74)	B/2	Sunload sensor (With auto A/C)
F3	(M6)	W/4	Headlamp aiming switch	C2	(M43)	B/2	High-level ventilator door motor	E1	(M75)	-	Body ground
F2	(M7)	W/10	Door mirror remote control switch	C1	(M44)	W/3	High-level ventilator door motor	B3	(M77)	SMJ	To (E105)
C4	(M8)	W/8	4WD mode switch (4WD models)	D2	(M45)	W/4	Hazard switch	B3	(M78)	B/2	To (E106)
A2	(M9)	-/6	Air bag cutoff switch	D2	(M46)	W/20	Audio unit	B1	(M80)	-/2	Tweeter LH
G4	(M11)	W/24	To (B1)	C2	(M49)	W/12	Audio unit	A2	(M83)	W/16	To (D61)
B3	(M13)	W/24	To (B3)	C3	(M52)	-/4	High-level ventilator switch	A2	(M84)	W/10	To (D62)
B3	(M14)	W/8	To (B4)	C3	(M53)	W/40	Auto AMP. (With auto A/C)	C3	(M88)	-/8	Fan switch (Without auto A/C)
G4	(M15)	W/8	To (B5)	D3	(M54)	GR/20	Heater control panel	C3	(M89)	-/6	Door lock and unlock switch
G2	(M20)	W/16	To (D21)	B4	(M55)	BR/6	Heated seat switch LH	C2	(M91)	W/8	Indicator unit
G3	(M21)	W/10	To (D22)	C4	(M56)	B/6	Heated seat switch RH	B2	(M97)	Y/2	To (M202)
G1	(M22)	-/2	Tweeter RH	C4	(M57)	W/16	Control device (With CVT)	C2	(M99)	W/8	To (M301)
A1	(M23)	W/18	To (R1)	C5	(M59)	Y/28	Air bag diagnosis sensor unit	D2	(M100)	W/3	To (M302)
E2	(M24)	W/2	Key switch	D3	(M60)	B/2	Power socket	B5	(M103)	B/1	Parking brake switch
F2	(M25)	GR/6	Ignition knob switch, key switch and key lock solenoid	B5	(M61)	GR/2	Inside key antenna (Console)	A2	(M105)	W/12	To (D71)
E3	(M26)	W/4	NATS antenna amp.	A1	(M63)	-/2	Front passenger air bag module	G3	(M112)	W/12	To (D32)
E2	(M27)	W/16	Combination switch	B2	(M64)	-/1	Front passenger air bag module				(Without intelligent Key system)
E2	(M28)	W/4	Steering lock unit	B1	(M65)	B/40	BCM (Body control module)				(Without intelligent Key system)
D3	(M29)	W/6	Ignition switch	C1	(M66)	-/12	BCM (Body control module)				
E3	(M30)	W/8	Steering angle sensor (With VDC)	B1	(M67)	-/8	BCM (Body control module)				
E3	(M32)	Y/6	Combination switch (Spiral cable)	C2	(M68)	B/2	Intake door motor (Without auto A/C)				
E3	(M33)	GR/8	Combination switch (Spiral cable)	B2	(M69)	W/16	4WD control unit (4WD models)				
E2	(M34)	W/40	Combination meter	D3	(M70)	GR/2	Inside key antenna (Instrument center)				
C1	(M35)	-	Body ground				(With intelligent Key system)				
F1	(M36)	-	Body ground								
E2	(M37)	-/8	EPS control unit								

JMMWAO13201

HARNES LAYOUT


< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

RHD : Engine Room Harness

INFOID:000000004897470

ENGINE COMPARTMENT



JMMWA0136GI

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PG

HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]


D2	(E1)	GR/2	: Fusible link holder (With gasoline engine)	B3	(E41)	B/2	: Washer pump
D3	(E2)	BR/2	: Fusible link holder (With gasoline engine)	A3	(E42)	-/2	: Headlamp washer pump
D3	(E3)	-/2	: Cooling fan motor	B2	(E43)	B/2	: Parking lamp RH
F3	(E4)	-	: Fuse and fusible link block	A2	(E45)	-/5	: Front combination lamp RH
F3	(E5)	-/3	: Horn relay	A2	(E47)	-/3	: Headlamp aiming motor RH
E3	(E6)	W/24	: To (F123)	B4	(E48)	-/2	: Front fog lamp RH
E3	(E7)	W/16	: To (F121)	C3	(E49)	B/3	: Refrigerant pressure sensor (With gasoline engine)
D3	(E8)	W/2	: To (F122)	B3	(E50)	-/3	: Refrigerant pressure sensor (With M9R engine)
F3	(E9)	B/2	: IPDM E/R (Intelligent power distribution module engine room)	D4	(E51)	-/2	: Horn
F2	(E10)	B/6	: IPDM E/R (Intelligent power distribution module engine room)	C4	(E52)	B/4	: OAT sensor
G3	(E11)	BR/12	: IPDM E/R (Intelligent power distribution module engine room)	F4	(E53)	-/4	: PTC relay-1 (With M9R engine)
F3	(E12)	W/12	: IPDM E/R (Intelligent power distribution module engine room)	F4	(E54)	-/4	: PTC relay-2 (With M9R engine)
F3	(E13)	W/16	: IPDM E/R (Intelligent power distribution module engine room)	E3	(E56)	L/4	: Turbocharger cooling pump relay (With M9R engine)
F3	(E14)	-/6	: IPDM E/R (Intelligent power distribution module engine room)	D3	(E57)	-/3	: Resistor
D2	(E16)	B/32	: ECM (With gasoline engine)	D2	(E58)	B/4	: Heated oxygen sensor 2
E2	(E18)	B/6	: Mass air flow sensor (With gasoline engine)	E4	(E59)	-/4	: Cooling fan relay-3
D1	(E20)	-/5	: Front wiper motor	C2	(E60)	B/3	: Water in fuel sensor (With M9R engine)
F4	(E21)	-	: Body ground	D3	(E63)	BR/2	: Fusible link holder (With M9R engine)
E3	(E22)	GR/2	: Front wheel sensor LH	D2	(E64)	GR/2	: Fusible link holder (With M9R engine)
G2	(E23)	-/2	: Side turn signal lamp LH	E2	(E121)	B/32	: ECM (With M9R engine)
E4	(E24)	B/2	: Parking lamp LH	E2	(E122)	B/2	: Turbocharger boost control solenoid valve (With M9R engine)
C3	(E25)	BR/3	: Intelligent Key warning buzzer (With Intelligent Key system)	F2	(E123)	-/5	: Mass air flow meter (With M9R engine)
E4	(E26)	-/5	: Front combination lamp LH	F4	(E126)	-/4	: PTC relay-3 (With M9R engine)
F4	(E28)	-/3	: Headlamp aiming motor LH				
F4	(E29)	-	: Body ground				
E5	(E30)	-/2	: Front fog lamp LH				
E3	(E32)	L/4	: Headlamp washer relay				
C3	(E33)	Y/2	: Crash zone sensor				
E1	(E34)	-/26	: ABS actuator and electric unit (Control unit) (Without VDC)				
E2	(E35)	-	: Body ground				
E1	(E36)	-/26	: ABS actuator and electric unit (Control unit) (With VDC)				
D1	(E37)	GR/2	: Brake fluid level switch				
C2	(E38)	-	: Body ground				
C2	(E39)	GR/2	: Front wheel sensor RH				
C1	(E40)	-/2	: Side turn signal lamp RH				

JMMWA0137GI

HARNES LAYOUT

[POWER SUPPLY & GROUND CIRCUIT]

< COMPONENT DIAGNOSIS >
PASSENGER COMPARTMENT



JMMWA0138GI

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNESS LAYOUT


< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

RHD : Engine Control Harness

INFOID:000000004897471

HR ENGINE



JMMWA0015G1

HARNESS LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

D2	(F2)	-	: Fusible link holder	B2	(E41)	G/2	: Intake valve timing control solenoid-valve
D2	(F3)	-	: Fusible link holder	D3	(E46)	G/3	: Park/neutral position switch (With M/T Except 4WD models)
E3	(F7)	GR/32	: ECM	C3	(E52)	-	: Starter motor
E3	(F8)	BR/48	: ECM	C4	(E53)	-	: Starter motor
C3	(F9)	-	: Engine ground	B3	(E63)	GR/1	: Oil pressure switch
B2	(F12)	B/2	: Knock sensor	B3	(E65)	B/3	: Oil level sensor
C3	(F13)	W/2	: Condenser	E3	(E121)	W/16	: To (E7)
A3	(F14)	-	: Alternator	E3	(E122)	W/2	: To (E8)
A2	(F15)	B/3	: Alternator	E3	(E123)	W/24	: To (E6)
B3	(F17)	B/2	: Compressor				
C3	(F20)	B/3	: Crankshaft position sensor (POS)				
C2	(F26)	B/3	: Camshaft position sensor (PHASE)				
D2	(F28)	GR/2	: Engine coolant temperature sensor				
D2	(F29)	B/6	: Electric throttle control actuator				
C2	(F30)	B/4	: Heated oxygen sensor 1				
C2	(F32)	L/2	: EVAP canister purge volume control solenoid valve				
B2	(F33)	GR/3	: Ignition coil No. 1 (With power transistor)				
C2	(F34)	GR/3	: Ignition coil No. 2 (With power transistor)				
C2	(F35)	GR/3	: Ignition coil No. 3 (With power transistor)				
C2	(F36)	GR/3	: Ignition coil No. 4 (With power transistor)				
B2	(F37)	GR/2	: Fuel injector No. 1				
B2	(F38)	GR/2	: Fuel injector No. 2				
C2	(F39)	GR/2	: Fuel injector No. 3				
C2	(F40)	GR/2	: Fuel injector No. 4				

JMMWA0016G1


A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNESS LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

MR ENGINE



JMMWA0017G1

HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

E2	(F2)	-	: Fusible link holder	B2	(F41)	G/2	: Intake valve timing control solenoid valve
E2	(F3)	-	: Fusible link holder	D3	(F46)	G/3	: Park/neutral position switch (With M/T, Except 4WD models)
E3	(F7)	GR/32	: ECM	E3	(F49)	B/2	: Park/neutral position switch (With M/T, 4WD models)
E2	(F8)	BR/48	: ECM	E3	(F51)	B/2	: Back-up lamp switch (With M/T, 4WD models)
C2	(F9)	-	: Engine ground	D4	(F55)	B/3	: Primary speed sensor (With CVT)
C2	(F10)	-	: Starter motor	C3	(F63)	GR/1	: Oil pressure switch
C3	(F11)	-	: Starter motor	C3	(F67)	B/2	: Oil level sensor
C3	(F12)	B/2	: Knock sensor	E3	(F121)	W/16	: To (E7)
C2	(F13)	W/2	: Condenser	E3	(F122)	W/2	: To (E8)
B3	(F14)	-	: Alternator	F3	(F123)	W/24	: To (E6)
B2	(F15)	B/3	: Alternator				
B3	(F17)	B/2	: Compressor				
E3	(F19)	B/3	: Secondary speed sensor (With CVT)				
E2	(F20)	B/3	: Crankshaft position sensor (POS)				
D3	(F21)	G/8	: Park/neutral position switch (With CVT)				
E4	(F24)	-/22	: CVT unit (With CVT)				
D4	(F25)	-/48	: TCM (Transmission control module) (With CVT)				
D1	(F26)	B/3	: Camshaft position sensor (PHASE)				
D2	(F28)	GR/2	: Engine coolant temperature sensor				
E2	(F29)	B/6	: Electric throttle control actuator				
D1	(F30)	B/4	: Heated oxygen sensor 1				
D2	(F32)	L/2	: EVAP canister purge volume control solenoid valve				
C1	(F33)	GR/3	: Ignition coil No. 1 (With power transistor)				
C2	(F34)	GR/3	: Ignition coil No. 2 (With power transistor)				
D2	(F35)	GR/3	: Ignition coil No. 3 (With power transistor)				
D2	(F36)	GR/3	: Ignition coil No. 4 (With power transistor)				
C1	(F37)	GR/2	: Fuel injector No. 1				
C2	(F38)	GR/2	: Fuel injector No. 2				
D2	(F39)	GR/2	: Fuel injector No. 3				
D3	(F40)	GR/2	: Fuel injector No. 4				

JMMWA0018GI

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNESS LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

M9R ENGINE



JMMWA0139GI

HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

D3	F4	-	Fusible link holder	C2	F146	-/2	Fuel injector No. 3
D2	F5	B/1	Fusible link holder	C2	F147	-/2	Fuel injector No. 4
B3	F14	-	Alternator	B3	F148	-/6	Electric throttle control actuator (Throttle position sensor/Throttle control motor)
B3	F15	B/3	Alternator	B2	F149	-/2	Fuel rail pressure control valve
B3	F17	B/2	Compressor	C1	F150	-/3	Exhaust gas pressure sensor
B3	F49	-	Starter motor	C3	F151	B/2	EGR cooler bypass valve control solenoid valve
B4	F50	-	Starter motor				
D4	F51	B/2	Back-up lamp switch				
E3	F54	B/3	Turbine revolution sensor				
B3	F64	B/2	Oil pressure switch				
B3	F67	B/2	Oil level sensor				
C4	F81	-/3	Turbocharger boost sensor				
B2	F95	-	Glow plug No. 1				
B2	F96	-	Glow plug No. 2				
C2	F97	-	Glow plug No. 3				
C3	F98	-	Glow plug No. 4				
C3	F99	-/6	EGR volume control valve				
E3	F109	-/8	Glow control unit				
E3	F121	W/16	To E7				
E3	F122	W/2	To E8				
F3	F123	W/24	To E6				
E2	F131	B/48	ECM				
E2	F132	BR/48	ECM				
D4	F133	B/2	Engine coolant temperature sensor				
C2	F134	-/2	Crankshaft position sensor				
D1	F137	-/2	Turbocharger cooling pump				
D2	F138	-/3	Camshaft position sensor				
C4	F139	-/3	Fuel rail pressure sensor				
D2	F140	-/2	Fuel temperature sensor				
D2	F141	B/6	Air fuel ratio sensor				
D2	F142	-/2	Exhaust gas temperature sensor 1				
D2	F143	-/2	Fuel pump				
B2	F144	-/2	Fuel injector No. 1				
C2	F145	-/2	Fuel injector No. 2				

JMMWA0140GI

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PG

HARNESS LAYOUT


< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

RHD : Body Harness

INFOID:000000004897472

LH SIDE



JMMWA0023GI

HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

B3	B3	W/24	: To (M13)	E3	(B80)	-/4	: Rear combination lamp LH
B3	B4	W/8	: To (M14)	G4	(B81)	GR/2	: Outside key antenna (Rear bumper) (With Intelligent Key system)
A3	B11	W/18	: To (E101)	D2	(B83)	W/4	: Luggage room lamp
C2	B14	Y/12	: Air bag diagnosis sensor unit	G4	(B84)	B/6	: To (B201)
C3	B16	Y/2	: Front LH side air bag module	B3	(B87)	W/8	: To (G111)
C3	B17	Y/1	: Front LH side air bag module	G4	(B90)	B/2	: Rear fog lamp
C2	B20	W/3	: Heated seat LH (With heated seat)	D2	(B92)	-/16	: Sonar control unit (With sonar system)
C2	B23	W/2	: Front seat belt buckle switch (Passenger side)	E3	(B93)	-/2	: Buzzer (With sonar system)
E2	B26	-	: Body ground	F3	(G151)	GR/2	: To (G201)
B3	B27	W/3	: Front door switch (Passenger side)	Body sub-harness (With sonar system)			
C3	B36	Y/2	: Front LH seat belt pre-tensioner	F4	(B201)	B/6	: To (B84)
B3	B37	Y/2	: LH side air bag (Satellite) sensor	F5	(B202)	-/3	: Corner sensor (Rear LH)
E4	B44	GR/2	: Rear wheel sensor LH	F5	(B203)	-/3	: Center sensor (Rear LH)
D3	B45	GR/2	: Inside key antenna (Rear seat) (With Intelligent Key system)	G4	(B204)	-/3	: Corner sensor (Rear RH)
E4	B46	GR/2	: To (B250)	G4	(B205)	-/3	: Center sensor (Rear RH)
C2	B48	W/2	: Occupant detection unit	Body sub-harness (4WD models)			
E3	B55	-/2	: Back-up lamp LH	D4	(B250)	GR/2	: To (B46)
E1	B56	-/2	: RH side curtain air bag module	E4	(B251)	GR/2	: 4WD solenoids
B3	B57	-	: Body ground				
E2	B58	B/1	: Rear window defogger				
C3	B63	W/4	: Rear seat belt buckle switch LH and center				
D3	B71	W/3	: Rear door switch LH				
E1	B72	-/2	: LH side curtain air bag module				
E1	B76	-/2	: High-mounted stop lamp				
G3	B77	W/8	: To (G157)				
G3	B78	W/4	: To (G158)				
G3	B79	W/2	: To (G159)				

JMMWA0024GI


A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNESS LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

RH SIDE



JMMWA0143GI

HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

F3	B1	W/24	To	M11
F3	B5	W/8	To	M15
F2	B9	W/4	To	D28
E3	B13	Y/12	Air bag diagnosis sensor unit	
E2	B18	Y/2	Front RH side air bag module	
D3	B19	Y/1	Front RH side air bag module	
E3	B21	W/3	Heated seat RH (With heated seat)	
E2	B22	W/2	Front seat belt buckle switch (Driver side)	
F3	B29	Y/2	Front RH seat belt pre-tensioner-1	
F3	B30	Y/2	RH side air bag (Satellite) sensor	
F2	B33	-	Body ground	
F3	B34	W/3	Front door switch (Driver side)	
D3	B38	GR/5	Fuel level sensor unit (With M9R engine 4WD models)	
E4	B39	GR/4	Fuel level sensor unit (With M9R engine 2WD models)	
E4	B40	GR/2	Fuel level sensor unit and fuel pump	
C3	B41	GR/2	Rear wheel sensor RH	
E4	B42	OR/2	Front RH seat belt pre-tensioner-2	
C4	B43	-/8	Auto levelizer control unit (With headlamp auto aiming)	
D3	B53	W/3	Rear door switch RH	
C3	B59	-/4	Rear combination lamp RH	
D3	B64	W/4	Rear seat belt buckle switch RH and center	
F3	B69	W/8	To	D91

JMMWA0144GI

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PG


HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

RHD : Room Lamp Harness

INFOID:000000004897473



- | | | | |
|-------|------|---|-------------------------|
| (R1) | W/18 | : | To (M23) |
| (R2) | W/3 | : | Sunshade switch |
| (R3) | W/4 | : | Microphone |
| (R4) | -/6 | : | Map lamp |
| (R5) | -/10 | : | Sunshade motor assembly |
| (R7) | W/3 | : | Personal lamp LH |
| (R8) | W/3 | : | Personal lamp RH |
| (R13) | -/3 | : | Light & Rain sensor |
| (R15) | -/6 | : | Room lamp |

JMMWAD146GI

HARNES LAYOUT


< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

RHD : Front Door Harness

INFOID:000000004897474

LH'SIDE



- D61 W/16 : To M83 (With Intelligent Key system)
- D62 W/10 : To M82
- D63 W/8 : Door mirror (Passenger side)
- D64 W/2 : Front door speaker LH
- D65 W/8 : Front power window switch (Passenger side)
- D66 -/2 : Front power window motor (Passenger side)
- D68 B/6 : Front door lock actuator (Passenger side)
- D69 L/2 : Front door request switch (Passenger side)
- D70 GR/2 : (With Intelligent Key system)
Outside key antenna (Passenger side)
- D71 W/12 : To M105 (With Intelligent Key system)
(Without Intelligent Key system)

JMMWAD150GI

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P


HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

RH SIDE

- D21 W/16 : To M20 (With Intelligent Key system)
- D22 W/10 : To M21
- D23 GR/8 : Door mirror (Driver side)
- D24 W/2 : Front door speaker RH
- D25 W/16 : Power window main switch
- D26 W/3 : Power window main switch
- D27 B/6 : Front power window motor (Driver side)
- D28 W/4 : To B5
- D29 B/6 : Front door lock actuator (Driver side)
- D30 L/2 : Front door request switch (Driver side)
- D31 GR/2 : Outside key antenna (Driver side)
(With Intelligent Key system)
- D32 W/12 : To M12
(Without Intelligent Key system)



JMMWA0151GI

HARNES LAYOUT


[POWER SUPPLY & GROUND CIRCUIT]

< COMPONENT DIAGNOSIS >

RHD : Rear Door Harness

INFOID:000000004897475

LH SIDE



- | | | | |
|--------|-----|----------|-----------------------------|
| (D111) | W/8 | To (B87) | |
| (D112) | -/2 | | Rear power window motor LH |
| (D113) | W/8 | | Rear power window switch LH |
| (D114) | W/2 | | Rear door speaker LH |
| (D115) | B/6 | | Rear door lock actuator LH |

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P


JMMWA0035GI

HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

RH SIDE



JMMWA0036G1


HARNES LAYOUT

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

RHD : Back Door Harness

INFOID:000000004897476



Back door harness

- D151 W/8 : To D181
- D152 -/4 : Back door lock assembly
- D153 - : Body ground
- D154 -/2 : Back-up lamp RH
- D155 B/1 : Rear window defogger
- D156 -/3 : Rear wiper motor
- D157 W/8 : To B77
- D158 W/4 : To B78
- D159 W/2 : To B79
- D201 GR/2 : To B15

Back door No. 2 harness

- D181 W/8 : To D151
- D184 -/2 : License plate lamp LH
- D185 -/2 : License plate lamp RH
- D186 GR/2 : Back door opener switch
- D187 GR/2 : Back door request switch
(With Intelligent Key system)

JMMWA0147G1

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PG

ELECTRICAL UNITS

< COMPONENT DIAGNOSIS >


[POWER SUPPLY & GROUND CIRCUIT]

ELECTRICAL UNITS


Terminal Arrangement

INFOID:000000004897477


ECM




ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)



BCM (BODY CONTROL MODULE)



TCM (TRANSMISSION CONTROL MODULE)



VD : With VDC
OV : Without VDC

JMMWAD125G1

SMJ (SUPER MULTIPLE JUNCTION)


< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

SMJ (SUPER MULTIPLE JUNCTION)

Terminal Arrangement

INFOID:000000004897478



A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

PG

JMMWA0043GI

HARNESS CONNECTOR

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

HARNESS CONNECTOR

Description

INFOID:000000004897479


HARNESS CONNECTOR (TAB-LOCKING TYPE)

- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the figure below.

CAUTION:

Never pull the harness or wires when disconnecting the connector.

[Example]



SEL768DA

HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the figure below.

HARNESS CONNECTOR


[POWER SUPPLY & GROUND CIRCUIT]

< COMPONENT DIAGNOSIS >

CAUTION:

- Never pull the harness or wires when disconnecting the connector.
- Be careful not to damage the connector support bracket when disconnecting the connector.

[Example]



HARNESS CONNECTOR (LEVER LOCKING TYPE)

- Lever locking type harness connectors are used on certain control units and control modules such as ECM, ABS actuator and electric unit (control unit), etc.
- Lever locking type harness connectors are also used on super multiple junction (SMJ) connectors.
- Always confirm the lever is fully locked in place by moving the lever as far as it will go to ensure full connection.

CAUTION:


A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

HARNESS CONNECTOR

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

Always confirm the lever is fully released (loosened) before attempting to disconnect or connect these connectors to avoid damage to the connector housing or terminals.



1. Control unit with single lever
A. Fasten
B. Loosen
C. Lever

2. Control unit with dual levers
A. Levers
B. Fasten
C. Loosen

3. SMJ connector
A. Lever
B. Fasten
C. Loosen

STANDARDIZED RELAY

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]


STANDARDIZED RELAY

Description

INFOID:000000004897480

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H

TYPE OF STANDARDIZED RELAYS

- 1M 1 Make
- 1T 1 Transfer
- 2M 2 Make
- 1M-1B 1 Make 1 Break

















SEL882H

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

STANDARDIZED RELAY

< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M-1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL188W

FUSE BLOCK - JUNCTION BOX (J/B)




[POWER SUPPLY & GROUND CIRCUIT]

< COMPONENT DIAGNOSIS >

FUSE BLOCK - JUNCTION BOX (J/B)

Fuse, Connector and Terminal Arrangement

INFOID:000000004897481



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

JMMWA0044GI

FUSE, FUSIBLE LINK AND RELAY BOX


< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]


FUSE, FUSIBLE LINK AND RELAY BOX

Fuse and Fusible Link Arrangement

INFOID:000000004897462



Fusible link holder (E1), (E2), (F2), (F3) (Gasoline engine)
 (E63), (E64), (F5) (M9R engine)



JMMWA01263I

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


< COMPONENT DIAGNOSIS >

[POWER SUPPLY & GROUND CIRCUIT]

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Fuse, Connector and Terminal Arrangement

INFOID:000000004897483



A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000004897484

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

BATTERY

< ON-VEHICLE REPAIR >

[POWER SUPPLY & GROUND CIRCUIT]


ON-VEHICLE REPAIR

BATTERY

Exploded View

- 1 : Battery terminal (+)
- 2 : Battery fix frame
- 3 : Battery fix frame mounting nuts
- 4 : Battery terminal (-)

INFOID:000000004897485




Removal and Installation

INFOID:000000004897486

REMOVAL

1. Loosen battery terminal nuts (1), and disconnect both battery cables from battery terminals.
CAUTION:
When disconnecting, disconnect the battery cable from the negative terminal first.
2. Remove battery fix frame mounting nuts (3) to remove battery fix frame (2).
3. Remove battery.



INSTALLATION

Install in the reverse order of removal.

CAUTION:

When connecting, connect the battery cable to the positive terminal first.

Battery fix frame mounting nut

: 5.4 N·m (0.55 kg-m, 48 in-lb)

Battery terminal nut

: 5.4 N·m (0.55 kg-m, 48 in-lb)

A
B
C
D
E
F
G
H
I
J
K
L
PG
N
O
P

BATTERY TERMINAL WITH FUSIBLE LINK


< ON-VEHICLE REPAIR >

[POWER SUPPLY & GROUND CIRCUIT]

BATTERY TERMINAL WITH FUSIBLE LINK

Exploded View

INFOID:000000004897487




1. Harness mounting nut
2. Fusible link holder mounting nut
3. Harness connector
4. Battery terminal with fusible link

Removal and Installation

INFOID:000000004897488

REMOVAL

1. Disconnect the battery cable from the negative terminal.
2. Remove cover of battery positive terminal.
3. Remove harness mounting nut (1) to disconnect harness connector (3).
4. Remove fusible link holder mounting nut (2) to remove battery terminal with fusible link (4).



INSTALLATION


Install in the reverse order of removal.

BATTERY TERMINAL WITH FUSIBLE LINK


< ON-VEHICLE REPAIR >

[POWER SUPPLY & GROUND CIRCUIT]

Harness mounting nut

: 10.3 N·m (1.1 kg-m, 8 ft-lb)

Fusible link holder mounting nut

: 10.3 N·m (1.1 kg-m, 8 ft-lb)

www.cargeek.ir

A
B
C
D
E
F
G
H
I
J
K
L

PG

N
O
P

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[POWER SUPPLY & GROUND CIRCUIT]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Battery

INFOID:000000004897489

Specification		Gasoline engine models	Diesel engine models
Type		L2	L3
20 hour rate capacity	[V - Ah]	12 - 60	12 - 70
Cold cranking current (For reference value)	[A]	600	720

www.cargoeek.ir