www.CarGeek.ir

MEGANE



23A AUTOMATIC TRANSMISSION

77 11 321 322

SEPTEMBER 2005

EDITION ANGLAISE

"The repair procedures given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The procedures may be modified as a result of changes introduced by the manufacturer in the production of the various component units and accessories from which his vehicles are constructed."

All rights reserved by Renault s.a.s.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of Renault s.a.s.

© Renault s.a.s. 2005

www.cargeek.ir

Transmission

Contents

Page

AUTOMATIC TRANSMISSION

	23A	AUTOMATIC TRANSMISSION	
4		Program no.: 94	
		Vdiag no.: 10	
		Introduction	23A-1
		Fault finding log	23A-5
		System operation	23A-7
		Allocation of tracks	23A-11
		Replacement of components	23A-13
		Configurations and programming	23A-14
		Fault summary table	23A-15
		Interpretation of faults	23A-16
		Conformity check	23A-61
		Status summary table	23A-73
		Interpretation of statuses	23A-74
		Parameter summary table	23A-94
		Interpretation of parameters	23A-95
		Dealing with command modes	23A-102
		Customer complaints	23A-104
		Fault finding chart	23A-106

AUTOMATIC TRANSMISSION

SIEMENS TA 2000

Vdiag no.: 14	
Introduction	23A-1
Fault finding log	23A-6
System operation	23A-8
Allocation of tracks	23A-13
Replacement of components	23A-15
Configurations and programming	23A-16
Fault summary table	23A-17
Interpretation of faults	23A-19
Conformity check	23A-70
Interpretation of statuses	23A-85
Parameter summary table	23A-105
Interpretation of parameters	23A-106
Fault finding chart	23A-126

ABBREVIATIONS

ABBREVIATIONS	MEANING OF ABBREVIATION			
ABS	Anti-lock braking system			
ALP	Fault finding chart			
APC	After ignition feed			
AVC	Before ignition feed			
BVA	Automatic transmission			
BVM	Manual gearbox			
BVR	Semi-automatic			
CAN	Controller Area Network			
AC	Air conditioning			
CD	Compact disc			
PAS	Power assisted steering (hydraulic)			
DAE	Electric power assisted steering			
DVD	Digital versatile disc			
DTC	Fault finding code			
EGR	Exhaust gas recirculation			
ESP	Electronic stability program			
GMV	Fan unit			
GNC	Compressed natural gas			
LPG	Liquified petroleum gas			
HLE	High elastic limit			
MAG	Metal active gas (for welding steel)			
MIG	Metal inert gas (for welding aluminium)			
MR	Workshop repair manual			
ТN	Technical note			
OBD	On board diagnostics			
SER	Resistance spot welding			
SSPP	Tyre pressure monitor			
THLE	Very high elastic limit			
ТМ	Labour time			
UCH	UCH			
UPC	Protection and switching unit			
ист	Roof control unit			
UHLE	Ultra high elastic limit			
VIN	Vehicle identification number			

www.cargeek.ir



1. SCOPE OF THIS DOCUMENT

This document presents the fault finding procedure applicable to all computers with the following specifications:

Vehicle(s): **MEGANE II** Function concerned: **AUTOMATIC TRANSMISSION** Name of computer: **Siemens TA 2000** Program no.: **94** VDIAG no.: **10**

2. ITEMS REQUIRED FOR FAULT FINDING

Documentation:

Fault finding procedures (this manual):

- Assisted fault finding (included in the diagnostic tool), Dialogys.

Wiring Diagrams:

- Visu-Schéma (CD-ROM), paper version.

Diagnostic tools: – CLIP

Special tooling required:

	Special tooling required
	Multimeter
Elé. 1681	Universal bornier
Elé. 1588	Bornier

3. REMINDERS

Procedure

To carry out fault finding on the vehicle's computers, switch the ignition to fault finding mode (forced + after ignition). Proceed as follows:

- Renault card in the card reader (keyless vehicle scenario 1, entry-level, not hands-free and scenario 2, top of the range, hands-free).
- Press and hold the start button (longer than **5 seconds**) with starting conditions not met.
- Then connect the diagnostic tool and carry out the required operations.

Note:

The left and right-hand discharge bulb computers are fed when the dipped headlights are switched on. It is only possible to test them after the ignition has been switched on in fault finding mode (forced + after ignition feed) and the dipped headlights are switched on.

To cut off the + after ignition, proceed as follows:

- Disconnect the diagnostic tool.
- Press the start button twice briefly (less than **3 seconds**).
- Check that the forced + after ignition feed has been cut off by observing the extinction of the computer warning lights on the instrument panel.



Faults

Faults are displayed as present or stored (they appeared in a certain context and have since disappeared, or they are still present but cannot be diagnosed in the current context).

The "**present**" or "**stored**" status of faults must be taken into account when using the diagnostic tool after switching on the + after ignition (without activating the system components).

Deal with present faults according to the procedure shown in the section on "Interpretation of faults".

For a stored fault, note the faults displayed and follow the instructions shown in the "Notes" section.

If the fault is **confirmed** when the notes are applied, the fault is present. In this case, deal with the fault.

If the fault is **not confirmed**, check:

- the electrical lines which correspond to the fault,
- the connectors on these lines (corrosion, bent pins, etc.),
- the resistance of the component detected as faulty,
- the condition of the wires (melted or split insulation, chafing).

Conformity check

The aim of the conformity check is to check the statuses and parameters that do not display a fault on the diagnostic tool when they are inconsistent. Therefore, this step is used to:

- Find faults which are not displayed but which may correspond to a customer complaint.
- Check that the system is operating correctly, and that there is no risk of a fault recurring after repair.

This section explains the fault finding procedures for statuses and parameters, and the conditions for checking them.

If the correct status is not displayed or a parameter is outside permitted tolerance values, you should consult the relevant fault finding page.

Customer complaints - Fault finding charts

If the diagnostic tool check is correct, but the customer complaint persists, the problem should be dealt with according to the "customer complaint".

A summary of the overall procedure to follow is provided on the following page in the form of a flow chart.



4. FAULT FINDING PROCEDURE





5. FAULT FINDING LOG



All faults in a complex system require a thorough diagnostic check with the appropriate tools. The FAULT FINDING LOG, which should be completed during the procedure, enables you to keep track of the fault finding carried out. It is an essential document for consultation with the manufacturer.

IT IS THEREFORE COMPULSORY TO COMPLETE A FAULT FINDING LOG EVERY TIME FAULT FINDING **IS CARRIED OUT.**

You will always be asked for this sheet:

NOTE

- When requesting technical assistance from the Techline.
- When requesting approval to replace parts for which approval is compulsory.
- To be attached to "monitored" parts required to be returned. The log is required for warranty reimbursement, and enables better analysis of the parts removed.

6. SAFETY INSTRUCTIONS

All work on components requires that the safety rules be obeyed to prevent damage or injury:

- Make sure that the battery is properly charged to avoid damaging the computers by using too low a voltage. - Use the proper tools.

7. LIST OF ABBREVIATIONS

- ABS: Anti-lock braking system
- ALP: Fault Finding Chart
- APC: After ignition
- BVA: Automatic transmission
- Controller area network CAN:
- CC: Short circuit
- CO: Open circuit
- Drive D:
- P/N: Park/Neutral
- R: Reverse

www.CarGeek.ir FAULT FINDING LOG

System: Automatic or semiautomatic gearbox

Page 1/2

List of monitored parts: Computer

Administrative identification							
Date		2	0	7			
Log completed by			<u> </u>	<u>_</u>			
VIN							
Engine							<u> </u>
Diagnostic tool	CLIP						
Update version							
<u>Customer complaint</u>							
681 Gears not changing		622 No	bise			679	No drive
680 Slipping		675 W	arning light illun	ninates	i —	682	Loss of power
683 Jolts or jerks	1 1	684 "3	H"		jĒ	685	Erratic gear change
Other Your comm	ients:	C	5				
<u>Conditions under whick</u>	<u>n the custo</u>	omer com	plaint occur	<u>'S</u>			
005 While driving		004 Int	ermittently			008	When decelerating
007 When accelerating 009 S			ıdden fault			010	Gradual deterioration
Other Your comments:							
Documentation used for	r fault find	ling					
		Fault fir	nding proce	dure usec		0	
Type of diagnostic manual:	Works	shop Repai	r Manual 📋	Techn	ical Note		Assisted fault finding
Fault finding manual no.:	Fault finding manual no.:						
Wiring diagram used							
Wiring Diagram Technical Note no.:							
Other documentation							
Title and/or part number:							
RENAULT	FD 12 Fault finding log						

page to print or photocopy - page to print or photocopy - page to print or photocopy

www.cargeek.ir

FAULT

System: Automatic or semiautomatic gearbox

Page 2/2

Identification of the computer and parts replaced in the system

Part 1 part number		
Part 2 part number		
Part 3 part number		
Part 4 part number		
Part 5 part number		
To be read with the diagnostic tool (Identification screen):		
Computer part number		
Supplier no.		
Program no.		
Software version		
Calibration no.		
VDIAG		

Faults found with the diagnostic tool

Fault no.	Present	Stored	Fault name	Description

• Context in which fault occurs

Status or parameter no.	Parameter name	Value	Unit

System-specific information

Description:

Additional information

Gearbox number

If the gearbox is automatic, which mode is it (automatic/semiautomatic)?				
Gear changes affected?				
Result of the gearbox oil level check				
Result of the oil level check with "Add-On"				
Appearance of the oil				
Oil leak?				
Location of the leak				
Type of noise (metallic, rubbing, etc.)				
Does the buzzer work?				
What factors led you to replace the computer?				
What other parts were replaced?				

Other faulty functions?

Your comments:



No 🔲	Seepage 🔲	Drops 🔲			
Yes 🔲	No 🗖				
2					

FD 12 Fault finding log

page to print or photocopy - page to print or photocopy - page to print or photocopy



GENERAL OPERATION

The automatic transmission on this model is the DP0, which is also found on other Renault vehicles including Laguna II, Clio II and Kangoo.

The automatic transmission computer controls gear-changing using several parameters, among them engine torque and the driver's driving style.

All signals travel to the computer by wire, except for those from the injection computer, which use the multiplex network.

Line K is used for computer diagnostics.

SYSTEM OPERATION

Multifunction switch (CMF) statuses:

Note:

Multifunction switch contact S1 is not connected on this model. Ignore **ET154 "Multifunction switches"**.

Lover position	Multifunction switch contact			
Lever position	S2	 	 S4	
Р	CLOSED	OPEN	OPEN	
R	CLOSED	CLOSED	CLOSED	
Ν	OPEN	CLOSED	OPEN	
D	OPEN	OPEN-	CLOSED	
М	OPEN	OPEN	CLOSED	
+	OPEN	OPEN	CLOSED	
-	OPEN	OPEN	CLOSED	



Sequential lever switch statuses:

Note:

The vehicle does not have a 3rd gear hold (D3). Ignore **ET155 "Third gear hold contact"**.

Lever position	Sequential lever upshift contact	Sequential lever downshift contact	
P	OPEN	OPEN	
R	OPEN	OPEN	
N	OPEN	OPEN	
D	OPEN	OPEN	
М	CLOSED	CLOSED	
+	CLOSED	OPEN	
-	OPEN	CLOSED	

Shift solenoids (EVS) statuses:							
Lever position	Gear engaged	Solenoid valve statuses					
		1	2	3	4	5	6
Р	Neutral	INACTIVE	INACTIVE	ACTIVE	INACTIVE	INACTIVE	INACTIVE
R	R	INACTIVE	INACTIVE	INACTIVE	INACTIVE	INACTIVE	INACTIVE
N	Neutral	INACTIVE	INACTIVE	ACTIVE	INACTIVE	INACTIVE	INACTIVE
P or N < -10°C	Neutral	INACTIVE	ACTIVE	INACTIVE	INACTIVE	INACTIVE	INACTIVE
D or M When stopped or driving	1	INACTIVE	INACTIVE	ACTIVE	ACTIVE	ACTIVE	INACTIVE
D or M When stopped or driving	2	INACTIVE	ACTIVE	INACTIVE	ACTIVE	INACTIVE	INACTIVE
D or M When driving	3	INACTIVE	INACTIVE	INACTIVE	INACTIVE	INACTIVE	INACTIVE
D or M When driving	4	ACTIVE	ACTIVE	INACTIVE	INACTIVE	INACTIVE	INACTIVE



MODULAR CONNECTOR



A Multifunction switch

B Hydraulic electronic interface

C Oil pressure sensor

D Turbine speed sensor

E Exchanger flow lock-up solenoid valve



COMPUTER INPUTS AND OUTPUTS



AUTOMATIC TRANSMISSION Fault finding - Track assignments



Computer track	Assignment	Track of the sensor
1	Shift solenoid feed	Electric/hydraulic interface track B3
2	Exchanger flow sensor control solenoid valve feed	Exchanger flow sensor control solenoid valve track 2
3	Not used	
4	AT display signal (except Scenic II)	Automatic transmission display track 2
5	Not used	
6	Not used	
7	Shift solenoid 3 - control	Electric/hydraulic interface track B10
8	Shift solenoid 4 - control	Electric/hydraulic interface track B7
9	Shift solenoid 2 - control	Electric/hydraulic interface track B8
10	Shift solenoid 1 - control	Electric/hydraulic interface track B11
11	Selector lever lock - control	Eco/perf switch track B2
12	Exchanger flow sensor solenoid valve - control	Exchanger flow sensor control solenoid valve track 1
13	Modulating solenoid valve 3	Electric/hydraulic interface track B5
14	Modulating solenoid valve 4	Electric/hydraulic interface track B2
15	Not used	
16	Brake light switch + signal	Brake light switch track 3
17	Not used	
18	Diagnostic signal K	Track 7 diagnostic socket
19	Lock-up modulating solenoid valve	Electric/hydraulic interface track B6
20	Shift solenoid 5 - control	Electric/hydraulic interface track B9
21	Not used	
22	Not used	
23	Not used	
24	Line pressure sensor feed	Pressure sensor track C1
25	Line pressure sensor - signal	Pressure sensor track C3
26	Modulating solenoid valve feed	Electric/hydraulic interface track B12
27	After ignition feed	Protection and Switching Unit grey connector track 10
28	Earth	
29	Not used	
30	Not used	

AUTOMATIC TRANSMISSION Fault finding - Track assignments



Computer track	Assignment	Sensor track	
31	Multifunction switch signal 2	Multifunction switch track A10	
32	Multifunction switch signal 3	Multifunction switch track A11	
33	Multifunction switch signal 4	Multifunction switch track A12	
34	Not used		
35	Not used		
36	Sequential switch control, downshift contact	Eco/perf control track B3	
37	Sequential lever N +1 control	Eco/perf control track A3	
38	Engine CAN H signal	Injection computer track K4	
39	Engine CAN L signal	Injection computer track K3	
40	Not used		
41	Not used		
42	Multifunction switch - signal	Multifunction switch track A7	
43	Not used		
44	Not used		
45	Gearbox input speed sensor + signal	Turbine speed sensor track D1	
46	Gearbox input speed sensor - signal	Turbine speed sensor track D2	
47	Not used		
48	Not used		
49	Not used		
50	Not used		
51	Not used		
52	Not used		
53	Pressure solenoid valve 1 - signal	Electric/hydraulic interface track B4	
54	Shift solenoid 6 - control	Electric/hydraulic interface track B1	
55	Line pressure sensor + signal	Pressure sensor track C2	
56	+ battery	Protection and Switching Unit grey connector track 1	



REPLACING THE COMPUTER

IT IS ESSENTIAL TO CONTACT YOUR TECHLINE BEFORE REPLACING AN AUTOMATIC TRANSMISSION COMPUTER.

If Techline approves the computer replacement, proceed as follows:

- In the "Identification" menu, find the gearbox oil wear meter code.
- Switch off the ignition.
- Replace the computer.
- If necessary, change the computer configuration in the "Enter configuration" menu.
- Enter the VIN into the computer with diagnostic tool command VP001 "VIN Entry".
- Enter the oil wear meter code from the old AT computer (found in the "Identification" menu) by running command VP015 "Transfer oil wear meter".
- Enter the gearbox oil change date with command VP016 "Enter gearbox oil change date".
- Switch off the ignition.
- Carry out a check using the diagnostic tool.
- Enter the After-Sales operation date with diagnostic tool command VP008 "Enter last After-Sales operation date".

REPLACING AN AUTOMATIC TRANSMISSION COMPONENT

For replacing other automatic transmission components, see Workshop Repair Manual 364 Section 2.



PROGRAMMING

• VP001 "VIN ENTRY":

As it is necessary to enter the VIN each time dialogue is established with the diagnostic tool, it must be programmed into each vehicle computer whenever a computer is replaced.

Programming procedure:

- Connect the diagnostic tool
- Refer to automatic transmission fault finding
- Select parameter setting VP001 "VIN Entry"
- Enter the vehicle's VIN
- Clear the computer memory
- Exit diagnostic mode
- Switch off the ignition
- Wait for the end of the "power latch"
- Double-check the setting

• VP009 "ENTER LAST AFTER-SALES OPERATION DATE":

The date of every operation carried out on the automatic transmission in the workshop must be entered.

Select command **VP009 "Enter last After-Sales operation date"** on the fault finding tool, then enter the service date with the keyboard.

• VP015 "TRANSFER OIL WEAR METER":

Transfer the oil wear meter code from the old computer.

Do this by selecting command **VP015 "Transfer oil wear meter"** on the fault finding tool, then use the keyboard to enter the code found on the replaced computer.

• VP016 "ENTER GEARBOX OIL CHANGE DATE":

Do this by selecting command **VP016 "Enter gearbox oil change date"** on the fault finding tool, then use the keyboard to enter the date found on the replaced computer.

23A

Fault descriptions			
DF002	Computer	DF088	Shift solenoid "EVS5" circuit
DF003	Analogue sensor feed	DF089	Shift solenoid "EVS4" circuit
DF005	Oil pressure sensor circuit	DF093	Sequential gear lever circuit
DF008	Multifunction switch intermediate	DF095	Shift lock electromagnet circuit
DEago		DF109	Engine torque multiplex signal
DF009	Multifunction switch prohibited position	DF112	Shift solenoid "EVS6" circuit
DF010	Instrument panel connection	DF114	Multiplex pedal position
DF012	Solenoid valve feed	DF116	Engine multiplex speed signal
DF016	Lock-up solenoid valve circuit	DF117	LH rear wheel multiplex speed signal
DF017	Exchanger flow rate solenoid valve circuit	DF118	RH rear wheel multiplex speed signal
DF018	Lock-up slip	DF119	Brake pedal position
DF020	Old oil	DF122	Passenger compartment computer connection
DF023	Engine oil temperature sensor circuit	DF123	ABS computer connection
DF024	Coolant temperature circuit	DF126	Turbine speed signal
DF029	Multifunction switch in unstable position	DF129	Electronic stability program (ESP)
DF036	Pressure regulating solenoid valve circuit	DF131	Slip
DF038	Turbine speed sensor circuit	DF174	ABS fault detection
DF048	Vehicle speed signal	DF175	Left-hand front wheel multiplex speed signal
DF049	Pressure regulation	DF176	Right-hand front wheel multiplex speed
DF055	Injection connection ——— instrument panel	DE177	signal
DF064	Display circuit		Automatic transmission overheating
DF085	Shift solenoid "EVS1" circuit		
DF086	Shift solenoid "EVS2" circuit		
DF087	Shift solenoid "EVS3" circuit		Ÿ



DF002 PRESENT OR STORED	COMPUTER			
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears after the ignition has been switched on.			
Check that the computer	earth is connected correctly to the vehicle's left-hand front side member.			
The battery voltage shou	Id be between 11.8 V and 13.2 V.			
Check the cleanness and condition of the connections. On track 1 of the Protection and Switching Unit's grey 12-track PPM2 connector, check the computer's permanent feed 20-A fuse F15.				
Check the cleanness an On track 10 of the Prote ignition feed 5-A fuse F5	d condition of the connections. Inction and Switching Unit's grey 12-track PPM2 connector, check the computer's after- H.			
Disconnect the battery. Disconnect the compute Disconnect connector Pl Take the universal bornie following connections: Computer the Computer the Computer the	r. Check the cleanness and condition of the connections. PM2 in the Protection and Switching Unit. er Elé. 1681. Check the insulation, continuity and absence of stray resistance on the rack 56 PSU connector PPM2 track 1 rack 27 PSU connector PPM2 track 10 rack 28 Left-hand front side member electronic earth 2			
Reconnect the battery. With the ignition on, check for 12 V in computer tracks 27 and 56 . If 12 V is not found, there is a failure in the Protection and Switching Unit. Run fault finding on the Protection and Switching Unit.				
If the fault is still present	, contact your Techline.			

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF003 PRESENT OR STORED	FEED TO THE ANALOGUE SENSORS		
NOTES	If fault DF002 "Computer" is present or stored, deal with it first. Conditions for applying the fault finding procedure to stored faults: The fault appears after the ignition has been switched on.		
Disconnect the battery. Disconnect the "modular	connector", and check the cleanness and condition of the connections.		
Take the "universal bornier Elé. 1681". Check the insulation, continuity and absence of stray resistance on the following connections: (For "modular connector" connection details, see the "System operation and Track assignments" section.) Computer track 24 Computer track 25 Computer track 25 Computer track 53 Computer track 54 Track B4 Modular connector plug Track B1 Modular connector plug			
Reconnect the "modular connector". Check that the oil pressure sensor resistance between tracks 24 and 25 of the computer connector is approximately 20 k Ω . If the resistance is not correct, either the sensor or the harness is damaged.			
Check the oil-temperature sensor resistance between computer tracks 53 and 54 . The resistance should be between 2360 and 2660 Ω at a temperature of approx. 20 °C. If the resistance is not correct, either the sensor or the harness is damaged.			
If the fault is still present, contact your Techline.			
If the fault does not dis	appear, deal with the other faults then go to the conformity check.		

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DE005	OIL PRESSURE SENSOR CIRCUIT		
PRESENT			
STOKED			
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears following a timed period of 10 seconds with the engine running at more than 2000 rpm .		
Disconnect the battery. Disconnect the "modular	connector", and check the cleanness and condition of the connections.		
Disconnect the computer. Check the cleanness and condition of the connections. Take the "universal bornier Elé. 1681". Check the continuity and insulation of the following connections: (For "modular connector" connection details, see the "System operation and Track assignments" section.) Computer track 24 Computer track 55 Computer track 25 Computer track 25 Comput			
Reconnect the "modular connector". Check that the oil pressure sensor resistance between tracks 24 and 25 of the computer connector is approximately 20 $k\Omega$. If the value is not correct, replace the sensor.			
If the fault is still not cu	ured, deal with the other faults and then proceed with the conformity check.		

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--

SIEMENS TA2000 PROGRAM no.: 94 VDIAG no.: 10



DF008	MULTIFUNCTION SWITCH IN INTERMEDIATE POSITION				
DF009	MULTIFUNCTION SWITCH IN INHIBITOR POSITION				
OR					
STORED					
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears when the selector lever is shifted from " Park " to " Drive " (with a stop at each lever position).				
Check the cleanness, c Check the control setting	ondition and mounting of the n as (see Workshop Repair Manua	nultifunction switch.			
Disconnect the battery. Disconnect the "modular connector" and check the cleanness and condition of connector " A " connections. (For "modular connector" connection positions, see the "System operation and Track assignments" section.)					
Take the "universal bornier Elé. 1681". Check the continuity of the following connections on the modular connector's socket: Lever in position "P" Modular connector track A10 Modular connector track A10					
Modular connector track A10		Modular connector track A7			
Modular conne	ector track A11	Modular connector track A7			
Modular connector track A12 —		Modular connector track A7			
Modular conne	ector track A11 —	Modular connector track A7			
Lever in position "D"					
Modular connector track A12 — Modular connector track A7					
(continued on next page)				

AFTER REPAIR Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--



٦

DF008				
CONTINUED				
Check the insulation of	the following connec	tions on the m	odular connector's socket:	
Lever in position "P"		•	Madulan as we as fau fue als A7	
Modular conne	ector track A	9	Modular connector track A7	
Modular conne	ector track A		Modular connector track A/	
Wodular conne	ector track A		Modular connector track A/	
<u>Level in position R</u>	octor track A	0	Modular connector track A7	
Lever in position "N"				
Modular conne	ector track A	9	Modular connector track A7	
Modular conne	ector track A		Modular connector track A7	
Modular conne	ector track A		Modular connector track A7	
Lever in position "D"		··- •		
Modular conne	ector track A	9	Modular connector track A7	
Modular conne	ector track A		Modular connector track A7	
Modular conne	ector track A		Modular connector track A7	
If the insulation is faulty,	replace the multifund	ction switch.		
Disconnect the computer	r. Check the cleanne	ess and condi	tion of the connections.	
Check the insulation, co	ontinuity and absen	ce of stray re	sistance on the following connections:	
Computer tr	rack 31 🗛 1	rack A10 Mo	dular connector plug	
Computer tr	ack 32 — 7	rack A11 Mo	dular connector plug	
Computer tr	ack 33 🗕 🔶 1	rack A12 Mo	dular connector plug	
Computer tr	rack 42	Frack A7 Mod	ular connector plug	

If the fault is still not cured, deal with the other faults and then proceed with the conformity check.

F C AFTER REPAIR (((Follow the instructions to confirm repair. Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
---------------------------------------	--



DF010 PRESENT OR STORED	INSTRUMENT PANEL CONNECTION
NOTES	None.

Test the multiplex network.

Refer to the "Multiplex network" fault finding section in the Workshop Repair Manual.

If the fault is still present, test the **instrument panel**. Refer to the **"Instrument panel**" section in the Workshop Repair Manual.



AFTER REPAIRDeal with any other faults.
Clear the fault memory and switch off the ignition.
Carry out a road test.
Complete the operation by carrying out a check with the diagnostic tool.



SIEMENS TA2000 PROGRAM no.: 94 VDIAG no.: 10



DF012 PRESENT OR STORED	SOLENOID VALVES FEED CO : Open circuit CC.1 : Short circuit to + 12 V
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 (" Shift solenoid activation ").
Disconnect the battery. Disconnect the "modular	connector", and check the cleanness and condition of the connections.
Disconnect the compute Take the "universal born the following connections (For "modular connector Computer tr Computer tr	r. Check the cleanness and condition of the connections. ier Elé. 1681". Check the insulation, continuity and absence of stray resistance on s: " connection positions, see the "System operation and Track assignments" section.) rack 1 Track B3 Modular connector plug rack 1 Track B11 Modular connector plug
Reconnect the "modular Check across tracks 10 at 20 °C . If the resistance is not co	connector". and 1 of the computer connector that the resistance of shift solenoid no. 1 is $40 \Omega \pm 2 \Omega$ prrect, the solenoid value or the electric/hydraulic interface harness is damaged.
If the fault is still not cu	ured, deal with the other faults and then proceed with the conformity check.

AFTER REPAIR	Follow the instructions to confirm repair. Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF016 PRESENT OR STORED	CONVERTER LOCK-UP SOLENOID VALVE CIRCUIT CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V	
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 ("Actuator sequential control").	
Disconnect the battery. Disconnect the "modular	connector", and check the cleanness and condition of the connections.	
Disconnect the compute Take the "universal born (For "modular connector Computer tr Computer tr	r. Check the cleanness and condition of the connections. ier Elé. 1681". Check the continuity and insulation of the following connections: " connection positions, see the "System operation and Track assignments" section.) rack 19 Track B6 Modular connector plug rack 26 Track B12 Modular connector plug	
Reconnect the "modular Check across tracks 19 valve is $1 \Omega \pm 0.2 \Omega$ at 2 If the resistance is not co	connector". and 26 of the computer connector that the resistance of the converter lock-up solenoid 0 °C. orrect, the solenoid valve or the electric/hydraulic interface harness is damaged.	
If the fault is still not cured, deal with the other faults and then proceed with the conformity check.		

AFTER REPAIR	Follow the instructions to confirm repair. Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF017 PRESENT OR STORED	EXCHANGER FLOW RATE SOLENOID VALVE CIRCUIT CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 ("Actuator sequential control").
Disconnect the battery. Disconnect the "modular	connector", and check the cleanness and condition of the connections.
Disconnect the compute Take the "universal born the following connection (For "modular connector Computer tr Computer tr	 r. Check the cleanness and condition of the connections. ier Elé. 1681". Check the insulation, continuity and absence of stray resistance on s: " connection positions, see the "System operation and Track assignments" section.) rack 12 Track E1 Modular connector plug rack 2 Track E2 Modular connector plug
Reconnect the "modular Check across tracks 12 valve is 40 $\Omega \pm 4 \Omega$ at 20 If the resistance is not co	connector". and 2 of the computer connector that the resistance of the heat exchanger flow solenoid) °C. prrect, the solenoid valve or harness is damaged.
If the fault is still not c	ured, deal with the other faults and then proceed with the conformity check.

	Follow the instructions to confirm repair. Deal with any other faults.
AFTER REPAIR	clear the fault memory and switch off the ignition.
	Carry out a road test.
	Complete the operation by carrying out a check with the diagnostic tool.



DF018 PRESENT OR STORED	CONVERTER LOCK-UP SLIPPAGE
	Carry out injection system fault finding and check that it is operating correctly
NOTES	If the following faults are present or stored, deal with them first: DF003 - DF005 - DF016 - DF020 - DF023 - DF038 - DF049 - DF177 Conditions for applying the fault finding procedure to stored faults: The fault appears after driving with 3 rd gear hold at a steady speed for more than 3 minutes continuously.

To check that there are no faults with the converter lock-up solenoid valve, use the interpretation of fault **DF016 "Converter lock-up solenoid valve circuit"**.

To check that there are no faults with the turbine speed sensor, use the interpretation of fault **DF038** "Turbine speed sensor circuit".

Check the gearbox oil quality and level.

If an oil change or top-up is necessary see the "Draining-Filling-Levels" section of the Workshop Repair Manual. Check that the transmission is not leaking oil.

Carry out the converter stall test.

Follow the procedure in the "Converter stall test" section of the Workshop Repair Manual.

Carry out a "Conformity check" to detect any possible faults.

See the "Taking line pressure" section of the Workshop Repair Manual.

Connect the pressure gauge for a line pressure reading.

Hot engine and gearbox oil temperature between 60 and 80 °C.

Take the line pressure readings under the following conditions:

selector lever in position "P" or "N" and engine running at 2000 rpm, the pressure should be between 2.6 and 3.2 bar,

- selector lever in position "R" and engine running at 2000 rpm, the pressure should be more than 4 bar,

 selector lever in position "D" and engine running at 2000 rpm, the pressure in first gear should be more than 7 bar.

If the values are not correct, there is a fault inside the gearbox.

If the fault is still present, contact the Techline.

AFTER REPAIR Deal with any other faults. Clear the fault memory and switch off the ignition. See the "System operation and Track assignments" section for how to reset the oil ageing counter to zero (Entering oil change date). Switch off the ignition, switch the ignition back on and carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.	oil
--	-----



DF020 PRESENT OR STORED	<u>OLD OIL</u>
NOTES	None.
Change the automatic tr (Refer to the relevant se	ansmission oil. ction in the Workshop Repair Manual.)
Reset the computer's oil Do this by running comm	ageing counter to zero and enter the oil change date. nand VP016 "Enter gearbox oil change date" .
Reset the self-adapting s If necessary, take the ve Driving procedure: Go for a normal drive tha	systems to zero by running command RZ005 "Self-adapting systems" . hicle for a drive to program the new self-adapting systems. at involves shifting up and down into every gear several times.

	~	

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF023 PRESENT OR STORED	GEARBOX OIL TEMPERATURE SENSOR CIRCUIT	
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears after a road test.	
Disconnect the battery. Disconnect the "modular	connector", and check the cleanness and condition of the connections.	
Disconnect the compute Take the "universal born the following connection (For "modular connector Computer to Computer to	r. Check the cleanness and condition of the connections. ier Elé. 1681". Check the insulation, continuity and absence of stray resistance on s: " connection positions, see the "System operation and Track assignments" section.) rack 53 Track B4 Modular connector plug rack 54 Track B1 Modular connector plug	
Reconnect the "modular connector". Check the oil temperature sensor resistance between computer connector tracks 53 and 54 . The resistance should be between 2360 and 2660 Ω at a temperature of 20 °C and between 290 and 327 Ω at a temperature of 80 °C. If the resistance is not correct, the sensor or the electric/hydraulic interface harness is damaged. Replace the sensor.		
If the fault is still not c	ured, deal with the other faults and then proceed with the conformity check.	

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF024 PRESENT OR STORED	COOLANT TEMPERATURE SENSOR CIRCUIT
NOTES	None.

Test the multiplex network.

Refer to the "Multiplex network" fault finding section in the Workshop Repair Manual.

If the fault is still present, carry out fault finding on the **injection** system. See the "**Injection**" section of the Workshop Repair Manual.

AFTER REPAIRDeal with any other faults.
Clear the fault memory and switch off the ignition.
Carry out a road test.
Complete the operation by carrying out a check with the diagnostic tool.





DF029 PRESENT OR STORED	MULTIFUNCTION SWI	TCH IN UNSTABLE POSITION
	Conditions for applying the	fault finding procedure to stored faults:
NOTES	The fault appears when the se at each lever position).	ector lever is shifted from " Park " to " Drive " (with a stop
Check the cleanness, c Check the control setting	ondition and mounting of the gs (see Workshop Repair Manua	multifunction switch. al).
Disconnect the battery. Disconnect the "modular (For "modular connector	[•] connector" and check the clea " connection positions, see the '	nness and condition of connector " A " connections. 'System operation and Track assignments" section.)
Take the "universal born connector's socket: Lever in position "P"	ier Elé. 1681". Check the conti	nuity of the following connections on the modular
Modular conne Lever in position "R"	ector track A10	Modular connector track A7
Modular conne	ector track A10	Modular connector track A7
Modular conne	ector track A11	Modular connector track A7
Lever in position "N"		
Modular conne	ector track A11	Modular connector track A7
Modular conne	ector track A12	Modular connector track A7
(continued on next page)	

	Follow the instructions to confirm repair.
	Deal with any other faults.
AFTER REPAIR	Clear the fault memory and switch off the ignition.
	Carry out a road test.
	Complete the operation by carrying out a check with the diagnostic tool.



DF029 CONTINUED			
Check the insulation of	the following connections of	on the modular connector's socket:	
Lever in position "P"			
Modular conne	ector track A9 –	Modular connector track A7	
Modular conne	ector track A11 –	Modular connector track A7	
Madulan assure	t		

Modular connector	track A12	Modular connector track A7	
Lever in position "R"			
Modular connector	track A9	Modular connector track A7	
Lever in position "N"			
Modular connector	track A9	Modular connector track A7	
Modular connector	track A10 —	Modular connector track A7	
Modular connector	track A12	Modular connector track A7	
Lever in position "D"			
Modular connector	track A9	Modular connector track A7	
Modular connector	Modular connector track A10 — Modular connector track A7		
Modular connector	track A11	Modular connector track A7	
If the insulation is faulty, replace the	multifunction switch.		
Disconnect the computer. Check the	cleanness and condi	tion of the connections.	
Check the insulation, continuity ar	d absence of stray re	sistance on the following connections:	
Computer track 31 —	> Track A10 Mo	dular connector plug	
Computer track 32 —	> Track A11 Mo	dular connector plug	
Computer track 33 —	> Track A12 Mo	dular connector plug	
Computer track 42 —	Track A7 Mod	lular connector plug	

If the fault is still not cured, deal with the other faults and then proceed with the conformity check.

AFTER REPAIR	Follow the instructions to confirm repair. Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF036	PRESSURE REGULATING SOLENOID VALVE CIRCUIT
PRESENT OR	CC.1 : Short circuit to + 12 V
STORED	
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 ("Actuator sequential control").
Disconnect the battery. Disconnect the "modular	connector", and check the cleanness and condition of the connections.
Disconnect the compute Take the "universal born (For "modular connector Computer tr Computer tr	r. Check the cleanness and condition of the connections. ier Elé. 1681". Check the continuity and insulation of the following connections: " connection positions, see the "System operation and Track assignments" section.) rack 20 Track B9 Modular connector plug rack 26 Track B12 Modular connector plug
Check across tracks B9 solenoid valve is $1 \Omega \pm 0$ If the resistance is not co	and B12 of the "modular connector" socket that the resistance of the converter lock-up 0.2 Ω at approximately 23 °C. prrect, the solenoid valve or the electric/hydraulic interface harness is damaged.
If the fault is still not co	ured, deal with the other faults and then proceed with the conformity check.

AFTER REPAIR	If replacing the pressure regulating solenoid valve (EVM), the self-adapting systems must be deleted (command RZ005). Follow the instructions to confirm repair. Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF037 PRESENT OR STORED	KICKDOWN SWITCH CIRCUIT DEF : Unidentified electrical fault
NOTES	None.

Test the multiplex network.

Refer to the "Multiplex network" section in the Workshop Repair Manual.

If the fault is still present, test the **ABS and ESP** systems. Refer to the "**ABS system and Electronic Stability Program**" section in the Workshop Repair Manual.

2		
	C	

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--





DF038 PRESENT OR STORED	TURBINE SPEED SENSOR CIRCUIT 1.DEF : No signal 2.DEF: Signal interference			
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears when the engine is running and the selector lever is in " Park ".			
Disconnect the battery. Disconnect the "modular connector", and check the cleanness and condition of the connections.				
Disconnect the computer. Check the cleanness and condition of the connections. Take the "universal bornier Elé. 1681". Check the continuity and insulation of the following connections: (For "modular connector" connection positions, see the "System operation and Track assignments" section.) Computer track 45 - Track D1 Modular connector plug Computer track 46 - Track D2 Modular connector plug				
Reconnect the "modular connector". Check across tracks 45 and 46 of the computer connector that the turbine speed sensor resistance is 300 $\Omega \pm 40 \Omega$ at approximately 20 °C . If the resistance is not correct, either the sensor or the harness is damaged. Replace the turbine speed sensor.				
If the fault is still not c	ured, deal with the other faults and then proceed with the conformity check.			

AFTER REPAIR	Follow the instructions to confirm repair. Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--


DF048 VEHICLE SPEED SIGNAL PRESENT 1.DEF: Problem with the system generating the speed signal or signal interference OR 2.DEF: No signal
--

NOTES Deal with faults DF117, DF118, DF175 or DF176 first if present or stored.
--

Refer to the "Multiplex network" section in the Workshop Repair Manual.

4

If the fault is still present, carry out fault finding on the ABS and ESP system. Refer to the "ABS system and Electronic Stability Program" section in the Workshop Repair Manual.

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF049 PRESENT OR STORED	GEARBOX OIL PRESSURE REGULATION 1.DEF: Pressure regulation 2.DEF: Measured pressure lower than the required pressure

	Carry out an injection system check and check that it is operating correctly
NOTES	If the following faults are present or stored, deal with them first: DF003 - DF005 - DF020 - DF023 - DF036 - DF038
	Conditions for applying the fault finding procedure to stored faults: The fault appears after a road test.

To check that there are no faults with the oil pressure sensor, use the interpretation of fault **DF005** "**Oil pressure** sensor circuit".

To make sure there are no problems with the pressure lock-up solenoid valve, use the interpretation of fault **DF036 "Pressure regulating solenoid valve circuit"**.

Check the gearbox oil quality and level.

If a operation is required, see the **"Draining-Filling-Levels"** section of the Workshop Repair Manual. Check that the gearbox is not leaking oil.

Carry out a conformity check to detect any possible faults.

See the "Line pressure measurement" section of the Workshop Repair Manual.

Connect the pressure gauge for a line pressure reading.

Hot engine with gearbox oil temperature between 60 °C and 80 °C.

Take the line pressure readings in the following conditions:

- with the selector lever in position "P" or "N" and the engine running at 2000 rpm, the pressure should be between 2.6 and 3.2 bar,
- with the selector lever in position "R" and the engine running at 2000 rpm, the pressure should be more than 4 bar,
- with the selector lever in position "D" and the engine running at 2000 rpm, the pressure in first gear should be more than 7 bar.

If the fault is still present, there is a mechanical or hydraulic failure in the gearbox.

Check the conformity of all "Statuses" and "Parameters" to find the cause of the fault.

If the fault is still present, contact the Techline.

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF055 PRESENT OR STORED	INJECTION SYSTEM/AUTOMATIC TRANSMISSION CONNECTION 1.DEF : No signal 2.DEF : Signal interference
NOTES	None.

Refer to the "Multiplex network" fault finding section in the Workshop Repair Manual.

If the fault is still present, carry out fault finding on the **injection** system. See the "**Injection**" section of the Workshop Repair Manual.

4

AFTER REPAIRDeal with any other faults.
Clear the fault memory and switch off the ignition.
Carry out a road test.
Complete the operation by carrying out a check with the diagnostic tool.





DF064 PRESENT OR STORED	DISPLAY CIRCUIT CO.0 : Open circuit or short circuit to earth	
NOTES	Switch on the ignition.	
Check the cleanness and condition of the selector lever display connections.		
Disconnect the battery. Disconnect the computer. Check the cleanness and condition of the connections. Take the "universal bornier Elé. 1681". Check the insulation, continuity and absence of stray resistance on the following connections: Computer track 4> Selector lever display track 2		
If the fault is still not c	ured, deal with the other faults and then proceed with the conformity check.	

Ē



AFTER REPAIRFollow the instruction Deal with any other Clear the fault mem Carry out a road test Complete the operation	ons to confirm repair. faults. hory and switch off the ignition. st. ation by carrying out a check with the diagnostic tool.
---	--



DF085 PRESENT OR STORED	"EVS1" SHIFT SOLENOID CIRCUITS CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V CC : Short circuit	
NOTES	First deal with fault DF012" Solenoid valves feed" if present or stored. Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 (" Actuator sequential control ").	
Disconnect the battery. Disconnect the "modular	connector", and check the cleanness and condition of the connections.	
Disconnect the computer. Check the cleanness and condition of the connections. Take the "universal bornier Elé. 1681". Check the continuity and insulation of the following connections: (For "modular connector" connection positions, see the "System operation and Track assignments" section.) Computer track 10 Track B11 Modular connector plug Computer track 1 Track B3 Modular connector plug		
Reconnect the "modular Check across tracks 10 at approximately 20 °C. If the resistance is not co	connector". and 1 of the computer connector that the resistance of shift solenoid no. 1 is $40 \Omega \pm 2 \Omega$ prrect, the solenoid value or the electric/hydraulic interface harness is damaged.	
If the fault is still not co	ured, deal with the other faults and then proceed with the conformity check.	

AFTER REPAIR	Follow the instructions to confirm repair. Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF086 PRESENT OR STORED	"EVS2" SHIFT SOLENOID CIRCUITS CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V CC : Short circuit	
NOTES	First deal with fault DF012 "Solenoid valves feed" if present or stored. Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 (" Actuator sequential control ").	
Disconnect the battery.	connector", and check the cleanness and condition of the connections.	
Disconnect the computer. Check the cleanness and condition of the connections. Take the "universal bornier Elé. 1681". Check the continuity and insulation of the following connections: (For "modular connector" connection positions, see the "System operation and Track assignments" section.) Computer track 9		
Reconnect the "modular connector". Check across tracks 9 and 1 of the computer connector that the resistance of shift solenoid no. 2 is 40 $\Omega \pm 2 \Omega$ at approximately 20 °C . If the resistance is not correct, the solenoid value or the electric/hydraulic interface harness is damaged.		
If the fault is still not c	ured, deal with the other faults and then proceed with the conformity check.	

AFTER REPAIR	Follow the instructions to confirm repair. Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF087 PRESENT OR STORED	"EVS3" SHIFT SOLENOID CIRCUITS CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V CC : Short circuit
	First deal with fault DF012 "Solenoid valves feed" if present or stored.
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 ("Actuator sequential control").
Disconnect the battery. Disconnect the "modular	connector", and check the cleanness and condition of the connections.
Disconnect the compute Take the "universal born (For "modular connector Computer tr Computer tr	 r. Check the cleanness and condition of the connections. ier Elé. 1681". Check the continuity and insulation of the following connections: " connection positions, see the "System operation and Track assignments" section.) rack 1
Reconnect the "modular Check across tracks 1 a approximately 20 °C. If the resistance is not co	connector". nd 7 of the computer connector that the resistance of shift solenoid no. 3 is 40 $\Omega \pm 2 \Omega$ at orrect, the solenoid value or the electric/hydraulic interface harness is damaged.
If the fault is still not co	ured, deal with the other faults and then proceed with the conformity check.

AFTER REPAIR	Follow the instructions to confirm repair. Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF088 PRESENT OR STORED	"EVS5" SHIFT SOLENOID CIRCUITS CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V CC : Short circuit
	First deal with fault DF012 "Solenoid valves feed" if present or stored.
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 ("Actuator sequential control").
Disconnect the battery. Disconnect the "modular	connector", and check the cleanness and condition of the connections.
Disconnect the compute Take the "universal born (For "modular connector Computer tr Computer tr	 r. Check the cleanness and condition of the connections. ier Elé. 1681". Check the continuity and insulation of the following connections: " connection details, see the "System operation and Track assignments" section.) rack 1 Track B3 Modular connector plug rack 13 Track B5 Modular connector plug
Reconnect the modular of Check across tracks 1 a at approximately 20 °C . If the resistance is not co	connector. and 13 of the computer connector that the resistance of shift solenoid no. 5 is 40 $\Omega \pm 2 \Omega$ prrect, the solenoid value or the electric/hydraulic interface harness is damaged.
If the fault is still not c	ured, deal with the other faults and then proceed with the conformity check.

AFTER REPAIR	Follow the instructions to confirm repair. Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF089 PRESENT OR STORED	"EVS4" SHIFT SOLENOID CIRCUITS CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V CC : Short circuit
NOTES	First deal with fault DF012 "Solenoid valves feed" if present or stored. Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 (" Actuator sequential control ").
Disconnect the battery. Disconnect the "modular	connector", and check the cleanness and condition of the connections.
Disconnect the compute Take the "universal born (For "modular connector Computer tr Computer tr	r. Check the cleanness and condition of the connections. ier Elé. 1681 ". Check the continuity and insulation of the following connections: " connection positions, see the "System operation and Track assignments" section.) rack 1
Reconnect the "modular Check across tracks 8 a approximately 20 °C . If the resistance is not co	connector". nd 1 of the computer connector that the resistance of shift solenoid no. 4 is 40 $\Omega \pm 2 \Omega$ at prrect, the solenoid valve or the electric/hydraulic interface harness is damaged.
If the fault is still not c	ured, deal with the other faults and then proceed with the conformity check.

AFTER REPAIR	Follow the instructions to confirm repair. Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF093 PRESENT OR STORED	SEQUENTIAL GEAR LEVER CIRCUITS
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears during a road test when changing up or down with the selector lever in position " M " (sequential control).
Check the cleanness ar	nd condition of the sequential switch module connections.
Disconnect the battery. Disconnect the compute Take the "universal born the following connections Computer tr Computer tr Battery earth	r. Check the cleanness and condition of the connections. ier Elé. 1681". Check the insulation, continuity and absence of stray resistance on s: rack 36 Sequential switch module track B3 Sequential switch module track A3 Sequential switch module track A2
If the fault is still present	, replace the sequential switch module.
If the fault is still not cu	ured, deal with the other faults and then proceed with the conformity check.

AFTER REPAIR	Follow the instructions to confirm repair. Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF095 PRESENT OR STORED	SHIFT LOCK ELECTROMAGNET CIRCUITS CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 ("Actuator sequential control").
Check the cleanness a	nd condition of shift lock electromagnet connections.
With the ignition on, che If there is no + 12 V: - Check fuse 5F in the I - Disconnect the battery - Disconnect connector - Check the cleanness Take the "universal born Protection and connector PPI If there is still no + 12 V check the Protection and	ck for + 12 V on track B1 of the shift lock electromagnet connector. Protection and Switching Unit, as well as the cleanness and condition of the connections. PPH2 in the Protection and Switching Unit. and condition of the connections. ier Elé. 1681". Check the earth insulation and continuity of the following connection: d Switching Unit H2 track 11
Disconnect the battery. Disconnect the compute Take the "universal born Computer trac	r. Check the cleanliness and condition of the connections. ier Elé. 1681". Check the continuity and insulation of the following connection: k 11→ Shift lock electromagnet track B2
Check the shift lock elect Protection and Switching The resistance should b If the resistance is not co	tromagnet resistance between track 11 of the computer connector and track 11 of g Unit connector PPH2 . e 40 $\Omega \pm 4\Omega$ at a temperature of approximately 20 °C. prrect, replace the shift lock electromagnet.
If the fault is still not c	ured, deal with the other faults and then proceed with the conformity check.

AFTER REPAIR	Follow the instructions to confirm repair. Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



	ENGINE TORQUE MULTIPLEX SIGNAL
DF109 PRESENT OR STORED	 1.DEF: Consistency 2.DEF: Real torque 3.DEF: Anticipated torque 4.DEF: Torque without reduction 5.DEF: Requested torque cannot be attained 6.DEF: Minimum torque not transmitted by engine management computer 7.DEF: Maximum torque not transmitted by engine management computer 8.DEF: Torque request fulfilled

NOTES

None.

Test the multiplex network.

Refer to the "Multiplex network" fault finding section in the Workshop Repair Manual.

If the fault is still present, carry out fault finding on the injection system. See the "**Injection**" section of the Workshop Repair Manual.

If the fault is still not cured, deal with the other faults and then proceed with the conformity check.

AFTER REPAIRDeal with any other faults.
Clear the fault memory and switch off the ignition.
Carry out a road test.
Complete the operation by carrying out a check with the diagnostic tool.



DF112 PRESENT OR STORED	EVS6 SHIFT SOLENOID CIRCUITS CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V CC : Short circuit	
	First deal with fault DF012 "Solenoid valves feed" if present or stored.	
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 ("Actuator sequential control").	
Disconnect the battery. Disconnect the "modular	connector", and check the cleanness and condition of the connections.	
Disconnect the computer. Check the cleanness and condition of the connections. Take the "universal bornier Elé. 1681". Check the continuity and insulation of the following connections: (For "modular connector" connection positions, see the "System operation and Track assignments" section.) Computer track 1		
Reconnect the "modular connector". Check across tracks 14 and 1 of the computer connector that the resistance of shift solenoid no. 6 is 40 $\Omega \pm 2 \Omega$ at approximately 20 °C. If the resistance is not correct, the solenoid value or the electric/hydraulic interface harpess is damaged		
If the fault is still not cu	ured, deal with the other faults and then proceed with the conformity check.	

AFTER REPAIR	Follow the instructions to confirm repair. Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF114 PRESENT OR STORED	MULTIPLEX PEDAL POSITION
NOTES	None.

Refer to the "Multiplex network" fault finding section in the Workshop Repair Manual.

If the fault is still present, carry out fault finding on the **injection** system. See the "**Injection**" section of the Workshop Repair Manual.

~

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF116 PRESENT OR STORED	MULTIPLEX ENGINE SPEED SIGNAL
NOTES	None.

Refer to the "Multiplex network" fault finding section in the Workshop Repair Manual.

If the fault is still present, carry out fault finding on the **injection** system. See the "**Injection**" section of the Workshop Repair Manual.

4

AFTER REPAIRDeal with any other faults.
Clear the fault memory and switch off the ignition.
Carry out a road test.
Complete the operation by carrying out a check with the diagnostic tool.



DF117 PRESENT OR STORED	LEFT-HAND REAR WHEEL MULTIPLEX SIGNAL
NOTES	None.

Refer to the "Multiplex network" section in the Workshop Repair Manual.

If the fault is still present, carry out fault finding on the **ABS and ESP** system. Refer to the "**ABS system and Electronic Stability Program**" section in the Workshop Repair Manual.

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.



DF118 PRESENT OR STORED	RIGHT-HAND REAR WHEEL MULTIPLEX SIGNAL
NOTES	None.

Refer to the "Multiplex network" section in the Workshop Repair Manual.

If the fault is still present, carry out fault finding on the **ABS and ESP** system. Refer to the "**ABS system and Electronic Stability Program**" section in the Workshop Repair Manual.

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.



DF119 PRESENT OR STORED	MULTIPLEX BRAKE PEDAL POSITION
NOTES	Nono

Refer to the "Multiplex network" section in the Workshop Repair Manual.

If the fault is still present, carry out fault finding on the **ABS and ESP** system. Refer to the "**ABS system and Electronic Stability Program**" section in the Workshop Repair Manual.

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF122 PRESENT OR STORED	UCH CONNECTION
NOTES	None.

Refer to the "Multiplex network" fault finding section in the Workshop Repair Manual.

If the fault is still present, test the **UCH**. Refer to the "**UCH**" section in the Workshop Repair Manual.

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF123 PRESENT OR STORED	ABS COMPUTER CONNECTION
10750	

Test the multiplex network (see 88B, Multiplex network).

If the fault is not cured, test the Anti-lock braking and Electronic stability program systems (see 38C, Anti-lock braking system / Electronic stability program).

AFTER REPAIR	Deal with any other faults. Clear the stored faults and switch off the ignition. Carry out a road test. Complete the operation by testing with the diagnostic tool.
--------------	--



DF126 PRESENT OR STORED	TURBINE SPEED SIGNAL		
NOTES	None.		
Disconnect the battery. Disconnect the "modular	connector", and check the cleanness and condition of the connections.		
Disconnect the compute Use the "universal bornin (For "modular connector Computer tr Computer tr	Disconnect the computer. Check the cleanness and condition of the connections. Use the "universal bornier Elé. 1681" to check the insulation and continuity on the following connections: (For "modular connector" connection positions, refer to the "System operation and track assignment" section.) Computer track 45		
Reconnect the "modular connector". Check across tracks 45 and 46 of the computer connector that the turbine speed sensor resistance is 300 $\Omega \pm 40 \Omega$. If the resistance is not correct, either the sensor or the harness is damaged.			
If the fault is still not c	ured, deal with the other faults and then proceed with the conformity check.		

AFTER REPAIR	Deal with any other faults. Clear the stored faults and switch off the ignition. Carry out a road test. Complete the operation by testing with the diagnostic tool.
--------------	--



DF129 PRESENT OR STORED	ELECTRONIC STABILITY PROGRAM
NOTES	None.

Test the multiplex network (see 88B, Multiplex network).

4

If the fault is not cured, test the Anti-lock braking and Electronic stability program systems (see 38C, Anti-lock braking system / Electronic stability program).

AFTER REPAIR	Deal with any other faults. Clear the stored faults and switch off the ignition. Carry out a road test. Complete the operation by testing with the diagnostic tool.
--------------	--



SLIP
Carry out injection system fault finding and check that it is operating correctly
Deal with all other faults first.
Conditions for applying the fault finding procedure to stored faults: The fault appears after a road test.

To check that there are no faults with the turbine speed sensor, use the interpretation of fault **DF038 "Turbine speed sensor circuit"**.

To check that there are no faults with the vehicle speed signal, use the interpretation of fault **DF048** "Vehicle speed signal".

Carry out a "Conformity check" to detect any possible faults.

If the fault is still present, a brake or clutch in the gearbox is certainly defective. Contact your Techline.

AFTER REPAIRFollow the instructions to confirm repair.
Carry out a road test.
Complete the operation by carrying out a check with the diagnostic tool.



DF174 PRESENT OR STORED	ABS FAULT DETECTION
NOTEO	Nega

Refer to the "Multiplex network" section in the Workshop Repair Manual.

If the fault is still present, carry out fault finding on the **ABS and ESP** system. Refer to the "**ABS system and Electronic Stability Program**" section in the Workshop Repair Manual.

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.



DF175 PRESENT OR STORED	LEFT-HAND FRONT WHEEL SPEED MULTIPLEX SIGNAL
NOTES	None.

Refer to the "Multiplex network" section in the Workshop Repair Manual.

If the fault is still present, carry out fault finding on the **ABS and ESP** system. Refer to the "**ABS system and Electronic Stability Program**" section in the Workshop Repair Manual.

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF176 PRESENT OR STORED	RIGHT-HAND FRONT WHEEL SPEED MULTIPLEX SIGNAL
NOTES	None.

Refer to the "Multiplex network" section in the Workshop Repair Manual.

If the fault is still present, carry out fault finding on the **ABS and ESP** system. Refer to the "**ABS system and Electronic Stability Program**" section in the Workshop Repair Manual.

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--



DF177 PRESENT OR STORED	AUTOMATIC TRANSMISSION OVERHEATING
	Carry out injection system fault finding and check that it is operating correctly
NOTES	If the following faults are present or stored, deal with them first:

DF003 - DF005 - DF016 - DF017 - DF018 - DF020 - DF023 - DF024 - DF036 - DF049 -DF131 Conditions for applying the fault finding procedure to stored faults: The fault appears after a road test.

To check that there are no faults with the gearbox oil temperature sensor, use the interpretation of fault **DF023 "Gearbox oil temperature sensor"**.

To check that there are no faults with the exchanger flow solenoid valve, use the interpretation of fault **DF017 "Exchanger flow solenoid valve circuit"**.

Check the gearbox oil quality and level.

If an oil change or top-up is necessary see the "**Draining-Filling-Levels**" section of the Workshop Repair Manual. Check that the gearbox is not leaking oil.

Check that the oil cooler is not blocked.

If the fault is still present, there is a definitely a mechanical or hydraulic fault. Deal with the other faults then proceed with the conformity check.

If the fault persists, contact your Techline.

AFTER REPAIR	Deal with any other faults. Clear the fault memory and switch off the ignition. Carry out a road test. Complete the operation by carrying out a check with the diagnostic tool.
--------------	--

DP094101.0

たい



NOTES	Only carry out this conformity check after a complete check with the fault finding tool (no faults present or stored). Test conditions: engine stopped, ignition on.			
Nored	The values indicated in this conformity check are given as examples only. If necessary, refer to the exact operating specifications in the Workshop Repair Manual.			

Order	Function	Parameter or Status checked or Action		Display and Notes	Fault finding
1	Engine speed	PR006:	Engine speed	0 rpm	If there is a problem, refer to the fault finding procedure for this parameter.
				"P" if selector in position "P" "N" if selector in	
				position "N"	
			Gear selector position	"R" if selector in position "R"	
2	Gear selector position	ET012:		"D" if selector in position "D"	If there is a fault, refer to the interpretation of this status
				"M" if selector in position "M"	
				"M+" if selector in position "M+"	
				"M-" if selector in position "M-"	
				"N" for position "N"	5
	Gear	Gear ET013: Gear engag		"1" for 1 st unlocked	If there is a fault, refer to
3			Gear engaged	"2" for 2 nd unlocked	the interpretation of this status.
				R for reverse gear position	
4	Feed	PR008:	Computer feed voltage	10.5 < X < 16	If there is a fault, refer to the interpretation of this parameter.
5	Vehicle speed	PR105:	Vehicle speed	0 mph	If there is a fault, refer to the interpretation of this parameter.

MAIN SCREEN



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no faults present or stored). Test conditions: engine stopped, ignition on.			
	The values shown in this conformity check are given as examples only. If necessary, refer to the exact function specifications in the Workshop Repair Manual.			

Order	Function	Parameter or Status checked or Action		Display and Notes	Fault finding
6	Brake pedal	ET142:	Brake pedal pressed	YES , if the brake pedal is pressed	If there is a fault, refer to the
6				NO, if the brake pedal is not pressed	interpretation of this status.
		ET003:	STOP light contact (closure)	ACTIVE, if the brake pedal is not pressed	If there is a fault, refer to the
			C	INACTIVE , if the brake pedal is pressed	interpretation of this status.
7	Brake switch		STOP light contact	INACTIVE if the	
			(opening)	brake pedal is not pressed	If there is a fault, refer to the
				ACTIVE, if the brake pedal is pressed	status.
8	Selection mode	ET097:	Manual mode	INACTIVE	ACTIVE, if lever is in position " M "
		ET127:	Sequential lever	OPEN, CLOSED, if	
	Sequential lever switch		downshift contact	selector lever in	If there is a fault,
		ET128:	Sequential lever	position " M- "	refer to the
			upshift contact	OPEN, CLOSED, if	interpretation of this
9				selector lever in position " M+ "	status.
		ET155:	Third gear hold contact		If there is a fault,
					refer to the
					status.
10	Driving mode	ET079:	Economy mode	YES, if driving is economical	WITHOUT
				NO, if driving is sporty	

MAIN SCREEN (continued)



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no faults present or stored). Test conditions: engine stopped, ignition on.		
	The values shown in this conformity check are given as examples only. If necessary, refer to the exact function specifications in the Workshop Repair Manual.		

MAIN SCREEN (continued)

Order	Function	Parameter or Status checked or Action		Display and Notes	Fault finding
11	Gearbox oil temperature	PR004:	Gearbox oil temperature	- 40 < X < 140 °C	If there is a fault, refer to the interpretation of this parameter.
12	Exchanger flow control solenoid valve (EPDE)	ET0207:	Exchanger flow control solenoid valve control	INACTIVE	If ACTIVE , refer to the interpretation of this status.
13	Old oil	ET079:	Old oil	YES NO	No fault finding procedure for this status.



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no faults present or stored). Test conditions: engine stopped, ignition on.			
NOTES	The values shown in this conformity check are given as examples only. If necessary, refer to the exact operating specifications in the Workshop Repair Manual.			

Order	Function	Parameter or Status checked or Action	Display and Notes	Fault finding
		44	"P" if selector in position "P"	
			"N" if selector in position "N"	
			"R" if selector in position "R"	
1	Gear selector position	ET012: Gear selector position	"D" if selector in position "D"	If there is a fault, refer to the interpretation of this status.
			"M" if selector in position "M"	
			"M+" if selector in position "M+"	
			"M-" if selector in position "M-"	
		ET013: Gear engaged	"N" for neutral position	
2	Gear		"1" for 1 st unlocked	If there is a fault, refer to the interpretation of this
			"2" for 2 nd unlocked	status.
			"R" for reverse	
3	Vehicle speed	PR105: Vehicle speed	0 mph	If there is a fault, refer to the interpretation of this parameter.
4	Engine speed	PR006: Engine speed	0 rpm	If there is a fault, refer to the interpretation of this parameter.
5	Oil pressure	PR003: Oil pressure	X < 0.2 bar	If there is a fault, refer to the interpretation of this parameter.

GEAR CHANGE SUB-FUNCTION



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no faults present or stored). Test conditions: engine stopped, ignition on.			
Nores	The values shown in this conformity check are given as examples only. If necessary, refer to the exact operating specifications in the Workshop Repair Manual.			

GEAR CHANGE SUB-FUNCTION (continued)

Order	Function	F	Parameter or Status checked or Action	Display and Notes	Fault finding
		ET021:	Shift solenoid 1	INACTIVE	
	4	ET022:	Shift solenoid 2	INACTIVE	
		ET023:	Shift solenoid 3	ACTIVE	If there is a fault, refer
	Solenoid valve control	ET024:	Shift solenoid 4	INACTIVE	of these statuses.
7		ET025:	Shift solenoid 5	INACTIVE	
		ET026:	Shift solenoid 6	INACTIVE	
		AC024:	Actuator sequential control	Command for controlling all the solenoid valves	If there is a fault, refer to the interpretation of this command.
				Lever in position "P"	
8	Multifunction switch	ET123:	Multifunction switch S2	CLOSED	If there is a fault, refer to the interpretation
		ET124:	Multifunction switch S3	OPEN	of these statuses.
		ET125:	Multifunction switch S4	OPEN	
9	Feeds	ET001:	Solenoid valves feed	PRESENT	If there is a fault, refer to the interpretation of these statuses.



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no faults present or stored). Test conditions: engine stopped, ignition on.
NOTES	The values shown in this conformity check are given as examples only. If necessary, refer to the exact operating specifications in the Workshop Repair Manual.

GEAR CHANGE SUB-FUNCTION (continued)

Order	Function	Parameter or Status checked or Action	Display and Notes	Fault finding
10	Selection mode	ET097: Manual mode	INACTIVE ACTIVE, if lever is in position " M "	If there is a fault, refer to the interpretation of these statuses.
11	Sequential lever switch	ET127: Sequential lever downshift contact ET128: Sequential lever upshift contact	OPEN CLOSED, if selector lever in position "M-" INACTIVE CLOSED, if selector lever in position "M+"	If there is a fault, refer to the interpretation of these statuses.
		ET155: Third gear hold contact	OPEN	





NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no faults present or stored). Test conditions: engine stopped, ignition on.			
Nores	The values shown in this conformity check are given as examples only. If necessary, refer to the exact operating specifications in the Workshop Repair Manual.			

PRESSURE REGULATION SUB-FUNCTION

Order	Function	Parameter or Status checked or Action		Display and Notes	Fault finding
1	Gear	ET013:	Gear engaged	"N" for neutral position "1" for 1 st unlocked "2" for 2 nd unlocked "R" for reverse position	If there is a fault, refer to the interpretation of this status.
2	Engine speed	PR006:	Engine speed	0 rpm	If there is a fault, refer to the interpretation of fault DF115.
		PR003:	Oil pressure	X < 0.2 bar	If there is a fault, refer to the interpretation of this parameter.
3	Oil pressure	PR138:	Required pressure	21 bar	None.
		PR146:	Difference between specification and oil pressure	X = PR138 - PR003	None.
4	Oil temperature	PR004:	Gearbox oil temperature	- 40 < X < 140 °C	If there is a fault, refer to the interpretation of this parameter.



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no faults present or stored). Test conditions: engine stopped, ignition on.			
Nores	The values shown in this conformity check are given as examples only. If necessary, refer to the exact operating specifications in the Workshop Repair Manual.			

Order	Function	Parar chee	neter or Status cked or Action	Display and Notes	Fault finding	
		1		"P" if selector in position "P"		
		4		"N" if selector in position "N"		
			•	"R" if selector in position "R"		
1	Gear selector	ET012:	Gear selector position	"D" if selector in position "D"	If there is a fault, refer to the interpretation of this status.	
				"M" if selector in position "M"		
				"M+" if selector in position "M+"		
				"M-" if selector in position "M-"		
	Brake pedal	ET142:	Brake pedal pressed	YES, if brake pedal is pressed	If there is a fault, refer to	
				NO, if brake pedal is not pressed	status.	
0		ET003:	STOP light contact (opening)	ACTIVE, if brake pedal is not pressed	If there is a fault, refer to	
2				INACTIVE, if brake pedal is pressed	status.	
		ET004:	STOP light contact (closure)	INACTIVE, if brake pedal is not pressed		
				ACTIVE, if brake pedal is pressed	status.	
3	Selector	ET157:	Selector lever unlocking	YES, if brake pedal is pressed NO, if brake pedal is not pressed		
	lever locking					

SELECTOR LEVER LOCK SUB-FUNCTION



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no faults present or stored). Test conditions: engine stopped, ignition on.			
Nores	The values shown in this conformity check are given as examples only. If necessary, refer to the exact operating specifications in the Workshop Repair Manual.			

SELECTOR LEVER LOCK SUB-FUNCTION

Order	Function	Parameter or Status checked or Action		Display and Notes	Fault finding
				In position "P"	
				OPEN	
4	Multifunction switch	ET123:	Multifunction switch S2		If there is a fault, refer
	ownorr	ET124:	Multifunction switch S3	OPEN	to the interpretation of these statuses.
		ET125:	Multifunction switch S4	OPEN	
5	Gear change mode	ET097:	Manual mode	ACTIVE, if selector lever is in position "M", "M+" or "M-"	If there is a fault, refer
			6	INACTIVE, if selector lever is in position "P", "R", "N" or "D"	to the interpretation of this status.
6	Sequential lever	ET127:	Sequential lever downshift contact	CLOSED, if lever in position " M- "	
				OPEN , if lever is in any position other than " M- "	If there is a fault, refer
		ET128:	Sequential lever upshift contact	CLOSED, if lever in position "M+"	these statuses.
				OPEN , if lever is in any position other than " M+ "	


NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no faults present or stored). Test conditions: engine stopped, ignition on.
	The values shown in this conformity check are given as examples only. If necessary, refer to the exact operating specifications in the Workshop Repair Manual.

Order	Function	Para ch	ameter or Status ecked or Action	Display and Notes	Fault finding
		PR006:	Engine speed	0 rpm	If there is a fault, refer to the interpretation of this parameter.
1 2 3 4	Rotation speeds	PR007:	Turbine speed	0 rpm	If there is a fault, refer to the interpretation of this parameter.
		PR128:	Engine/turbine speed difference	0 rpm	If there is a fault, refer to the interpretation of this parameter.
		PR003:	Oil pressure	X < 0.2 bar	If there is a fault, refer to the interpretation of this parameter
2	Oil pressure	PR138:	Required pressure	21 bar	None.
1 2 3 4		PR146:	Difference between specification and oil pressure	X = PR138 - PR003	None.
3	Torque converter	ET071:	Torque converter	INACTIVE	If there is a fault, refer to the interpretation of this status.
4	Oil	PR004:	Gearbox oil temperature	- 40 < X < 140 °C	If there is a fault, refer to the interpretation of this parameter.
	temperature	ET010:	Oil too hot signal	YES/NO	YES, if oil temperature is > 140 °C
5	Driving mode	ET079:	Economy mode	YES, if driving is economical	None.
5				NO, if driving is sporty	

LOCK-UP/UNLOCKING SUB-FUNCTION



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no faults present or stored). Test conditions: engine stopped, ignition on.
	The values shown in this conformity check are given as examples.

Parameter or Status Order Function **Display and Notes Fault finding** checked or Action PR003: Oil pressure X < 0.2 bar If there is a fault, refer 1 Oil pressure to the interpretation of this parameter. - 40 °C < X < 140 °C PR004: Gearbox oil If there is a fault, refer Oil 2 to the interpretation of temperature temperature this parameter. PR105: Vehicle speed 0 mph If there is a fault, refer 3 Vehicle speed to the interpretation of this parameter. **PR006:** Engine speed 0 rpm If there is a fault, refer 4 Engine speed to the interpretation of this parameter. PR007: Turbine speed 0 rpm If there is a fault, refer Speed of 5 to the interpretation of rotation this parameter. Engine/ PR128: Engine/turbine If there is a fault, refer 0 rpm 6 turbine speed speed difference to the interpretation of difference this parameter.

SUB-FUNCTION: CREEPING AT IDLE SPEED



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no faults present or stored). Test conditions: engine stopped, ignition on.
	The values shown in this conformity check are given as examples.

Parameter or Status Order Function **Display and Notes** Fault finding checked or Action % PR135: Specified If there is a fault, refer Specified 7 pedal position to the interpretation pedal position of this parameter. ET003: STOP light **OPEN**, brake pedal If there is a fault, refer contact released. 8 Brake pedal to the interpretation (opening) CLOSED, brake pedal of this status. pressed. ET004: Stop light OPEN, brake pedal If there is a fault, refer released. contact 9 Brake pedal to the interpretation (closure) CLOSED, brake pedal of this status. pressed. "R" for reverse. ET013: Gear engaged "1P" for 1st locked. "2P" for 2nd locked. "3P" for 3rd locked. "4P" for 4th locked. "1G" for 1st slipping. If there is a fault, refer "2G" for 2nd slipping. 10 to the interpretation Gear engaged "3G" for 3rd slipping. of this status. "4G" for 4th slipping. "1" for 1st unlocked. "2" for 2nd unlocked. "3" for 3rd unlocked. "4" for 4th unlocked.

SUB-FUNCTION: CREEPING AT IDLE SPEED (continued)

AUTOMATIC TRANSMISSION

Fault finding - List of statuses



Tool status	Diagnostic tool description
ET001	Solenoid valves feed
ET003	Stop light contact (opening)
ET010	Oil too hot signal
ET012	Selector lever position
ET013	Gear engaged
ET020	Exchanger flow control solenoid valve (EPDE)
ET021	Shift solenoid 1
ET022	Shift solenoid 2
ET023	Shift solenoid 3
ET024	Shift solenoid 4
ET025	Shift solenoid 5
ET026	Shift solenoid 6
ET071	Torque converter
ET097	Manual mode
ET123	Multifunction switch S2
ET124	Multifunction switch S3
ET125	Multifunction switch S4
ET127	Sequential lever downshift contact
ET128	Sequential lever upshift contact
ET142	Brake pedal pressed
ET157	Selector lever unlocking



	SOLENOID VALVES FEED
ET001	

NOTES	There must be no present or stored faults.
-------	--

Force power to the solenoid valves by running command **AC024 "Actuator sequential control"** described in the "Command mode procedures" section.

Disconnect the computer. Check the cleanness and condition of the connections.

Take the "universal bornier **Elé. 1681**". Check the insulation, continuity and absence of stray resistance on the solenoid valve tracks. (For "modular connector" connection positions, see the "System operation and Track assignments" section.)

Undervoltage:

- With the solenoid valve "ACTIVE", the voltage should be 0 V at the solenoid valve terminals.
- With the solenoid valve "INACTIVE", the voltage should be 12 V at the solenoid valve terminals.

Reconnect the modular connector and check that a solenoid valve's control current is **250 mA** when the solenoid valve is **"ACTIVE**".

If the status is not correct, use fault procedure DF012 "Shift solenoids feed".

If the fault is still present, contact your Techline.

AFTER REPAIR

Repeat the conformity check from the start.



	STOP LIGHT CONTACT (OPENING)
ET003	

NOTES	There must be no present or stored faults.
NOTES	There must be no present or stored faults.

Check that the status is "ACTIVE" with the brake pedal released, and changes to "INACTIVE" when the pedal is
pressed.
Check the cleanness and condition of the brake light switch connections.

Check the **position**, **adjustment** and **correct operation** of the brake light switch.

Disconnect the battery.

Disconnect the computer. Check the cleanness and condition of the connections.

Take the "universal bornier **Elé. 1681**". Check the **insulation, continuity and absence of stray resistance** on the following connections:

Computer track 16 -----> Stop light switch track 3

Repair if necessary.

If the correct statuses are not displayed, replace the sensor.

AFTER REPAIR Repeat the conform

Repeat the conformity check from the start.



	OIL TOO HOT SIGNAL
ET010	

NOTES There must be no present or stored faults.	
---	--

This status indicates that the oil temperature is higher than normal operating temperature. The status is **NO** if the gearbox oil temperature is below **140** °C.

The status changes to YES when the gearbox oil temperature exceeds 140 °C.

When the status is "YES", the oil temperature has to drop below 130 °C for the status to change to "NO".

If the correct status is not displayed, use the interpretation of fault **DF177 "Automatic transmission overheating"**.

If the fault is still present, contact your Techline.

AFTER REPAIR Repeat the conformity check from the start.



ET012 NOTES There must be no present or stored faults. LEVER POSITION "P"-"R"-"N"-"D" Check the cleanness, condition and mounting of the automatic transmission multifunction switch. Check the control settings (see Workshop Repair Manual). Disconnect the battery. Disconnect the "modular connector" and check the cleanness and condition of connector "A" connections. (For "modular connection connection positions, see the "System operation and Track assignments" section.) Carry out the following checks on the multifunction switch: Continuity: Lever in position "P", track A10 Lever in position "P", track A10 Lever in position "P", track A12 Lever in position "P", track A3, A11, A12 Lever in position "P", track A3, A10, A11 Disconnect the multifunction switch. Connect the "universal bornier El6. ft81" in place of the computer and check the insulation, continuity and absence of stray resistance in the connections between: Computer track 31 Computer track 32 Multifunction switch track A11 Computer track 33 Multifunction switch track A12		GEAR SELECTOR POSITION	
NOTES There must be no present or stored faults. LEVER POSITION "P"-"R"-"N"-"D" Check the cleanness, condition and mounting of the automatic transmission multifunction switch. Check the control settings (see Workshop Repair Manual). Disconnect the battery. Disconnect the "modular connector" and check the cleanness and condition of connector "A" connections. (For "modular connector" connection positions, see the "System operation and Track assignments" section.) Carry out the following checks on the multifunction switch: Continuity: Lever in position "P", track A10 Lever in position "R", track A11, A12 Lever in position "P", track A21 Lever in position "P", track A31 Lever in position "P", track A3, A11, A12 Lever in position "R", track A9, A11, A12 Lever in position "R", track A9, A10, A11 Lever in position "R", track A9, A10, A12 Lever in position "R", track A9, A10, A11 Lever in position "R", track A1, A12 Lever in position "R", track A9, A10, A11 Lever in position "R", track A1, A12 Lever in position "R", track A1, A14 Lever in position "R", track A14, A14 Lever in position "R", track A14, A14 Lever in position "R", track	ET012		
NOTES There must be no present or stored faults. LEVER POSITION "P"-"R"-"N"-"D" Check the cleanness, condition and mounting of the automatic transmission multifunction switch. Check the control settings (see Workshop Repair Manual). Disconnect the battery. Disconnect the "modular connector" and check the cleanness and condition of connector "A" connections. (For "modular connector" connection positions, see the "System operation and Track assignments" section.) Carry out the following checks on the multifunction switch: Continuity: Lever in position "P", track A10 Lever in position "N", track A11 Lever in position "P", track A2 Lever in position "P", track A3, A11, A12 Lever in position "P", track A3, A11, A12 Lever in position "P", track A3, A11, A12 Lever in position "P", track A3, A10, A12 Lever in position "P", track A3, A10, A11 Track A7 Lever in position "P", track A3, A10, A12 Lever in position "P", track A3, A10, A11 Track A7 Lever in position "P", track A3, A10, A11 Track A7 Lever in position "P", track A3, A10, A11 Track A7 Lever in position "P", track A3, A10, A12 Track A7 Lever in position "P", track A3, A10, A11 Track A7 Disconnect the multifunction switch. Connect the "universal bornier El6, 1681" in place of the computer and check the insulation, continuity and absence of strary resistance in the connections between: Computer track 31 Computer track A12			
NOTES There must be no present or stored faults. LEVER POSITION "P"-"R"-"N"-"D" Check the cleanness, condition and mounting of the automatic transmission multifunction switch. Check the control settings (see Workshop Repair Manual). Disconnect the battery. Disconnect the "modular connector" and check the cleanness and condition of connector "A" connections. (For "modular connector" connection positions, see the "System operation and Track assignments" section.) Carry out the following checks on the multifunction switch: Continuity: Lever in position "P", track A10 Lever in position "N", track A11 Lever in position "N", track A12 Lever in position "D", track A12 Lever in position "P", track A9 Lever in position "R", track A9, A11, A12 Lever in position "R", track A9, A11, A12 Lever in position "R", track A9, A10, A12 Lever in position "D", track A9, A10, A12 Lever in position "D", track A9, A10, A11 Lever in position "D", track A9, A10, A12 Lever in position "D", track A9, A10, A11 Lever in position "D", track A11 Lever in positio			
NOTES There must be no present or stored faults. LEVER POSITION "P"-"R"-"N"-"D" Check the cleanness, condition and mounting of the automatic transmission multifunction switch. Check the control settings (see Workshop Repair Manual). Disconnect the battery. Disconnect the "modular connector" and check the cleanness and condition of connector "A" connections. (For "modular connector" connection positions, see the "System operation and Track assignments" section.) Carry out the following checks on the multifunction switch: Lever in position "P", track A10 Lever in position "R", track A10, A11, A12 Lever in position "N", track A12 Lever in position "D", track A12 Lever in position "P", track A9, A11, A12 Lever in position "P", track A9, A11, A12 Lever in position "P", track A9, A10, A11 Lever in position "P", track A10, A11 Lever in position "P", track A10, A12 Lever in position "P", track A3, A10, A11 Lever in position "P", track A10, A11 Lever in position "P", track A3, A10, A11 Lever in position "P", track A11, A12 Lever in position "P", track A3, A10, A11 Lever in position "P", track A11, A12 Lever in position "P", track A3, A10, A11			
LEVER POSITION "P"-"R"-"N"-"D" Check the cleanness, condition and mounting of the automatic transmission multifunction switch. Check the control settings (see Workshop Repair Manual). Disconnect the battery. Disconnect the "modular connector" and check the cleanness and condition of connector "A" connections. (For "modular connector" connection positions, see the "System operation and Track assignments" section.) Carry out the following checks on the multifunction switch: Continuity: Lever in position "P", track A10 Lever in position "R", track A10, A11, A12 Lever in position "N", track A11 Lever in position "D", track A12 Insulation: Lever in position "P", track A9, A11, A12 Lever in position "R", track A9, A11, A12 Lever in position "R", track A9, A10, A12 Lever in position "N", track A9, A10, A12 Lever in position "N", track A9, A10, A12 Lever in position "D", track A9, A10, A11 Disconnect the multifunction switch. Connect the multifunction switch. Connect the multifunction switch. Connect the "universal bornier Elé. f881" in place of the computer and check the insulation, continuity and absence of stray resistance in the connections between: Computer track 31 Computer track 32 Multifunction switch track A11 Computer track 33 Multifunction switch track A11	NOTES	There must be no present or stored faults.	
LEVER POSITION "P"-"R"-"N"-"D" Check the cleanness, condition and mounting of the automatic transmission multifunction switch. Check the control settings (see Workshop Repair Manual). Disconnect the battery. Disconnect the "modular connector" and check the cleanness and condition of connector "A" connections. (For "modular connector" connection positions, see the "System operation and Track assignments" section.) Carry out the following checks on the multifunction switch: Lever in position "P", track A10 Lever in position "R", track A11 Lever in position "R", track A12 track A7 track A7 track A7 Insulation: Lever in position "P", track A9, A11, A12 Lever in position "R", track A9, A11, A12 Lever in position "R", track A9, A11, A12 Lever in position "P", track A9, A11, A12 Lever in position "P", track A9, A11, A12 Lever in position "P", track A9, A10, A12 Disconnect the multifunction switch. Connect the multifunction switch. Connect the universal bornier EI6. 1681" in place of the computer and check the insulation, continuity and absence of stray resistance in the connections between: Computer track 31 Computer track A11 Computer track A11 Computer track A12			
Disconnect the battery. Disconnect the "modular connector" and check the cleanness and condition of connector "A" connections. (For "modular connector" connection positions, see the "System operation and Track assignments" section.) Carry out the following checks on the multifunction switch: Continuity: Lever in position "P", track A10 Lever in position "R", track A10, A11, A12 Lever in position "N", track A11 Lever in position "D", track A12 Lever in position "P", track A9, A11, A12 Lever in position "R", track A9 Lever in position "R", track A10, A11 Track A7 Lever in position "R", track A10, A11 Disconnect the multifunction switch. Connect the "universal bornier Elé. 1681" in place of the computer and check the insulation, continuity and absence of stray resistance in the connections between: Computer track 31 Computer track 32 Multifunction switch track A11 Computer track 32 Multifunction switch track A12	LEVER POSITION "P"-"R"-"N"-"D"	Check the cleanness, condition and mounting of the automatic transmission multifunction switch. Check the control settings (see Workshop Repair Manual).	
Carry out the following checks on the multifunction switch: Continuity: Lever in position "P", track A10 Lever in position "R", track A10, A11, A12 Lever in position "N", track A11 Lever in position "D", track A12 Insulation: Lever in position "P", track A9, A11, A12 Lever in position "R", track A9 Lever in position "R", track A9 Lever in position "N", track A9, A10, A12 Lever in position "N", track A9, A10, A12 Lever in position "D", track A9, A10, A11 Disconnect the multifunction switch. Connect the "universal bornier Elé. 1681" in place of the computer and check the insulation, continuity and absence of stray resistance in the connections between: Computer track 31 Computer track 33 Multifunction switch track A11 Computer track 33 Multifunction switch track A11		Disconnect the battery. Disconnect the "modular connector" and check the cleanness and condition of connector " A " connections. (For "modular connector" connection positions, see the "System operation and Track assignments" section.)	
Continuity: Lever in position "P", track A10 track A7 Lever in position "R", track A10, A11, A12 track A7 Lever in position "N", track A11 track A7 Lever in position "D", track A12 track A7 Insulation: track A9, A11, A12 Lever in position "P", track A9, A11, A12 track A7 Lever in position "R", track A9, A11, A12 track A7 Lever in position "P", track A9, A10, A12 track A7 Lever in position "N", track A9, A10, A12 track A7 Lever in position "D", track A9, A10, A11 track A7 Disconnect the multifunction switch. Connect the "universal bornier Elé. 1681" in place of the computer and check the insulation, continuity and absence of stray resistance in the connections between: Computer track 31 Multifunction switch track A10 Computer track 32 Multifunction switch track A11		Carry out the following checks on the multifunction switch:	
Lever in position "P", track A10 Lever in position "R", track A10, A11, A12 Lever in position "N", track A11 Lever in position "D", track A12 Insulation: Lever in position "P", track A9, A11, A12 Lever in position "R", track A9 Lever in position "N", track A9, A10, A12 Lever in position "N", track A9, A10, A12 Lever in position "D", track A9, A10, A11 Disconnect the multifunction switch. Connect the "universal bornier Elé. 1681" in place of the computer and check the insulation, continuity and absence of stray resistance in the connections between: Computer track 31 Computer track 32 Multifunction switch track A11 Computer track 33 Multifunction switch track A12		Continuity:	
Lever in position "N", track A10, A11, A12 Lever in position "N", track A11 Lever in position "D", track A12 Insulation: Lever in position "P", track A9, A11, A12 Lever in position "R", track A9 Lever in position "N", track A9, A10, A12 Lever in position "D", track A9, A10, A11 Disconnect the multifunction switch. Connect the "universal bornier Elé. 1681" in place of the computer and check the insulation, continuity and absence of stray resistance in the connections between: Computer track 31 Computer track 32 Multifunction switch track A11 Computer track 33 Multifunction switch track A12		Lever in position "P", track A10	
Lever in position "D", track A12 Insulation: Lever in position "P", track A9, A11, A12 Lever in position "R", track A9 Lever in position "N", track A9, A10, A12 Lever in position "D", track A9, A10, A12 Disconnect the multifunction switch. Connect the "universal bornier Elé. 1681" in place of the computer and check the insulation, continuity and absence of stray resistance in the connections between: Computer track 31 Computer track 32 Multifunction switch track A11 Computer track 33 Multifunction switch track A12		Lever in position "N", track A10, A11, A12 track A7 Lever in position "N", track A11 track A7	
Insulation: Lever in position "P", track A9, A11, A12 Lever in position "R", track A9 Lever in position "N", track A9, A10, A12 Lever in position "D", track A9, A10, A11 Disconnect the multifunction switch. Connect the "universal bornier Elé. 1681" in place of the computer and check the insulation, continuity and absence of stray resistance in the connections between: Computer track 31 → Multifunction switch track A10 Computer track 32 → Multifunction switch track A11 Computer track 33 → Multifunction switch track A12		Lever in position "D", track A12	
Lever in position "P", track A9, A11, A12 Lever in position "R", track A9 Lever in position "N", track A9, A10, A12 Lever in position "D", track A9, A10, A11 Disconnect the multifunction switch. Connect the "universal bornier Elé. 1681" in place of the computer and check the insulation, continuity and absence of stray resistance in the connections between: Computer track 31 Computer track 32 Multifunction switch track A11 Computer track 33 Multifunction switch track A12		Insulation:	
Lever in position 'R', track A9, A10, A12 Lever in position 'D', track A9, A10, A11 track A7 Lever in position 'D', track A9, A10, A11 track A7 Disconnect the multifunction switch. Connect the "universal bornier Elé. 1681" in place of the computer and check the insulation, continuity and absence of stray resistance in the connections between: Computer track 31 + Multifunction switch track A10 Computer track 32 + Multifunction switch track A11 Computer track 33 + Multifunction switch track A12		Lever in position "P", track A9, A11, A12	
Lever in position "D", track A9, A10, A11 Disconnect the multifunction switch. Connect the "universal bornier Elé. 1681" in place of the computer and check the insulation, continuity and absence of stray resistance in the connections between: Computer track 31 Computer track 32 Multifunction switch track A10 Computer track 33 Multifunction switch track A11 Computer track 33 Multifunction switch track A12		Lever in position "N", track A9, A10, A12	
Disconnect the multifunction switch. Connect the "universal bornier Elé. 1681" in place of the computer and check the insulation, continuity and absence of stray resistance in the connections between: Computer track 31		Lever in position "D", track A9, A10, A11 + track A7	
Computer track 42 — Multifunction switch track A7		Disconnect the multifunction switch. Connect the "universal bornier Elé. 1681" in place of the computer and check the insulation, continuity and absence of stray resistance in the connections between: Computer track 31 — Multifunction switch track A10 Computer track 32 — Multifunction switch track A11 Computer track 33 — Multifunction switch track A12 Computer track 42 — Multifunction switch track A7 Repair if necessary	

AFTER REPAIR	Repeat the conformity check from the start.



ET012 (continued)	
NOTES	There must be no present or stored faults.
LEVER POSITION "M" "M+" AND "M-" SEQUENTIAL SHIFT	Check the cleanness and condition of the sequential switch module connections. Disconnect the computer. Check the cleanness and condition of the connections. Take the "universal bornier Elé. 1681". Check the insulation, continuity and absence of stray resistance on the following connections: Computer track 36 Sequential switch module track B3 Computer track 37 Sequential switch module track A3 Battery earth Sequential switch module track A2 Repair if necessary. If the fault is still present, replace the sequential switch module.

AFTER REPAIR

Repeat the conformity check from the start.



ET013	GEAR ENGAGED	
NOTES	There must be no present or s	tored faults.
 "1" for 1st unlocked "2" for 2nd unlocked "3" for 3rd unlocked "4" for 4th unlocked "1G" for 1st slipping "2G" for 2nd slipping 		 "1P" for 1st locked "2P" for 2nd locked "3P" for 3rd locked "4P" for 4th locked "R" for reverse "MD" for safe position

- 2G" for 2' ⁴ slipping - "**3G**" for 3rd slipping
- "4G" for 4th slipping

If the fault is caused by the converter lock-up, use the interpretation of faults DF016 "Lock-up solenoid valve circuit", DF018 "Lock-up slip" and DF120 "Controlled slip".

"N" for neutral position

If the fault is caused by the gear engaged, carry out fault finding on the multifunction switch. Check that statuses ET123, ET124, ET125 and ET126 display correctly. Check the multifunction switch adjustment.

If the fault is still present, contact your Techline.





ET020	EXCHANGER FLOW CONTROL SOLENOID VALVE
-------	---------------------------------------

NOTES	There must be no present or stored faults.
-------	--

The exchanger flow control solenoid valve is "ACTIVE" when the gearbox oil temperature exceeds 100 °C and the engine speed is more than 2000 rpm.

Otherwise the solenoid valve remains inactive.

Run command **AC024 "Actuator sequential control"** and check that the activation status changes from "**INACTIVE**" to "**ACTIVE**".

When the solenoid valve is "ACTIVE" the voltage should be 0 V.

When the solenoid valve is "INACTIVE" the voltage should be 12 V.

Reconnect the computer.

Activate the solenoid valves with command AC024 "Actuator sequential control" and check the solenoid valve current.

If the current is 260 mA, the solenoid valve is operating correctly.

If the current is lower, check the connections and wiring from the computer to the exchanger flow solenoid valve.

If the command status does not change, use the interpretation of fault **DF017 "Exchanger flow solenoid valve circuit"**.

If the problem persists after the diagnostic procedure for fault **DF017 "Exchanger flow solenoid valve circuit"** has been followed, contact your Techline.

AFTER REPAIR	Repeat the conformity check from the start.



	SHIFT SOLENOID 1
ET021	

NOTES	There must be no present or stored faults.
NOTES	mere must be no present of stored ladits.

This indicates the status of the solenoid valve: "ACTIVE / INACTIVE". Its status must be "INACTIVE" in all lever positions.

Disconnect the computer. Check the **cleanness and condition** of the connections. Check the continuity between **track 9** of the computer connector and **track B8** of the "modular connector". Check across **tracks 1 and 9** of the computer connector that the resistance of shift solenoid no. 1 is $40 \Omega \pm 2 \Omega$ at approximately 20 °C.

If the resistance exceeds 50 Ω , check the harness, computer connector and "modular connector".

Reconnect the computer.

Activate the solenoid valves with command AC024 "Actuator sequential control" and measure the current in the solenoid valves.

If the current is **250 mA**, the solenoid valve is operating correctly.

If the current is lower, check the connections and wiring from the computer to the solenoid valve.

If the correct status is not displayed, use the interpretation of fault DF085 "Shift solenoid 1 circuit".

If the fault is still present, replace the electric/hydraulic interface.

AFTER REPAIR

Repeat the conformity check from the start. Check that all up and down shifts are correct.



	SHIFT SOLENOID 2
ET022	

NOTES	There must be no present or stored faults.

The status should be **"INACTIVE**" when the selector lever is in position **"P"**, **"R"**, **"N"**, or **"D"**. The status should be **"ACTIVE**" when the selector lever is in position **"M"**, **"M+"**, or **"M-"**.

Disconnect the computer. Check the **cleanness and condition** of the connections. Check the **continuity** between **track 9** of the computer connector and **track B8** of the "modular connector". Check across **tracks 1 and 9** of the computer connector that the resistance of shift solenoid no. 2 is $40 \Omega \pm 2 \Omega$ at approximately 20 °C.

If the resistance exceeds 50 Ω , check the harness, computer connector and "modular connector".

Reconnect the computer.

Activate the solenoid valves with command **AC024** "Actuator sequential control" and measure the current in the solenoid valves.

If the current is **250 mA**, the solenoid valve is operating correctly.

If the current is lower, check the connections and wiring from the computer to the solenoid valve.

If the correct status is not displayed, use the interpretation of fault DF086 "Shift solenoid 2 circuit".

If the fault is still present, replace the electric/hydraulic interface.

Repeat the conformity check from the start. Check that shifting up and down through each gear works properly.



	SHIFT SOLENOID 3
ET023	

NOTES	There must be no present or stored faults.

The status should be "INACTIVE" when the selector lever is in position "R", "M+", or "M-".

The status should be "ACTIVE" when the selector lever is in position "P", "N", "D", or "M".

Disconnect the computer. Check the **cleanness and condition** of the connections. Check the **continuity** between **track 7** of the computer connector and **track B10** of the "modular connector". Check across **tracks 1 and 7** of the computer connector that the resistance of shift solenoid no. 3 is $40 \Omega \pm 2 \Omega$ at approximately 20 °C.

If the resistance exceeds 50 Ω , check the harness, computer connector and "modular connector".

Reconnect the computer.

Activate the solenoid valves with command **AC024** "Actuator sequential control" and measure the current in the solenoid valves.

If the current is **250 mA**, the solenoid valve is operating correctly.

If the current is lower, check the connections and wiring from the computer to the solenoid valve.

If the correct status is not displayed, use the interpretation of fault DF087 "Shift solenoid 3 circuit".

If the fault is still present, replace the electric/hydraulic interface.

AFTER REPAIR

Repeat the conformity check from the start. Check that shifting up and down through each gear works properly.



	SHIFT SOLENOID 4
ET024	

NOTES	There must be no present or stored faults.
-------	--

The status should be "INACTIVE" when the selector lever is in position "P", "R", or "N".

The status should be "ACTIVE" when the selector lever is in position "M", "M+", or "M-".

Disconnect the computer. Check the **cleanness and condition** of the connections. Check the **continuity** between **track 8** of the computer connector and **track B7** of the "modular connector". Check across **tracks 1 and 8** of the computer connector that the resistance of shift solenoid no. 4 is $40 \Omega \pm 2 \Omega$ at approximately 20 °C.

If the resistance exceeds 50 Ω , check the harness, computer connector and "modular connector".

Reconnect the computer.

Activate the solenoid valves with command **AC024** "Actuator sequential control" and measure the current in the solenoid valve.

If the current is **250 mA**, the solenoid valve is operating correctly.

If the current is lower, check the connections and wiring from the computer to the solenoid valve.

If the correct status is not displayed, use the interpretation of fault DF089 "Shift solenoid 4 circuit".

If the fault is still present, replace the electric/hydraulic interface.

AFTER REPAIR

Repeat the conformity check from the start. Check that shifting up and down through each gear works properly.



	SHIFT SOLENOID 5
ET025	

There must be no present or stored faults.

The status should be **"INACTIVE**" when the selector lever is in position "**P**", "**R**", "**N**", "**M+**", or "**M-**". The status should be **"ACTIVE**" when the selector lever is in position "**D**", or "**M**".

Disconnect the computer. Check the **cleanness and condition** of the connections. Check the **continuity** between **track 13** of the computer connector and **track B5** of the "modular connector". Check across **tracks 14 and 1** of the computer connector that the resistance of shift solenoid no. 5 is $40 \Omega \pm 2 \Omega$ at approximately 20 °C.

If the resistance exceeds 50 Ω , check the harness, computer connector and "modular connector".

Reconnect the computer.

Activate the solenoid valves with command **AC024** "Actuator sequential control" and measure the current in the solenoid valves.

If the current is **250 mA**, the solenoid valve is operating correctly.

If the current is lower, check the connections and wiring from the computer to the solenoid valve.

If the correct status is not displayed, use the interpretation of fault DF088 "Shift solenoid 5 circuit".

If the fault is still present, replace the electric/hydraulic interface.

Repeat the conformity check from the start. Check that shifting up and down through each gear works properly.



	SHIFT SOLENOID 6
ET026	

NOTES	There must be no present or stored faults.

This indicates the status of the solenoid valve: "ACTIVE / INACTIVE". The status should be "INACTIVE" when the selector lever is in any engaged gear position.

Disconnect the computer. Check the **cleanness and condition** of the connections. Check the **continuity** between **track 14** of the computer connector and **track B2** of the "modular connector". Check across **tracks 14 and 1** of the computer connector that the resistance of shift solenoid no. 6 is $40 \Omega \pm 2 \Omega$ at approximately 20 °C.

If the resistance exceeds 50 Ω , check the harness, computer connector and "modular connector".

Reconnect the computer.

Activate the solenoid valves with command **AC024** "Actuator sequential control" and measure the current in the solenoid valves.

If the current is **250 mA**, the solenoid valve is operating correctly.

If the current is lower, check the connections and wiring from the computer to the solenoid valve.

If the status displayed is still not correct, use the interpretation of fault DF112 "Shift solenoid 6 circuit".

If the fault is still present, replace the electric/hydraulic interface.

AFTER REPAIR

Repeat the conformity check from the start. Check that shifting up and down through each gear works properly.



ET071	TORQUE CONVERTER

NOTES There	must be no present or stored faults.
--------------------	--------------------------------------

This indicates the status of the torque converter.

The status should be "ACTIVE" when the vehicle is driven with a gear engaged.

The status should be "INACTIVE" when starting, changing gears, or if the vehicle is stopped.

If the correct status is not displayed, use the interpretation of fault **DF016 "Converter lock-up solenoid valve circuit"**.

If the fault is still present, contact your Techline.

AFTER REPAIR Repeat the conformity check from the start.



	MANUAL MODE
ET097	

NOTES	There must be no present or stored faults.
10120	

This status indicates the selector lever position. The status should be "ACTIVE" when the selector lever is in position "M", "M+" or "M-". The status should be "INACTIVE" when the selector lever is in position "P", "R", "N", or "D".

If the correct status is not displayed, use the interpretation of fault DF093 "Sequential gear lever circuit".

If the fault is still present, replace the sequential switch module.

If the fault is still present, contact your Techline.



AFTER REPAIR Repeat the conformity check from the start. Check that all up and down gear changes operate correctly in automatic and sequential mode.



FT123	MULTIFUNCTION SWITCH S2
ET124	MULTIFUNCTION SWITCH S3
ET125	MULTIFUNCTION SWITCH S4

NOTES	There must be no present or stored faults. Multifunction switch contact S1 is not connected on this model.
-------	---

These indicate the status of the various multifunction switch contacts for each selector lever position. The switch status can be **"OPEN"** or **"CLOSED"** (see table below).

	S2	S 3	S4
Р	CLOSED	OPEN	OPEN
R	CLOSED	CLOSED	CLOSED
N	OPEN	CLOSED	OPEN
D	OPEN	OPEN	CLOSED
М	OPEN	OPEN	CLOSED
M+	OPEN	OPEN	CLOSED
M-	OPEN	OPEN	CLOSED

If the correct status is not displayed, use the interpretation of fault: – DF008 "Multifunction switch intermediate position".

If after these checks, statuses ET123, ET124 or ET125 are incorrect, replace the multifunction switch.

AFTER REPAIR	Repeat the conformity check from the start.



	SEQUENTIAL LEVER DOWNSHIFT CONTACT
ET127	

NOTES There must be no present or stored faults.	
---	--

This indicates the status of the sequential lever downshift contact.

The status should be "CLOSED" when the selector lever is held in position "M-".

The status should be "OPEN" when the selector lever is in any position except "M-".

Check the sequential switch + 12 V feed on track B1 and the earth on track A2 of the sequential switch.

With the selector lever in position "**M**", measure the voltage between:

Sequential switch track B5 -----> Earth Sequential switch track B6 -----> Earth

If any of the measured values is + 12 V, replace the sequential switch.

If the values are 0 V, check that the selector lever positions match the instrument panel display.

If the correct status is not displayed, use the interpretation of fault DF093 "Sequential gear lever circuit".

If the fault is still present, contact your Techline.

AFTER REPAIR Repeat the conformity check from the start.



	SEQUENTIAL LEVER UPSHIFT CONTACT
ET128	

NOTES	There must be no present or stored faults.
NOTES	There must be no present or stored faults.

This indicates the status of the sequential lever upshift contact.

The status should be "CLOSED" when the selector lever is in position "M+".

The status should be "OPEN" when the selector lever is in any position except "M+".

Check the sequential switch + 12 V feed on track B1 and the earth on track A2 of the sequential switch.

With the selector lever in position "**M**", measure the voltage between:

Sequential switch track B5 -----> Earth Sequential switch track B6 -----> Earth

If any of the measured values is + 12 V, replace the sequential switch.

If the values are **0 V**, check that the selector lever positions match the instrument panel display.

If the correct status is not displayed, use the interpretation of fault DF093 "Sequential gear lever circuit".

If the fault is still present, contact your Techline.

AFTER REPAIR Repeat the conformity check from the start.



	BRAKE PEDAL PRESSED
ET142	

NOTES	There must be no present or stored faults.
-------	--

This status indicates the position of the brake pedal The status is "**YES**" when the brake pedal is pressed. The status is "**NO**" when the brake pedal is not pressed.

If the correct status is not displayed as above, use the interpretation of fault DF119 "Brake pedal position".

If the fault is still present, replace the brake sensor. If the fault is still present, contact your Techline.

AFTER REPAIR	Repeat the conformity check from the start.



	SELECTOR LEVER UNLOCKING
ET157	

NOTES	There must be no present or stored faults.
-------	--

This status indicates whether or not the selector lever is unlocked.

Lever in position "P".

The status is **"YES**" when the brake pedal is pressed.

The status is " $\ensuremath{\text{NO}}$ " when the brake pedal is not pressed.

Lever in any position except "P".

The status is "YES" whether or not the brake pedal is pressed.

Check that the instrument panel indicates that the lever is in position "P".

Check that, when the brake pedal is pressed, the "Press brake pedal" message disappears from the instrument panel.

Check the selector lever operation up to the multifunction switch. Adjust the cable if necessary.

Check that statuses ET154, ET123, ET124 and ET125 "Multifunction switch" are correct.

If the correct status is not displayed, use the interpretation of fault **DF095** "Selector lever locking electromagnet circuit".

If the fault is still present, contact your Techline.

AFTER REPAIR	Repeat the conformity check from the start.

AUTOMATIC TRANSMISSION

Fault finding - List of parameters



Parameter names	
PR003	Oil pressure
PR004	Gearbox oil temperature
PR007	Turbine speed
PR008	computer feed voltage
PR105	Vehicle speed
PR128	Engine/turbine speed difference



PR003	OIL PRESSURE
NOTES	There must be no present or stored faults.

Disconnect the battery. Disconnect the "modular connector", and check the cleanness and condition of the connections.
Disconnect the computer. Check the cleanness and condition of the connections. Take the "universal bornier Elé. 1681 ". Check the insulation, continuity and absence of stray resistance on the following connections: (For "modular connector" connection positions, see the "System operation and Track assignments" section.)
Computer track 24 Computer track 55 Computer track 25 Computer track 25 Computer track 20 Computer track 20 Track B9 Modular connector plug Computer track 26 Track B12 Modular connector plug
Reconnect the "modular connector". Check that the oil pressure sensor resistance between tracks 24 and 25 of the computer connector is approximately 20 k Ω . If the value is not correct, replace the sensor.
Check across tracks 20 and 26 of the computer connector that the resistance of the pressure regulating solenoid valve is $1 \Omega \pm 0.2 \Omega$ at approximately 23 °C. If the resistance is not correct, the solenoid valve or the electric/hydraulic interface harness is damaged.
Check the gearbox oil quality and level. If an oil change or top-up is necessary see the "Draining-Filling-Levels" section of the Workshop Repair Manual. Check that the gearbox is not leaking oil. (continued on next page)

AFTER REPAIR	Repeat the conformity check from the start.



PR003 CONTINUED				
--------------------	--	--	--	--

See the "Taking line pressure" section of the Workshop Repair Manual.

Connect the pressure gauge for a line pressure reading.

With the engine hot and the gearbox oil temperature between **60 and 80 °C**, check the difference between the line pressure sensor (**PR003**) and pressure gauge in the following conditions:

- with the engine stopped, the pressure gauge should indicate a residual pressure of about **0.2 bar**.

If the sensor reading differs by more than **0.2 bar**, replace the sensor.

- with the engine running at about **1200 rpm** the pressure gauge reading should reach **7 bar**.

If the sensor reading differs by more than **0.8 bar**, replace the sensor.

Hot engine and gearbox oil temperature between 60 and 80 °C.

Take the line pressure readings under the following conditions:

- selector lever in position "P" or "N" and engine running at 2000 rpm, the pressure should be between 2.6 and 3.2 bar.
- with the selector lever in position "R" and engine running at 2000 rpm, the pressure should be more than 4 bar.
- with the selector lever in position "D" and engine running at 2000 rpm, the pressure in first gear should be more than 7 bar.

If the values are not correct, there is a problem inside the gearbox.

If the fault is still present, contact your Techline.

AFTER REPAIR

Repeat the conformity check from the start.

NOTES



	GEARBOX OIL TEMPERATURE
PR004	

There must be no present or stored faults.

Disconnect the battery. Disconnect the "modular connector", and check the cleanness and condition of the connections.
Disconnect the computer. Check the cleanness and condition of the connections. Take the "universal bornier Elé. 1681 ". Check the insulation, continuity and absence of stray resistance on the following connections: (For "modular connector" connection positions, see the "System operation and Track assignments" section.)
Computer track 53 Track B4 Modular connector plug Computer track 54 Track B1 Modular connector plug Computer track 12
Reconnect the "modular connector". Check the oil pressure sensor resistance between computer connector tracks 53 and 54 . The resistance should be between 2360 and 2660 Ω at a temperature of 20 °C and between 290 and 327 Ω at a temperature of 80 °C. If the resistance is not correct, the sensor or the electric/hydraulic interface harness is damaged.
Reconnect the "modular connector". Check across tracks 12 and 2 of the computer connector that the resistance of the heat exchanger flow solenoid valve is 40 $\Omega \pm 4 \Omega$ at approximately 20 °C. If the resistance is not correct, the solenoid valve or harness is damaged.
Check that the water-oil exchanger is not blocked.

AFTER REPAIR	Repeat the conformity check from the start.



	TURBINE SPEED
PR007	

NOTES	There must be no present or stored faults.
Check the turbine speed sensor mounting.	

Disconnect the battery.

Disconnect the "modular connector", and check the cleanness and condition of the connections.

Disconnect the computer. Check the cleanness and condition of the connections. Take the "universal bornier **Elé. 1681**". Check the **insulation and continuity** of the following connections: (For "modular connector" connection details, see the "System operation and Track assignments" section.)

Computer track 45 **Track D1 Modular connector plug** Computer track 46 **Track D2 Modular connector plug**

Reconnect the "modular connector".

Check that the turbine speed sensor resistance between tracks 45 and 46 of the computer connector is approximately 300 $\Omega \pm 40 \Omega$.

If the resistance is not correct, either the sensor or the harness is damaged. Replace the faulty component.

If the fault persists after the sensor has been replaced, contact your Techline.

AFTER REPAIR

Repeat the conformity check from the start.



	COMPUTER FEED VOLTAGE
PR008	

NOTES	There must be no present or stored faults. All electrical consumers switched off.
-------	--

Carry out a thorough check of the battery and charging circuit (see values in the Workshop Repair Manual).
Disconnect the computer. Check the condition and cleanness of the contacts.
Check that the computer earth is properly connected to the vehicle's front left side member.
Check the 20A permanent computer feed fuse marked " 15 " in the Protection and Switching Unit. Check the cleanness and condition of the connections.
Check the 5A after-ignition computer feed fuse marked "5H" in the Protection and Switching Unit. Check the cleanness and condition of the connections.
Disconnect the computer. Disconnect the computer. Check the cleanness and condition of the connections. Disconnect the connector marked " PPM2 " in the Protection and Switching Unit. Take the "universal bornier Elé. 1681 ". Check the insulation and continuity of the following connections:
Computer track 56 — Connector PPM2 track 1 Computer track 27 — Connector PPM2 track 10 Computer track 28 — Left-hand front side member electronic earth 2
Reconnect the battery. With the ignition on, check the presence of + 12 V on tracks 56 and 27 of the computer connector. If there is no + 12 V , there is a fault in the Protection and Switching Unit. Run fault finding on the Protection and Switching Unit.

AFTER REPAIR Rep	peat the conformity check from the start.
------------------	---



Fault finding - Interpretation of parameters

	VEHICLE SPEED
PR105	

NOTES There must be no present or stored faults.	
---	--

Test the multiplex network.

Refer to Workshop Repair Manual 366, "Multiplex network" section.

If the fault is still present, carry out fault finding on the **ABS and ESP** system. See the "**ABS/ESP**" section in the Workshop Repair Manual.

AFTER REPAIR Repeat the conformity check from the start.



AUTOMATIC TRANSMISSION



Fault finding - Interpretation of parameters

PR128	ENGINE/TURBINE SPEED DIFFERENCE	
NOTES	Carry out injection system fault finding and check that it is operating correctly.	
	There must be no present or stored faults.	
Check the gearbox oil quality and level. If an oil change or top-up is necessary see the "Draining-Filling-Levels" section of the Workshop Repair Manual. Check that the gearbox is not leaking oil.		
Disconnect the battery. Disconnect the "modular	connector", and check the cleanness and condition of the connections.	
Disconnect the computer. Check the cleanness and condition of the connections. Take the "universal bornier Elé. 1681 ". Check the insulation and continuity of the following connections: (For "modular connector" connection details, see the "System operation and Track assignments" section.)		
Computer track 45 Track D1 Modular connector plug Computer track 46 Track D2 Modular connector plug Computer track 19 Track B6 Modular connector plug Computer track 26		
Reconnect the "modular connector". Check across tracks 45 and 46 of the computer connector that the turbine speed sensor resistance is 300 $\Omega \pm 40 \Omega$ at approximately 20 °C . If the resistance is not correct, either the sensor or the harness is damaged.		
Reconnect the "modular connector". Check across tracks 19 and 26 of the computer connector that the resistance of the converter lock-up solenoid valve is 1 $\Omega \pm$ 0.2 Ω at approximately 20 °C . If the resistance is not correct, the solenoid valve or the electric/hydraulic interface harness is damaged.		
Carry out a converter stall test. Follow the procedure in the "Converter stall test" section of the Workshop Repair Manual.		
 See the "Taking line pressure" section of the Workshop Repair Manual. Connect the pressure gauge for a line pressure reading. Hot engine and gearbox oil temperature between 60 and 80 °C. Take the line pressure readings under the following conditions: with the selector lever in position "P" or "N" and engine running at 2000 rpm, the pressure should be between 2.6 and 3.2 bar. with the selector lever in position "R" and engine running at 2000 rpm, the pressure should be more than 4 bar. with the selector lever in position "D" and engine running at 2000 rpm, the pressure in first gear should be more than 7 bar, If the values are not correct, there is a fault inside the gearbox. 		
If the fault is still present, contact your Techline.		
AFTER REPAIR	Repeat the conformity check from the start.	



	SHIFT SOLENOID ACTIVATION
AC024	

NOTES	Check the 20A permanent computer feed fuse marked " 15 " in the Protection and Switching Unit. Check the cleanness and condition of the connections. Check the 5A after-ignition computer feed fuse marked " 5H " in the Protection and Switching Unit. Check the cleanness and condition of the connections. Replace them if necessary.
	Zero engine and vehicle speed, selector lever in position " P " or " N ".

If the solenoid valves are not activated, check:

- the gearbox oil level,
- the cleanness and condition of the computer connector and "modular connector",

Repair it	necessary.
-----------	------------

Check the **insulation**, **continuity and absence of stray resistance** on the following connections:

Computer track 1 ——— Modular connector track B3 (+ 12 V)
Computer track 10 — Modular connector track B11 (EVS 1)
Computer track 9 — Modular connector track B8 (EVS 2)
Computer track 7 — Modular connector track B10 (EVS 3)
Computer track 8 — Modular connector track B7 (EVS 4)
Computer track 13 — Modular connector track B5 (EVS 5)
Computer track 14 — Modular connector track B2 (EVS 6)
Computer track 26 — Modular connector track B12 (modulating solenoid valve)
Computer track 20 — Modular connector track B6 (converter lock-up solenoid valve)
Computer track 2 — Modular connector track E2 (exchanger flow control solenoid valve)
Computer track 12 — Modular connector track E1 (exchanger flow control solenoid valve)
Repair if necessary.
If the fault is still present, contact your Techline.

AFTER REPAIR R	Repeat the conformity check from the start.
----------------	---



CLEARING

Before using the delete commands, engine and vehicle speed must be zero and the selector lever must be in position "**P**" or "**N**".

• RZ004 "Clear fault memory"

This command deletes present and stored faults in the automatic transmission computer.

• RZ005 "Self-adapting system"

This command clears the self-adapting systems in the automatic transmission computer.

Doing a road test with the vehicle after running this command is recommended before returning the vehicle to the customer. This is because, after the command, the automatic transmission may occasionally malfunction as the self-adapting systems readjust.

• RZ006 "Converter lock-up self-adapting system"

This command clears the self-adapting systems associated with the converter.

It is recommended to road test the vehicle after running this command before returning the vehicle to the customer. This is because, after the command, the automatic transmission may occasionally malfunction as the converter-related self-adapting systems reset.

• RZ007 "OBD memory"

This command clears the computer's OBD memory.



ALP 1

ALP 2

NOTES

Consult "Customer complaints" only after carrying out a full diagnostic check with the diagnostic tool and completing the conformity check.

NO DIALOGUE WITH THE COMPUTERS

ENGINE STARTING FAULTS

The starter does not operate when the selector lever is in position P or N

 AUTOMATIC TRANSMISSION OPERATING FAULTS
 ALP 3

 No forward and/or reverse drive
 Slow engagement with engine racing followed by a jolt when pulling away

 Reversing lights do not work
 The vehicle pulls away sluggishly

 Jolts, slippage or engine racing when changing gear

 No gear changing, vehicle stuck in one gear

 Missing one or more gears

AUTOMATIC TRANSMISSION MALFUNCTION WHEN CHANGING GEAR ALP 4

ERRATIC GEAR CHANGES A



- ALP 6

- ALP 7

ALP 8

NOTES

Consult "Customer complaints" only after carrying out a full diagnostic check with the diagnostic tool and completing the conformity check.

REVERSING LIGHTS DO NOT WORK

Reverse gear works and the bulbs are OK

OIL PRESENT UNDER THE VEHICLE

SELECTOR LEVER DOES NOT LOCK IN "PARK" POSITION

SELECTOR LEVER STUCK IN "PARK" POSITION (IMPOSSIBLE TO UNLOCK IT BY PRESSING THE BRAKE PEDAL) ALP 9


ALP 1	No dialogue with computers
NOTES	None.
Try the diagnostic tool on another vehicle. Check:	
 The connection between the diagnostic tool and the diagnostic socket (correct connection and lead in good condition). The computer feed. The engine and passenger compartment fuses. 	
Check that the CLIP probe is fed via tracks 16 (+ 12 V) , and 4 and 5 (earth) of the diagnostic socket, as shown by the illumination of the two red warning lights on the probe. Check that the CLIP probe is fed via the computer's USB port. Check that the CLIP probe is communicating with the vehicle's computers; this can be seen by the illumination of the two green diodes on the probe.	
Check the following tracks on the diagnostic socket: track 1 + After ignition track 16 + Battery tracks 4 and 5 - Earth Repair if necessary.	
No communication on line K. Check the continuity, insulation and absence of stray resistance on line K of the diagnostic socket (track 7).	
Disconnect the connector from the climate control computer in order to check the insulation, continuity and absence of stray resistance on the following connections:	
Computer track 27 + After ignition Computer track 56 + Battery Computer track 28 Earth Computer track 18 Diagnostic socket	

AFTER REPAIR Carry out a complete check with the diagnostic tool.	



ALP 2	The starter motor will not operate when the selector lever is in position P or N
-------	--

NOTES	Consult the fault finding charts only after carrying out a full diagnostic check with the diagnostic tool and completing the conformity check.
-------	--

Check the consistency between the diagnostic tool display, the selector lever positions and the gear engaged shown on the instrument panel.

Check the multifunction switch mounting. Check the lever adjustment using the method described in the Technical Note.

Switch off the ignition and disconnect the automatic transmission computer connector. Check that fuse F3 (25 A) is in good condition; replace it if necessary. With the start button pressed, check the presence of + 12 V on track 3 of the PSU.

Check that the start button is operating correctly.

Check the power circuit of the starter relay and the starter motor.

Test the injection system and the UCH.

AFTER REPAIR	Carry out a complete check using the diagnostic tool.



ALP 3 Automatic transmission operating problems

liagnostic check ‹.

Use the diagnostic tool to check the correlation between the display and the selector lever positions (ignition on and engine stopped).
Check the lever adjustment, following the instructions in the Technical Note.
Check the oil level and condition (colour, odour, etc.). If the oil condition suggests an internal problem, replace the automatic transmission.
With the engine stopped, check the line pressure signal supplied by the oil pressure sensor. Replace the sensor if the pressure signal is > 0.2 bar .
 Connect a pressure gauge to the pressure connection on the gearbox casing (check that the oil temperature is more than 20 °C before continuing). Note the line pressure value shown on the pressure gauge and by the diagnostic tool in the following conditions: With the brakes on, selector lever in "D" and engine speed = 1200 rpm. Replace the pressure sensor if the gauge and diagnostic tool readings differ. Repeat the check after replacement.
With the gearbox oil temperature between 60 °C and 90 °C , brakes applied and selector lever in position "D", place a pedal presser or pusher on the accelerator pedal to get a stable reference pressure of approximately 8 bar (engine speed approximately 1300 rpm). Note the pressure gauge and diagnostic tool readings obtained under these conditions, while ensuring that the engine speed remains stable between both readings. These measurements must be carried out quite quickly so that these conditions do not have to be maintained for too long.
Replace the pressure regulating solenoid valve and the oil if the difference between the two readings is more than 0.5 bar . Repeat the check after replacement. If the fault is still present, replace the hydraulic control valve and all the solenoid valves.
Start the engine. With the brakes applied, move the selector lever to position " D " and accelerate, observing the turbine speed signal. If the turbine speed signal changes, replace the gearbox.





ALP 3 CONTINUED		
--------------------	--	--

Refer to the procedure and the safety instructions for carrying out a torque converter stall test. Theoretical engine speed at the stall speed: 2300 ± 150 rpm. If the stall speed value is incorrect, replace the torque converter, converter lock-up solenoid valve, and oil. If the

oil is burnt, also replace the hydraulic control valve and all the solenoid valves.

When replacing the torque converter, ensure that the reaction shaft is securely attached to the hub of the oil pump (swaged shaft).

Note: a stall speed which is too low may be linked to a lack of engine power.

Carry out a road test, observing the engine speed on the instrument panel and the information displayed on the diagnostic tool.

If the engine speed does not vary with each change of gears, replace the hydraulic control valve and all the solenoid valves.

AFTER REPAIR	As a final step, clear the stored faults with command RZ004 "Clear stored faults", the computer self-adapting systems with command RZ005 "Self-adapting system" and the converter self-adapting systems with command RZ006 "Converter lock-up" self-adapting system. Refer to the "Configuration and Programming" section for how to reset the oil ageing counter to zero (enter gearbox oil change date).
--------------	--



ALP 4 Automatic transmission malfunction when changing gears	\$
--	----

NOTES	Consult the fault finding charts only after carrying out a full diagnostic check with the diagnostic tool and completing the conformity check.
-------	--

Automatic transmission gear change malfunction may be observed without any fault being stored in the computer.

These malfunctions may be due to contact resistance faults on the selection and progressive engagement solenoid valve (EVS1 to EVS6) control lines preventing the self-test system from detecting a solenoid valve fault or preventing the solenoid valves from being controlled.

Check the clamping efficiency and condition of the clips on all the solenoid valve control line connections from the computer to the solenoid valve.



AFTER REPAIR Carry out a road test, then do a complete check with the diagnostic tool.



ALP 5	Erratic gear changes

NOTES Consult the fault finding charts only after carrying out a full diagnostic che with the diagnostic tool and completing the conformity check.

Carry out a road test with the CLIP diagnostic tool, and check that status **ET013 "Gear engaged"** is correct.

If the customer complaint occurs when the brake pedal is released, check that status **ET142 "Brake pedal pressed"** really is **NO**.

If not, adjust the brake light switch and brake pedal return spring.

Check that the instrument panel display of the gear engaged matches the selector lever position.

Check the routing of the automatic transmission harness (high voltage interference fault). Change it if necessary.

Check the adjustment of the external control. If the fault persists, replace the multifunction switch.

Carry out a fault finding procedure on the injection system.

Check the **PR006 "Engine speed"** signal during a road test at a steady speed. If the signal is wrong, replace the engine speed sensor.



AFTER REPAIR Carry out a road test, then do a complete check with the diagnostic tool.





ALP 6	Reversing lights do not operate (Scenic II only)										
NOTES	Consult the fault finding charts only after carrying out a full diagnostic check with the diagnostic tool and completing the conformity check.										
Check that the bulbs a Check the condition of Check that the rear lig	rre in good condition. ⁻ the bulb contacts. Repair if necessary. hts earth is correct. Right-hand rear light track 4 and left-hand rear light track 1 .										
Switch off the ignition a Switch the ignition on a Check the condition of PPM2 .	Switch off the ignition and disconnect the modular connector. Switch the ignition on again and check for + after ignition on modular connector track A2 . Check the condition of fuse F5C (10A) in the PSU and the presence of + after ignition on track 6 of connector PPM2 .										
Switch off the ignition a (gearbox side) with the If continuity is not prov If the continuity is okay connector PPM2 .	Switch off the ignition and check the continuity between tracks A1 and A2 of the modular connector (gearbox side) with the selector lever in position " R ". If continuity is not provided, replace the multifunction switch. If the continuity is okay, check the continuity between track A1 of the modular connector and track 9 of PSU connector PPM2 .										
Switch on the ignition. With the selector lever track 9 of PSU right-hand rear left-hand rear l	r in position "R", check the presence of + 12 V on: connector PPH2 r light track 2 light track 3										





Oil present under vehicle

NOTES	Consult the fault finding charts only after carrying out a full diagnostic check with the diagnostic tool and completing the conformity check.
-------	--

Clean the gearbox.

Check the oil level and top up if necessary, following the procedure described in the Workshop Repair Manual.

Find the source of the leak, carry out the necessary repairs, or change the defective parts to stop the leak. Check the oil level.

If there is no gearbox leak, look for a leak on the engine side.

AFTER REPAIR	Carry out a road test, then do a complete check with the diagnostic tool.

23A

Diagnostic - Fault finding charts

ALP 8 Selector lever does not lock in "Park" position

NOTES	Consult the fault finding charts only after carrying out a full diagnostic check with the diagnostic tool and completing the conformity check.
-------	--

If no fault can be identified in the shift-lock electromagnet, check the operation of the stop light switch. Use the interpretation of fault **DF119 "Brake pedal position"** and status **ET003 "Brake light switch"**.

If the customer complaint is still present, look for a mechanical fault on the lever locking mechanism.

ALP 9	Selector lever stuck in "Park" position (unlocking impossible)

Consult the fault finding charts only after carrying out a full diagnostic check NOTES with the diagnostic tool and completing the conformity check.

If no fault can be identified in the shift-lock electromagnet, check the operation of the stop light switch. Use the interpretation of fault **DF119 "Brake pedal position"** and status **ET003 "Brake light switch"**.

If the customer complaint is still present, look for a mechanical fault on the lever locking mechanism.

AFTER REPAIR	Carry out a complete check using the diagnostic tool



1. SCOPE OF THIS DOCUMENT

This document presents the fault finding procedure applicable to all computers with the following specifications:

Vehicle(s): MEGANE II and SCENIC

Function concerned: Automatic transmission

2. PREREQUISITES FOR FAULT FINDING

Documentation type

Fault finding procedures (this manual):

- Assisted fault finding (integrated into the diagnostic tool), Dialogys.
- Wiring Diagrams:

- Visu-Schéma (CD-ROM), paper version.

Type of diagnostic tools

– CLIP

Special tooling required

Special tooling required								
	Multimeter							
Elé. 1681	Universal bornier							

3. RECAP

Procedure

To run fault finding on the vehicle computers, switch on the ignition.

Proceed as follows:

- Connect the diagnostic tool and perform the required operations.

IMPORTANT

Computer supply for the fault finding procedure:

To run fault finding on the vehicle computers, proceed as follows:

- Renault card on the card holder (keyless vehicle scenario 1 (basic, not hands-free) and scenario 2 (top of the range, hands-free)).
- Long press (more than 5 seconds) on Start button without start-up conditions.
- Then connect the diagnostic tool and perform the required operations.

Name of computer: **Siemens TA 2000** Vdiag no.: **14**



Faults

Faults are declared either present or stored (depending on whether they appeared in a certain context and disappeared since, or whether they remain present but have not been diagnosed within the current context).

The **present** or **stored** status of faults should be taken into consideration when the diagnostic tool is switched on after the + after ignition feed (without any system components being active).

For a present fault, apply the procedure described in the Interpretation of faults section.

For a stored fault, note the faults displayed and apply the instructions in the Notes section.

If the fault is **confirmed** when the instructions in the Notes section are applied, the fault is present. Deal with the fault.

If the fault is not confirmed, check:

- the electrical lines which correspond to the fault,
- the connectors for these lines (for oxidation, bent pins, etc.),
- the resistance of the component detected as faulty,
- the condition of the wires (melted or split insulation, wear).

Conformity check

The aim of the conformity check is to check data that does not produce a fault on the diagnostic tool because the data is inconsistent. Therefore, this phase is used to:

- carry out fault finding on faults that do not have a fault display, and which may correspond to a customer complaint,
- check that the system is operating correctly and that there is no risk of a fault recurring after repairs.

This section gives the fault finding procedures for statuses and parameters and the conditions for checking them.

If a status is not behaving normally or a parameter is outside the permitted tolerance values, consult the corresponding fault finding page.

Customer complaints - Fault finding chart

If the test with the diagnostic tool is OK but the customer complaint is still present, the fault should be processed by **customer complaint**.

A synopsis of the general procedure to follow is provided on the following page in the form of a flow chart.



4. FAULT FINDING PROCEDURE





4. FAULT FINDING PROCEDURE (continued)

Wiring check

Fault finding problems

Disconnecting the connectors and/or manipulating the wiring harness may temporarily remove the cause of a fault. Electrical measurements of the voltage, resistance and insulation are generally correct, especially if the fault is not present when analysing (stored fault).

Visual inspection

Look for damage under the bonnet and in the passenger compartment. Carefully check the fuses, insulators and wiring harness routing. Look for signs of oxidation.

Tactile inspection

While manipulating the wiring harness, use the diagnostic tool to note any change in fault status from "stored" or "present".

Make sure that the connectors are correctly locked.

Apply light pressure to the connectors.

Twist the wiring harness.

If there is a change in status, try to locate the source of the fault.

Inspection of each component

Disconnect the connectors and check the appearance of the clips and tabs, as well as the crimping (no crimping on the insulating section).

Make sure that the clips and tabs are correctly locked in the sockets.

Make sure that no clips or tabs have been dislodged during connection.

Check the clip contact pressure using an appropriate model of tab.

Check the continuity/insulation

Check the continuity of entire lines, then section by section. Look for a short circuit to earth, to + 12 V or to another wire.

If a fault is detected, repair or replace the wiring harness.



5. FAULT FINDING LOG



Any fault on a complex system requires thorough fault finding with the appropriate tools. The FAULT FINDING LOG, which should be completed during the procedure, enables you to keep track of the procedure which is carried out. It is an essential document when consulting the manufacturer.

IMPORTANT!

IT IS THEREFORE MANDATORY TO FILL OUT A FAULT FINDING LOG EACH TIME FAULT FINDING IS CARRIED OUT.

You will always be asked for this log:

NOTE

- when requesting technical assistance from the Techline,
- for approval requests when replacing parts for which approval is obligatory,
- to be enclosed when returning monitored parts on request. The log is needed for warranty reimbursement, and enables better analysis of the parts removed.

6. SAFETY ADVICE

Safety rules must be observed during any work on a component to prevent any damage or injury:

- make sure that the battery is properly charged to avoid damaging the computers with a low load,
- use the appropriate tools,
- immobilise the vehicle for all tests in the workshop on the automatic transmission with the engine running.

www.CarGeek.ir FAULT FINDING LOG

System: Automatic or sequential gearbox

Page 1/2

List of monitored parts: Computer

Administrative identification															
Date					2	0									
Log com	pleted by	/				11									
VIN															
Engine												<u> </u>			
Diagnost	ic tool		CLI	<u></u> Р		_ 	ĺ								
Update v	rersion						,								
• Custor	mer com	nplaint													
681	Gears no	ot changing		622	N	oise			Γ	Т	679	No di	ive		
680	Slipping			675	In	Indicator light comes on					682	Loss of power			
683	Jolts or je	erks		684	"3	3H"			Ī		685	Erratic gear change			
Other Your comments:															
Condit	tions un	der which th	e cus	tomer o	com	iplaint oc	curs								
005	While dri	ving		004	In	ntermittently 008 When decelerating									
007 When accelerating 009					Si	dden fault 010 Gra							ual deterio	ration	
Other Your comments:								1							
• Docun	nentatio	n used in fau	ult fin	din <u>g</u>											
				Fau	lt fir	nding pro	cedure	used							
Type of diagnostic manual: Workshop Rep				Repa	air Manua	l 🖬 Te	chnica	al Note	e [a Ase	sisted	fault find	ling (
Fault findi	ng manu	al no.:													
Wiring diagram used															
Wiring Diagram Technical Note no.:															
Other documentation															
Title and/o	or part nu	umber:													
FD 12 Fault finding log															

page to print or photocopy - page to print or photocopy - page to print or photocopy

www.cargeek.ir

FAUMTVF MOING LOG

System: Automatic or sequential gearbox

Computer identification and system parts replaced

Part 1 part no.	
Part 2 part no.	
Part 3 part no.	
Part 4 part no.	
Part 5 part no.	
To be read with the diagnostic tool (Ide	entification screen):
Computer part no.	
Supplier no.	
Program no.	
Software version	
Calibration no.	
VDIAG	

Faults found with the diagnostic tool

Fault no.	Present	Stored	Fault name	Specification

Conditions under which fault occurs

Status or parameter no.	Parameter name	Value	Unit
	5		

System-specific information

Description:

Additional information

Gearbox serial number

If the gearbox is automatic, which mode is it (automatic/sequential)? Gear changes affected? Result of the gearbox oil level check Result of the oil check using "Add-On" Appearance of the oil Oil leak? Location of the leak Type of noise (metallic, friction, etc.) Does the buzzer work?

What factors led you to replace the computer?

What other parts were replaced?

Other defective functions?

Your comments:



FD 12 Fault finding log

Droplets 📮

Page 2/2

Seepage 📮

No 🗖

No 📮

Yes 🗋



GENERAL OPERATION

The automatic transmission on this model is a DP0, which is also found on other Renault vehicles including the Clio II, Kangoo or Megane.

The automatic transmission computer controls gear-shifting based on several parameters, among them engine torque and the type of driving being done.

All signals travel to the computer by wire, except for those from the injection computer, which use the multiplex network.

Fault finding on the computer is carried out via the multiplex network (CAN).

SYSTEM OPERATION

Multifunction switch (CMF) statuses:

Note:

On this vehicle, contact S1 of the multifunction switch depends on **status ET128 "Upper switch on sequential lever"**.

Lover position	Multifunction switch contact			
Lever position	P/N	S2	S3	S4
Р	CLOSED	OPEN	CLOSED	CLOSED
R	CLOSED	OPEN	OPEN	OPEN
Ν	CLOSED	CLOSED	OPEN	CLOSED
D	CLOSED	CLOSED	CLOSED	OPEN
Μ	CLOSED	CLOSED	CLOSED	OPEN
+	CLOSED	CLOSED	CLOSED	OPEN
-	CLOSED	CLOSED	CLOSED	OPEN



Sequential lever switch statuses:

Note:

The vehicle does not have a fixed 3rd (D3).

Lever position	Upper sequential lever contact	Lower sequential lever contact
Р	ACTIVE	ACTIVE
R	ACTIVE	ACTIVE
Ν	ACTIVE	ACTIVE
D	ACTIVE	ACTIVE
М	INACTIVE	INACTIVE
+	INACTIVE	ACTIVE
-	ACTIVE	INACTIVE



Sequence solenoid valve (EVS) statuses:

Lever	Gear	Solenoid valve statuses					
position	engaged	1	2	3	4	5	6
Р	Neutral	INACTIVE	INACTIVE	ACTIVE	INACTIVE	INACTIVE	INACTIVE
R	R	INACTIVE	INACTIVE	INACTIVE	INACTIVE	INACTIVE	INACTIVE
N	Neutral	INACTIVE	INACTIVE	ACTIVE	INACTIVE	INACTIVE	INACTIVE
P or N < - 10 °C	Neutral	INACTIVE	ACTIVE	INACTIVE	INACTIVE	INACTIVE	INACTIVE
D or M stationary or driving	1	INACTIVE	INACTIVE	ACTIVE	ACTIVE	INACTIVE	INACTIVE
D or M stationary or driving	2	INACTIVE	ACTIVE	INACTIVE	ACTIVE	INACTIVE	INACTIVE
D or M While driving	3	INACTIVE	INACTIVE	INACTIVE	INACTIVE	INACTIVE	INACTIVE
D or M While driving	4	ACTIVE	ACTIVE	INACTIVE	INACTIVE	INACTIVE	INACTIVE



MODULAR CONNECTOR



- A Multifunction switch
- B Hydraulic electronic interface
- C Oil pressure sensor
- **D** Turbine speed sensor
- E Exchanger flow lock-up solenoid valve



COMPUTER INPUTS AND OUTPUTS



AUTOMATIC TRANSMISSION



Fault finding - Allocation of computer tracks

Computer track	Description	Track of the sensor
1	Shift solenoid valve power supply	track B3 electric/hydraulic interface
2	Exchanger flow lock-up solenoid valve supply	track 2 exchanger flow lock-up solenoid valve
3	Not used	
4	Gear lever display signal	track 2 gear lever display
5	Not used	
6	Not used	
7	Shift solenoid valve 3 control	track B10 electric/hydraulic interface
8	Shift solenoid valve 4 control	track B7 electric/hydraulic interface
9	Shift solenoid valve 2 control	track B8 electric/hydraulic interface
10	Shift solenoid valve 1 control	track B11 electric/hydraulic interface
11	Gear lever lock control	shift pattern control track B2
12	Exchanger flow lock-up solenoid valve control	track 1 exchanger flow lock-up solenoid valve
13	Shift solenoid valve 5 control	track B5 electric/hydraulic interface
14	Shift solenoid valve 6 control	track B2 electric/hydraulic interface
15	Not used	
16	Brake switch "Open" signal	brake light switch track 3
17	Not used	
18	Diagnostic socket	
19	Lock-up modulating solenoid valve control	track B6 electric/hydraulic interface
20	Oil pressure regulating solenoid valve	track B9 electric/hydraulic interface
21	Not used	
22	Not used	
23	Not used	
24	Pressure sensor feed	pressure sensor track C1
25	Pressure sensor earth	pressure sensor track C3
26	Modulating solenoid valve power supply	track B12 electric/hydraulic interface
27	+ After ignition feed	track 12 of the white 16-track connector in the Protection and Switching Unit
28	Computer earth	
29	Not used	
30	Not used	

AUTOMATIC TRANSMISSION



Fault finding - Allocation of computer tracks

Computer track	Description	Track of the sensor
31	Multifunction switch signal 2	multifunction switch track A10
32	Multifunction switch signal 3	multifunction switch track A11
33	Multifunction switch signal 4	multifunction switch track A12
34	Not used	
35	Not used	
36	Lower one touch switch contact control	track B3 shift pattern control
37	Upper one touch switch contact control	track A3 shift pattern control
38	CAN H2 signal	track A4 injection computer (K9K, F9Q) track K4 injection computer (F4R, K4M)
39	CAN L2 signal	track A3 injection computer (K9K, F9Q) track K3 injection computer (F4R, K4M)
40	Not used	
41	Not used	
42	Multifunction switch earth	multifunction switch track A7
43	Not used	
44	Not used	
45	Turbine speed signal	turbine speed sensor track D1
46	Turbine speed earth	turbine speed sensor track D2
47	Not used	
48	Not used	
49	Not used	
50	Not used	
51	Not used	
52	Not used	
53	Temperature sensor earth	electric/hydraulic interface track B4
54	Temperature sensor signal	electric/hydraulic interface track B1
55	Line pressure signal	pressure sensor track C2
56	+ Battery supply	Protection and Switching Unit white 16-track connector track 8



REPLACING THE COMPUTER

IT IS ESSENTIAL TO CONTACT YOUR TECHLINE BEFORE REPLACING AN AUTOMATIC TRANSMISSION COMPUTER.

If Techline approves the computer replacement, proceed as follows:

- Note the gearbox oil condition meter code in the Identification menu: ID018 "Oil condition meter" and the date of the last gearbox oil service ID017 "Gearbox oil service date".
- Switch off the ignition.
- Replace the computer.
- If necessary, change the computer configuration in the "Write configuration" menu.
- Enter the VIN into the computer with diagnostic tool command VP001 "Write VIN".
- Enter the oil condition meter code from the old automatic transmission computer (found in the Identification menu) using command VP015 "Transfer oil condition meter".
- Enter the gearbox oil change date with command VP016 "Write gearbox oil service date".
- Enter the After-Sales service date with diagnostic tool command VP009 "Write last After-Sales service date".
- Carry out a check with the diagnostic tool, on the identification screen.
- Switch off the ignition.

REPLACING AN AUTOMATIC TRANSMISSION COMPONENT

For replacing other automatic transmission components, see MR 364, Mechanics, 23A, Automatic transmission.



PROGRAMMING

• VP001 "VIN entry":

As it is necessary to enter the VIN each time dialogue is established with the diagnostic tool, it must be programmed into each vehicle computer whenever a computer is replaced.

Programming procedure:

- Connect the diagnostic tool.
- Consult the fault finding procedure for the automatic transmission.
- Select configuration VP001 "VIN entry".
- Enter the VIN.
- Exit fault finding mode.
- Switch off the ignition.
- Wait for the end of Power-latch: over 10 seconds.

• VP009 "Enter last After-Sales operation date":

Every time work is carried out on the automatic transmission in the workshop, enter the date of the operation.

Select command **VP009** "Write last After-Sales operation date" on the diagnostic tool, then use the tool's keypad to enter the date of the operation.

• VP015 "Transfer oil condition meter":

Transfer the oil condition meter code from the old computer. Selecting command **VP015 "Transfer oil condition meter"** at the diagnostic tool, then use the keyboard

to enter the code found on the replaced computer.

• VP016 "Write gearbox oil change date":

Select command VP016 "Write gearbox oil change date" at the diagnostic tool, then use the keyboard to enter the date found on the replaced computer.

* The immobiliser warning light will flash for a few seconds after the ignition is switched off.

AUTOMATIC TRANSMISSION

Fault finding - Fault summary table



Tool fault	Associated DTC	Diagnostic tool title
DF003	0641	Analogue sensor power supply
DF005	0840	Oil pressure sensor circuit
DF009	0705	Multifunction switch prohibited position
DF012	0657	Solenoid valve supply
DF016	0795	Lock-up solenoid valve circuit
DF017	2753	Exchanger flow rate solenoid valve circuit
DF023	0710	Gearbox oil temperature sensor circuit
DF029	0709	Multifunction switch in unstable position
DF036	0775	Pressure regulating solenoid valve circuit
*DF064	0814	Display circuit
DF084	C001	Multiplex network
DF085	0753	"EVS1" Shift solenoid valve circuit
DF086	0758	"EVS2" Shift solenoid valve circuit
DF087	0763	"EVS3" Shift solenoid valve circuit
DF088	0773	"EVS5" Shift solenoid valve circuit
DF089	0768	"EVS4" Shift solenoid valve circuit
DF093	0819	Manual one touch button switch circuit
DF095	1928	Shift lock electromagnet circuit
DF109	D123	Engine torque multiplex signal
DF112	2709	"EVS6" Shift solenoid valve circuit
DF113	0740	Converter lock-up servo control
DF131	0730	Slipping
DF145	D12F	P/N contact pedal position multiplex signal

* All Megane vehicles except Scenic

AUTOMATIC TRANSMISSION

Fault finding - Fault summary table



Tool fault	Associated DTC	Diagnostic tool title
DF147	D122	Invalid anticipated torque multiplex signal
DF177	0218	Automatic transmission overheating
DF183	C140	No UCH multiplex signal
DF185	C121	ABS/ESP absent multiplex signal
DF186	C100	No injection multiplex signal
DF226	0841	Automatic transmission internal pressure
DF227	D403	UCH brake pedal multiplex signal
DF228	D22B	Invalid ABS lateral acceleration multiplex signal
DF229	D208	Invalid ABS brake multiplex signal
DF230	0720	Invalid vehicle speed multiplex signal
DF231	D200	Vehicle speed absent multiplex signal
DF232	0603	Computer
DF233	0604	Computer
DF234	0605	Computer
DF235	D121	Pedal position multiplex signal
DF236	D11F	Invalid engine speed multiplex signal
DF237	D100	Invalid coolant temperature signal
DF238	D12B	Raw engine torque multiplex signal
DF239	D120	Invalid real engine torque multiplex signal
DF240	D220	Invalid front right-hand wheel speed multiplex signal
DF241	D221	Invalid front left-hand wheel speed multiplex signal
DF242	D225	Invalid rear right-hand wheel speed multiplex signal
DF243	D226	Invalid rear left-hand wheel speed multiplex signal
DF244	0715	Turbine speed sensor signal
DF263	D12D	Instant max. torque multiplex signal



55000	ANALOGUE SENSOR	FEEDS	
DF003 PRESENT OR STORED	1.DEF: Voltage outside permitted range of values		
NOTES	Special notes: Use bornier Elé. 1681 for any Customer complaint: deterior	/ work on the computer connectors. ation in gear change shift patterns	
Deal first with faults: DFC circuit". Disconnect the battery. Check the condition an Disconnect the compute Repair if necessary.	005 "Oil pressure sensor circo d cleanliness of the modular c r. Check the cleanliness and c	uit" and DF023 "Gearbox oil temperature sensor onnector connections. condition of the connections.	
Check the insulation, co connections: (see System operation	ontinuity and the absence of in and Allocation of computer t	terference resistance to earth, to + 12 V of the following racks on the "modular connector")	
	Computer track 24 —	Track C1 male modular connector	
	Computer track 25	Track C3 male modular connector	
	Computer track 53	Track B4 male modular connector	
	Computer track 54	Track B1 male modular connector	
check the supply of the Repair if necessary.	e analogue sensors = 5 V		
If the fault is still present	, contact the Techline.		

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
--------------	--



DF005 PRESENT OR STORED	OIL PRESSURE SENSOR CIRCUIT CO.0 : Open circuit or short circuit to earth
	Conditions for applying the fault finding procedure to stored faults: The fault appears after a timed period of 10 seconds with the engine running at

NOTES	The fault appears after a timed period of 10 seconds with the engine running at 2000 rpm .		
	Special notes: Use bornier Elé. 1681 for any work on the computer connectors.		

Disconnect the battery. Disconnect the "modular connector", and check the cleanliness and condition of the connections. Disconnect the computer. Check the cleanliness and condition of the connections. Repair if necessary.			
Check the insulation, continuity and the absence of interference resistance to earth, to + 12 V of the following connection: (see System operation and Allocation of computer tracks on the "modular connector")			
Computer track 24			
With the ignition on, check for + 12 V on track C1 of the oil pressure sensor connector.			
Computer track 55			
Computer track 25			
The voltage on track C1 of the modular connector should be + 5 V. If it is not, check the computer feed. Reconnect the "modular connector". Measure the resistance of the oil pressure sensor between tracks 25 and 55 of the computer connector (female pins). Replace the sensor if the resistance is not approximately 20 k Ω .			
If the fault is still present, contact the Techline.			

AFTER REPAIRDeal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.	
---	--

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF009 PRESENT OR STORED	MULTIFUNCTION SWITCH IN INHIBITOR POSITION
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault is reported present when the selector lever is shifted from " P " to " D " (with a stop at each lever position).

Special notes: Use bornier Elé. 1681 for any work on the computer connectors.

Check the cleanliness, condition and attachment of the multifunction switch. Check the adjustment of the control (see MR 364 Mechanics, 23A, Automatic transmission). Repair if necessary.					
Check the cleanliness and condition of the connector A connections (see System operation and Allocation of computer tracks on the "modular connector").					
Check the continuity of the following connections on the female "modular connector":					
Lever in position "P"					
Modular connector track A10					
Lever in position "R"					
Modular connector track A10					
Modular connector track A11					
Modular connector track A12					
Lever in position "N"					
Modular connector track A11					
Lever in position "D"					
Modular connector track A12 — Track A7 modular connector					
If the continuity is faulty, change the multifunction switch.					

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
DP0TA2000_V14_DF009	



CONTINUED

Check the insulation of the following connections on the "modular connector's" female plug:				
Lever in position "P"				
Modular connector track A9 ——— Track A7 modular connector				
Modular connector track A11 — — Track A7 modular connector				
Modular connector track A12 — Track A7 modular connector				
Lever in position "R"				
Modular connector track A9 — — Track A7 modular connector				
Lever in position "N"				
Modular connector track A9 — — Track A7 modular connector				
Modular connector track A10 — Track A7 modular connector				
Modular connector track A12 — Track A7 modular connector				
Lever in position "D"				
Modular connector track A9 — — Track A7 modular connector				
Modular connector track A10				
Modular connector track A11				
If the insulation is faulty, replace the multifunction switch.				
Check the cleanliness and condition of the connections. Check the insulation, continuity and the absence of interference resistance to earth, to + 12 V of the following connections:				
Computer track 31 — Track A10 male modular connector				
Computer track 32 — Track A11 male modular connector				
Computer track 33 — Track A12 male modular connector				
Computer track 42 — Track A7 male modular connector				
With the ignition on, check for + 12 V on track A2 of the multifunction switch.				
If the fault is still present, contact the Techline.				

AFTER REPAIR Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF012 PRESENT OR STORED	SOLENOID VALVE SUPPLY CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V				
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 "Actuator sequential control".				
	Special notes: Use bornier Elé. 1681 for any work on the computer connectors.				
Disconnect the battery. Disconnect the "modular connector", and check the cleanliness and condition of the connections. Disconnect the computer. Check the cleanliness and condition of the connections. Repair if necessary.					
Check the insulation, continuity and the absence of interference resistance to earth, to + 12 V of the following connections: (see System operation and Allocation of computer tracks on the "modular connector")					
Computer track 1 — Track B3 male modular connector					
Computer track 10					
Computer track 7 Track B10 male modular connector					
	Computer track 9 Track B8 male modular connector				
	Computer track 8				
	Computer track 13				
	Computer track 14				
	Computer track 26				
	Computer track 20				
	Computer track 19				
	Computer track 53				
	Computer track 54				
With the ignition on, check for + 12 V on tracks B12 and B3 of the connector on the electric/hydraulic interface. Check the earth to track B4 of the connector on the electric/hydraulic interface.					

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
DP0TA2000_V14_DF012	



	D	F	0	1	2
--	---	---	---	---	---

CONTINUED

Reconnect the "modular connector".

Measure the **resistance** of shift solenoid valve no. 1 between **tracks 10 and 1** of the computer connector: Replace the solenoid valve or the electric/hydraulic interface wiring if the **resistance** is not **40** $\Omega \pm$ **2 at 20** °C.

If the fault is still present, contact the Techline.

AFTER REPAIRDeal with any other faults. Clear the fault memory.Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.



DF016 PRESENT OR STORED	LOCK-UP SOLENOID VALVE CIRCUIT CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V	
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 "Actuator sequential control". Special notes: Use bornier Elé. 1681 for any work on the computer connectors.	
Disconnect the battery. Disconnect the "modular connector", and check the cleanliness and condition of the connections. Disconnect the computer. Check the cleanliness and condition of the connections. Repair if necessary.		
Check the insulation, continuity and the absence of interference resistance to earth, to + 12 V and the following connections: (see System operation and Allocation of computer tracks on the "modular connector")		
	Computer track 19	
	Computer track 26	
Reconnect the "modular connector". Measure the resistance of the converter lock-up solenoid valve between tracks 19 and 26 of the connector, computer female pins: Replace the solenoid valve or the electric/hydraulic interface wiring if the resistance is not 1 $\Omega \pm$ 0.12 at 23 °C.		
If the fault is still present	, contact the Techline.	

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
--------------	--

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF017 PRESENT OR STORED	EXCHANGER FLOW RATE SOLENOID VALVE CIRCUIT CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V	
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 "Actuator sequential control".	
	Special notes: Use bornier Elé. 1681 for any work on the computer connectors.	
Disconnect the battery. Disconnect the computer. Check the cleanliness and condition of the connections. Disconnect the "modular connector", and check the cleanliness and condition of the connections. Repair if necessary.		
Check the insulation, continuity and the absence of interference resistance to earth, to + 12 V and the following connections: (see System operation and Allocation of computer tracks on the "modular connector")		
	Computer track 12 Track E1 male modular connector	
	Computer track_2	
Reconnect the "modular connector". Measure the resistance of the exchanger flow lock-up solenoid valve between tracks 12 and 2 of the computer female pin connector: Replace the exchanger flow solenoid valve or the wiring if the resistance is not 40 $\Omega \pm$ 4 at 23 °C.		
If the fault is still present	, contact the Techline.	

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
--------------	--



DF023 PRESENT OR STORED	GEARBOX OIL TEMPERATURE SENSOR CIRCUIT CO.0 : Open circuit or short circuit to earth	
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault is declared present after a road test.	
	Special notes: Use bornier Elé. 1681 for any work on the computer connectors.	
Disconnect the battery. Disconnect the "modular connector", and check the cleanliness and condition of the connections. Disconnect the computer. Check the cleanliness and condition of the connections. Repair if necessary.		
Check the insulation, continuity and the absence of interference resistance to earth, to + 12 V and the following connections: (see System operation and Allocation of computer tracks on the "modular connector")		
	Computer track 53 — Frack B4 male modular connector	
	Computer track 54	
Reconnect the "modular connector". Measure the resistance of the oil temperature sensor between tracks 53 and 54 of the computer female pin connector: Replace the sensor or the wiring if the resistance is not between: 2360 Ω and 2660 Ω at 20 °C 290 Ω and 327 Ω at 80 °C		
If the fault is still present, contact the Techline.		
<u> </u>		

AFTER REPAIR Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF029 PRESENT OR STORED	MULTIFUNCTION SWITCH IN UNSTABLE POSITION		
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears when the selector lever is moved from position "P" to position "D" with a stop at each lever position.		
<u>}</u>	Special notes Use bornier Elé. 1681 for any work on the computer connectors.		
Check the cleanliness, condition and attachment of the multifunction switch. Check the adjustment of the control (see MR 364 Megane Bodywork, 23A Automatic transmission). Repair if necessary.			
Disconnect the battery. Disconnect the "modular connector" and check the cleanliness and condition of the connector "A" connections. (see System operation and Track assignments on the "modular connector") Check the continuity of the following connections on the "modular connector's" female plug:			
Lever in position "P"			
Modular connector track A10			

	modulal connector track Alo		Hack Al modulal connector	
Lever in position "R"				
	Modular connector track A10		Track A7 modular connector	
	Modular connector track A11		Track A7 modular connector	
	Modular connector track A12	\rightarrow	Track A7 modular connector	
Lever in position "N"				
	Modular connector track A11	>	Track A7 modular connector	
Lever in position "D"				
	Modular connector track A12	>	Track A7 modular connector	

If the continuity is faulty, change the multifunction switch.

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
DP0TA2000_V14_DF029	



DF029 CONTINUED	
Check the insulation of	the following connections on the "modular connector's" female plug:

Lever in position "P"			
Modular connector track A9 ——— Track A7 modular connector			
Modular connector track A11 ——— Track A7 modular connector			
Modular connector track A12 — Track A7 modular connector			
Lever in position "R"			
Modular connector track A9 — — Track A7 modular connector			
Lever in position "N"			
Modular connector track A9 — — Track A7 modular connector			
Modular connector track A10 — — Track A7 modular connector			
Modular connector track A12 — Track A7 modular connector			
Lever in position "D"			
Modular connector track A9 — — Track A7 modular connector			
Modular connector track A10			
If the insulation is faulty, replace the multifunction switch.			
Disconnect the computer. Check the cleanliness and condition of the connections. Check the insulation, continuity and the absence of interference resistance to earth, to + 12 V and the following connections:			
Computer track 31 — Frack A10 male modular connector			
Computer track 32 — Track A11 male modular connector			
Computer track 33 — Track A12 male modular connector			
Computer track 42 — Track A7 male modular connector			
If the values are not correct, move the wiring about while taking the measurements again. If the values are still incorrect, replace the modular connector.			
If the fault is still present, contact the Techline.			

AFTER REPAIR Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF036 PRESENT OR STORED	PRESSURE REGULATING SOLENOID VALVE CIRCUIT CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V	
	Conditions for applying the fault finding procedure to stored faults:	

NOTES			
	Special notes: Use bornier Elé. 1681 for any work on the computer connectors.		
CO.0	NOTES	None	

Disconnect the battery. Disconnect the "modular connector", and check the cleanliness and condition of the connections. Disconnect the computer. Check the cleanliness and condition of the connections. Repair if necessary.			
Check the insulation, continuity and the absence of interference resistance to earth, to + 12 V and the following connections: (see System operation and track assignments on the "modular connector")			
Computer track 20	ack B9 male modular connector		
Computer track 26	ack B12 male modular connector		
Repair if necessary.			
Measure the resistance of the converter lock-up solenoid valve between tracks B9 and B12 of the female "modular connector":			

Replace the solenoid value or the electric/hydraulic interface wiring if the resistance is not 1 $\Omega \pm$ 0.2 at 23 °C.

CC.1	NOTES	None	

Check the temperature sensor supply between **track 54 of the computer and track B1** of the electric/hydraulic interface.

Check the lock-up solenoid valve supply between **track 26 of the computer and track B12** of the electric/ hydraulic interface.

If the fault is still present, contact the Techline.

AFTER REPAIRDeal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF064 PRESENT OR STORED	DISPLAY CIRCUIT CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V		
NOTES	None		
Disconnect the battery. Check the cleanliness and condition of the gear lever display connections.			
Disconnect the computer. Check the cleanliness and condition of the connections. Use the "Universal bornier Elé. 1681 " to check the insulation, continuity and absence of interference resistance on the following connection:			
	Computer track 4 ——— Track 2 Gear lever display		
Repair if necessary.			
If the fault is still present, contact the Techline.			

AFTER REPAIRDeal with any other faults. Clear the fault memory.Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.



DF084 PRESENT OR STORED	MULTIPLEX NETWORK 1.DEF: Carry out the multiplex network fault finding procedure

NOTES

None

Run a multiplex network test (see 88B, Multiplexing).

If the fault is still present, contact the Techline.

AFTER REPAIRDeal with any other faults. Clear the fault memory.
Switch off the ignition and carry out a road test followed by a check with the diagnostic
tool.

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF085 PRESENT OR STORED	<u>"EVS1" SHIFT SOLENOID VALVE CIRCUIT</u> CC.0 : Short circuit to earth CO : Open circuit CC.1 : Short circuit to + 12 V

	Deal with fault DF012 "Solenoid valves feed" first if it is present or stored.
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 "Actuator sequential control".
La la	Special notes: Use bornier Elé. 1681 for any work on the computer connectors.

Disconnect the battery. Disconnect the "modular connector", and check the cleanliness and condition of the connections. Disconnect the computer. Check the cleanliness and condition of the connections. Repair if necessary.	
Check the insulation, continuity and the absence of interference resistance to earth, to + 12 V and the following connections: (see System operation and Allocation of computer tracks on the "modular connector")	
Computer track 10	
Computer track 1	
Repair if necessary.	
Reconnect the "modular connector". Measure the resistance of the shift solenoid valve no. 1 between tracks 10 and 1 of the computer connector: (which corresponds to track B3 and B11 of the connector, female pins). Replace the solenoid valve or the electric/hydraulic interface wiring if the resistance is not 40 $\Omega \pm$ 2 at 23 °C.	
If the fault is still present, contact the Techline.	

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
--------------	--

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF086 PRESENT OR STORED	<u>"EVS2" SHIFT SOLENOID VALVE CIRCUIT</u> CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V
NOTES	Deal with fault DF012 "Solenoid valves feed" first if it is present or stored. Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 "Actuator sequential control" .

Use bornier Elé. 1681 for any work on the computer connectors.

Disconnect the battery. Disconnect the "modular connector", and check the cleanliness and condition of the connections. Disconnect the computer. Check the cleanliness and condition of the connections. Repair if necessary.	
Check the insulation, continuity and the absence of interference resistance on the following connections: (see System operation and Allocation of computer tracks on the "modular connector")	
Computer track 9 — Track B8 male modular connector	
Computer track 1	
Repair if necessary.	
Reconnect the "modular connector". Measure the resistance of the shift solenoid no. 2 valve between tracks 9 and 1 of the computer connector: (which corresponds to track B3 and B8 of the connector, female pins). Replace the solenoid valve or the electric/hydraulic interface wiring if the resistance is not 40 $\Omega \pm$ 2 at 23 °C.	
If the foult is still present, contact the Tashling	

If the fault is still present, contact the Techline.

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
--------------	--

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF087 PRESENT OR STORED	<u>"EVS3" SHIFT SOLENOID VALVE CIRCUIT</u> CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V
NOTES	Deal with fault DF012 "Solenoid valves feed" first if it is present or stored. Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 "Actuator sequential control" .

Use bornier Elé. 1681 for any work on the computer connectors.

Disconnect the battery. Disconnect the "modular connector", and check the cleanliness and condition of the connections. Disconnect the computer. Check the cleanliness and condition of the connections. Repair if necessary.	
Check the insulation, continuity and the absence of interference resistance on the following connections: (see System operation and Allocation of computer tracks on the "modular connector")	
Computer track 1	
Computer track 7	
Repair if necessary.	
Reconnect the "modular connector". Measure the resistance of the shift solenoid valve no. 3 between tracks 1 and 7 of the computer connector: (which corresponds to track B3 and B10 of the connector, female pins). Replace the solenoid valve or the electric/hydraulic interface wiring if the resistance is not 40 $\Omega \pm$ 2 at 23 °C.	
If the fault is still present, contact the Techline.	

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
--------------	--

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF088 PRESENT OR STORED	<u>"EVS5" SHIFT SOLENOID VALVE CIRCUIT</u> CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V
NOTES	Deal with fault DF012 "Solenoid valves feed" first if it is present or stored. Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 "Actuator sequential control" .
	Special notes: Use bornier Elé. 1681 for any work on the computer connectors.

Disconnect the battery. Disconnect the "modular connector", and check the cleanliness and condition of the connections. Disconnect the computer. Check the cleanliness and condition of the connections. Repair if necessary.		
Check the insulation, continuity and the absence of interference resistance on the following connections: (see System operation and Allocation of computer tracks on the "modular connector")		
Computer track 1 — Track B3 male modular connector		
Computer track 13		
Repair if necessary.		
Reconnect the "modular connector". Measure the resistance of the shift solenoid valve no. 5 between tracks 1 and 13 of the computer connector: (which corresponds to track B3 and B5 of the connector, female pins). Replace the solenoid valve or the electric/hydraulic interface wiring if the resistance is not 40 $\Omega \pm$ 2 at 23 °C.		
If the fault is still present, contact the Taphling		

If the fault is still present, contact the Techline.

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
--------------	--

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF089 PRESENT OR STORED	<u>"EVS4" SHIFT SOLENOID VALVE CIRCUIT</u> CC.0 : Short circuit to earth CO : Open circuit CC.1 : Short circuit to + 12 V	
NOTES	Deal with fault DF012 "Solenoid valves feed" first if it is present or stored. Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 "Actuator sequential control" .	
<u>}</u>	Special notes: Use bornier Elé. 1681 for any work on the computer connectors.	
Disconnect the battery. Disconnect the "modular connector", and check the cleanliness and condition of the connections. Disconnect the computer. Check the cleanliness and condition of the connections. Repair if necessary.		
Check the insulation, c (see System operation	ontinuity and the absence of interference resistance on the following connections: and Allocation of computer tracks on the "modular connector")	
	Computer track 1 track B3 male modular connector	
	Computer track 8	
Repair if necessary.		
Reconnect the "modular Measure the resistance corresponds to track B3 Replace the solenoid va	connector". of the shift solenoid valve no. 4 between tracks 8 and 1 of the computer connector: (which and B7 of the connector, female pins). Ive or the electric/hydraulic interface wiring if the resistance is not 40 $\Omega \pm$ 2 at 23 ° C .	
If the fault is still present	, contact the Techline.	

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
--------------	--

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF093 PRESENT OR STORED	ONE-TOUCH MANUAL CONTROL CIRCUIT 1.DEF: Signal inconsistency CC.0 : Short circuit to earth

NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears during a road test when selecting position "M" with the lever (one-touch control).
	Special notes: Use bornier Elé. 1681 for any work on the computer connectors.

Disconnect the battery. Disconnect the "modular connector", and check the Disconnect the computer. Check the cleanliness a Repair if necessary.	e cleanliness and condition of the connections. and condition of the connections.
Check the insulation, continuity and the absence of interference resistance on the following connections:	
Computer track 36	Track B3 one-touch switch module
Computer track 37	Track A3 one-touch switch module
Computer track 11	Track B2 one-touch switch module
Battery earth	Track A2 one-touch switch module
Repair if necessary.	
If the fault is still present, contact the Techline.	

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
--------------	--



DF095 PRESENT OR STORED	SELECTOR LEVER LOCK ELECTROMAGNET CIRCUIT CO : Open circuit CC.1 : Short circuit to + 12 V	
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears when the selector lever is in position "P".	
	Special notes: Use bornier Elé. 1681 for any work on the computer connectors.	
Check the cleanliness a	and condition of the gear lever lock electromagnet connections.	
 With the ignition on, check for + 12 V in track B1 of the gear lever lock electromagnet connector. Disconnect the battery. Check fuse 5F in the Protection and Switching Unit, as well as the cleanliness and condition of the connections. Disconnect connector PPH2 in the Protection and Switching Unit. Check the cleanliness and condition of the connections. Use the "Universal bornier Elé. 1681". To check the insulation to earth and the continuity of the following connection: Protection and Switching Unit Lever lock electromagnet track B1 connector PPH2 track 11 		
With the ignition on, if there is still no + 12 V on track B1 of the lever lock electromagnet connector, carry out Protection and Switching Unit fault finding.		
Disconnect the battery. Disconnect the computer. Check the cleanliness and condition of the connections. Take "Universal bornier Elé. 1681 ". Check the insulation and continuity of the following connection:		
	Computer track 11	
Repair if necessary.		
Check gear lever lock electromagnet resistance between track 11 of the computer connector and track 11 of the Protection and Switching Unit connector PPH2 . The resistance should be 40 $\Omega \pm 4 \Omega$ at a temperature of approximately 23 °C. Otherwise replace the gear lever lock electromagnet.		
If the fault is still present	, contact the Techline.	

AFTER REPAIRDeal with any other faults. Clear the fault memory.Switch off the ignition and carry out a road test followed by a check with the diagnostictool		AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
--	--	--------------	--

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF109 PRESENT OR STORED	ENGINE TORQUE MULTIPLEX SIGNAL 1.DEF : Multiplex frames absent or values invalid (fault with the computer generating the signal or CAN connection fault)

NOTES

None

Run a multiplex network test (see 88B, Multiplexing).

If the fault is still present, carry out fault finding on the injection system (see **17B**, **Petrol injection** or **13B**, **Diesel injection**).

If the fault is still present, contact the Techline.

AFTER REPAIRDeal with any other faults. Clear the fault memory.Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF112 PRESENT OR STORED	<u>"EVS6" SHIFT SOLENOID VALVE CIRCUIT</u> CO.0 : Open circuit or short circuit to earth CC.1 : Short circuit to + 12 V
	Deal with fault DF012 "Solenoid valves feed" first if it is present or stored. Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 "Actuator sequential control"

NOTES	The fault appears after running command AC024 "Actuator sequential control".
	Special notes: Use bornier Elé. 1681 for any work on the computer connectors.

Disconnect the battery. Disconnect the "modular of Disconnect the computer. Repair if necessary.	connector", and check the cle a Check the cleanliness and c	anline onditi	ess ior	a and condition of the connections. n of the connections.
Check the insulation, co following connections: (see System operation a	ntinuity and the absence of nd Allocation of computer to	interfe racks,	ere	ence resistance to earth, to + 12 V and the nodular connector" connections)
	Computer track 1 —			Track B3 male modular connector
	Computer track 14 —			Track B2 male modular connector
Repair if necessary.				
Reconnect the "modular c Measure the resistance of (which corresponds to trac Replace the solenoid value	onnector". of the shift solenoid valve no. 6 ck B2 and B3 of the connector e or the electric/hydraulic inter	6 betw , fema face v	ree ale wiri	n tracks 14 and 1 of the computer connector: pins). ng if the resistance is not 40 $\Omega \pm$ 2 at 23 °C.
If the fault is still present, o	contact the Techline.			

AFTER REPAIR Deal wi Switch o tool.	th any other faults. Clear the fault memory. off the ignition and carry out a road test followed by a check with the diagnostic



DF113 PRESENT OR STORED	CONVERTER LOCK-UP SERVO CONTROL

	Conditions for applying the fault finding procedure to stored faults: The fault appears after running command AC024 "Actuator sequential control".
NOTES	 If the following faults are present or stored, deal with them first: DF003 "Analogue sensor feeds". DF005 "Oil pressure sensor circuit". DF016 "Lock-up solenoid valve circuit". DF177 "Automatic transmission overheating". DF226 "Automatic transmission internal pressure". DF244 "Turbine speed sensor signal".

Check the quality and oil level of the gearbox (see MR 364 Mechanics 23A, Automatic transmission, Fill-up oil level).

Make sure that the gearbox is not leaking oil.

Check the converter setting point (see MR 364 Mechanics, 23A, Automatic transmission, Converter setting point check).

With the engine running, check the behaviour of **PR006 "Engine speed"** and **PR007 "Turbine speed"**. If the fault is still present, check conformity.

Set up the pressure gauge for a line pressure reading.

Hot engine and gearbox oil temperature between 60 and 80 °C.

Take the line pressure readings under the following conditions:

NOTE

The vehicle must be stationary: handbrake on and brake pedal depressed.

- gear lever at "P" or "N" and engine running at 2000 rpm: the pressure should be between 2.6 and 3.2 bar,
- gear lever at "R" and engine running at 2000 rpm: the pressure should be above 4 bar,
- gear lever at "D" and engine running at 2000 rpm: the pressure in first gear should be above 7 bar.

If the values are not correct, contact the Techline.

AFTER REPAIRDeal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.



DF131 PRESENT OR STORED	SLIPPAGE 1.DEF: Permanent low level
NOTES	Deal with all other faults first. Conditions for applying the fault finding procedure to stored faults: Safe mode is triggered after a fault, not by the driver.
In particular, check the absence of faults on: - the turbine speed sensor, DF244 "Turbine speed sensor signal" , - the vehicle speed signal, DF230 "Invalid vehicle speed multiplex signal" . Check that the value of PR003 oil pressure is equal to 31 bar (forced setpoint). Possible faulty components: Slave cylinder (brakes, clutch) or computer. Then check cleanliness and condition of the gearbox oil.	
Possible faulty components: Slave cylinder (brakes, clutch) or computer. Then check cleanliness and condition of the gearbox oil. If the fault is still present, contact the Techline.	

6	

AFTER REPAIRDeal with any other faults. Clear the fault memory.Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.



DF145 PRESENT OR STORED	INVALID PEDAL POSITION MULTIPLEX SIGNAL 1.DEF : Multiplex frames absent or values invalid (fault with the computer generating the signal or CAN connection fault)		
NOTES	Conditions for applying the fault finding procedure to stored faults: If the fault appears following a road test during which the quality of the gear changes deteriorates.		
Disconnect the battery.			
Disconnect the gearbox	computer. Check the cleanliness and condition of the connections.		
If the fault is still present	, run fault finding on the injection system (see 17B, Petrol injection or 13B, Diesel		
injection). Repair if necessary.			
Run a multiplex netwo	Run a multiplex network test (see 88B, Multiplexing).		
If the fault is still present, contact the Techline.			



AFTER REPAIRDeal with any other faults. Clear the fault memory.
Switch off the ignition and carry out a road test followed by a check with the diagnostic
tool.

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF147 PRESENT OR STORED	INVALID ANTICIPATED TORQUE MULTIPLEX SIGNAL 1.DEF : Multiplex frames absent or values invalid (fault with the computer generating the signal or CAN connection fault)

NOTES

None

Run a multiplex network test (see 88B, Multiplexing).

If the fault is still present, contact the Techline.

AFTER REPAIRDeal with any other faults. Clear the fault memory.
Switch off the ignition and carry out a road test followed by a check with the diagnostic
tool.

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF177 PRESENT OR STORED	AUTOMATIC TRANSMISSION OVERHEATING
	If the following faults are present or stored, deal with them first: – DF003 "Analogue sensor feeds". – DF005 "Oil pressure sensor circuit". – DF016 "Lock-up solenoid valve circuit".

NOTES	 DF017 "Exchanger flow solenoid valve circuit". DF023 "Gearbox oil temperature sensor circuit". DF036 "Pressure regulating solenoid valve circuit". DF131 "Slipping". DF226 "Automatic transmission internal pressure". DF237 "Invalid coolant temperature signal". Conditions for applying the fault finding procedure to stored faults: The fault is declared present after a road test.
-------	---

Check gearbox oil quality and level.

If a procedure is required (see MR 366 Megane 2, 23A, Automatic transmission, Filling and top-up). Make sure that the water-oil exchanger is not blocked. Check the oil temperature sensor resistance of track 53 to track 54, the resistance should be: $2660 \Omega < R < 2360 \Omega$ at 20 °C and 327 $\Omega < R < 290 \Omega$ at 80 °C

If the fault is still present, contact the Techline.

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
--------------	--



DF183 PRESENT OR STORED	UCH MULTIPLEX SIGNAL ABSENT 1.DEF: Carry out the multiplex network fault finding procedure
NOTES	None

If the fault is still present, carry out fault finding on the UCH system (see 87B, Passenger compartment connection unit).

AFTER REPAIRDeal with any other faults. Clear the fault memory.Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.



DF185 PRESENT OR STORED	ABS/ESP MULTIPLEX SIGNAL ABSENT 1.DEF: Carry out the multiplex network fault finding procedure
NOTES	None

If the fault has not been resolved, carry out fault finding on the system (see 38C, ABS system). A priace i.

If the fault is still present, contact the Techline.

Deal with any other faults. Clear the fault memory. AFTER REPAIR Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.



DF186 PRESENT OR STORED	NO INJECTION MULTIPLEX SIGNAL 1.DEF: Carry out the multiplex network fault finding procedure
NOTES	None

If the fault is still present, carry out fault finding on the **injection** system (see **17B**, **Petrol injection** or **13B**, **Diesel injection**).

If the fault is still present, contact the Techline.

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.



DF226 PRESENT OR STORED	AUTOMATIC TRANSMISSION INTERNAL PRESSURE

NOTES	 If the following faults are present or stored, deal with them first: DF003 "Sensor feeds". DF005 "Oil pressure sensor circuit". DF023 "Gearbox oil temperature sensor circuit". DF036 "Pressure regulating solenoid valve circuit". DF244 "Turbine speed sensor signal". Conditions for applying the fault finding procedure to stored faults: The fault is declared present after a road test.

See the section "Measuring the line pressure" in the Repair Manual.

Set up the pressure gauge for a line pressure reading.

Hot engine and gearbox oil temperature between 60 and 80 °C.

Take the line pressure readings under the following conditions:

NOTE

The vehicle must be stationary: handbrake on and brake pedal depressed.

with the selector lever at "P" or "N" and engine speed at 2000 rpm the pressure must be between 2.6 and 3.2 bar.

- with the selector lever at "R" and engine speed at 2000 rpm the pressure must be greater than 4 bar.

- with the selector lever at "D" and engine speed at 2000 rpm the pressure in first gear must be greater than 7 bar. If the fault has not been resolved, check the conformity of all the statuses and parameters to find the source of the fault.

If the fault is still present, contact the Techline.

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
--------------	--

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DE007	INVALID UCH BRAKE PEDAL MULTIPLEX SIGNAL
DF227 PRESENT OR STORED	1.DEF : Multiplex frames absent or values invalid (fault with the computer generating the signal or CAN connection fault)

NOTES

None

Run a multiplex network test (see 88B, Multiplexing).

If the problem is not resolved, carry out fault finding on the UCH system (see 87B, Passenger compartment connection unit).

If the fault is still present, contact the Techline.

AFTER REPAIRDeal with any other faults. Clear the fault memory.Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.

NOTES



DF228 PRESENT OR STORED	INVALID ABS LATERAL ACCELERATION MULTIPLEX SIGNAL 1.DEF : Multiplex frames absent or values invalid (fault with the computer generating the signal or CAN connection fault)
	- invalid ABS lateral acceleration multiplex signal:

Signal sent as multiplex frames by the ABS computer to the automatic transmission
computer to tell it whether the vehicle is tending to drift out (understeer).

Run a multiplex network test (see 88B, Multiplexing).

If the fault is still present, carry out fault finding on the system (see 38C, ABS system).

4

If the fault is still present, contact the Techline.

Deal with any other faults. Clear the fault memory. AFTER REPAIR Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF229 PRESENT OR STORED	INVALID ABS BRAKE MULTIPLEX SIGNALS 1.DEF : Multiplex frames absent or values invalid (fault with the computer generating the signal or CAN connection fault)

NOTES

None

Run a multiplex network test (see 88B, Multiplexing).

If the fault is still present, carry out fault finding on the system (see 38C, ABS system). <u>β</u><u>ntact t.</u>

If the fault is still present, contact the Techline.

Deal with any other faults. Clear the fault memory. AFTER REPAIR Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.



DF230 PRESENT OR STORED	INVALID INVALID VEHICLE SPEED MULTIPLEX SIGNAL 1.DEF: Signal incoherence

	If the following faults are present or stored, deal with them first: – DF240 "Invalid front right-hand wheel speed multiplex signal".
NOTES	 DF241 "Invalid front left-hand wheel speed multiplex signal". DF242 "Invalid rear right-hand wheel speed multiplex signal". DF243 "Invalid rear left-hand wheel speed multiplex signal".

Run a multiplex network test (see MR 366 Megane 8, 88B, Multiplexing).

If the fault has not been resolved, carry out fault finding on the system (see 38C, ABS system).

If the fault is still present, contact the Techline.

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
--------------	--



DF231 PRESENT OR STORED	ABSENT VEHICLE SPEED MULTIPLEX SIGNAL 1.DEF: Carry out the multiplex network fault finding procedure

	If the following faults are present or stored, deal with them first: – DE240 "Invalid front right-hand wheel speed multiplex signal"
NOTES	 DF241 "Invalid front left-hand wheel speed multiplex signal".
	 DF242 "Invalid rear right-hand wheel speed multiplex signal".
	 DF243 "Invalid rear left-hand wheel speed multiplex signal".

Run a multiplex network test (see 88B, Multiplexing).

If the fault has not been resolved, carry out fault finding on the system (see 38C, ABS system).

If the fault is still present, contact the Techline.

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
	tool.



DF232 PRESENT OR STORED	COMPUTER 1.DEF: Internal electronic fault
NOTES	Special note: The fault relates to an internal computer fault.
If the fault is stored , cle Switch off the ignition, w	ar the fault from the computer memory. ait until the end of power latch* then switch the ignition back on and re-establish dialogue:

Check the computer supply and earth: - + 12 V on track 27 of the computer,

- the earth track 28 of the computer.

If the fault is still present, contact the Techline.

* The immobiliser warning light will flash for a few seconds after the ignition is switched off.

AFTER REPAIRDeal with any other faults. Clear the fault memory.
Switch off the ignition and carry out a road test followed by a check with the diagnostic
tool.



DF233 PRESENT OR STORED	<u>COMPUTER</u>
	1
NOTES	Special note: The fault relates to an internal computer fault.
If the fault is stored , cle	ar the fault from the computer memory.
Switch off the ignition, w	rait until the end of power latch* then switch the ignition back on and re-establish dialogue:
Check the computer su	oply and earth:
- + 12 V on track 27 of	the computer,
I – the earth track 28 of t	he computer.

If the fault is still present, contact the Techline.

* The immobiliser warning light will flash for a few seconds after the ignition is switched off.

AFTER REPAIRDeal with any other faults. Clear the fault memory.Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.



DF234 PRESENT OR STORED	<u>COMPUTER</u>
NOTES	Special note: The fault relates to an internal computer fault.
If the fault is stored , cle	ar the fault from the computer memory.
Switch off the ignition, w	ait until the end of power latch* then switch the ignition back on and re-establish dialogue:
Check the computer sup	oply and earth:
– + 12 V on track 27 of	the computer,
– the earth track 28 of t	he computer.

If the fault is still present, contact the Techline.

* The immobiliser warning light will flash for a few seconds after the ignition is switched off.

AFTER REPAIRDeal with any other faults. Clear the fault memory.
Switch off the ignition and carry out a road test followed by a check with the diagnostic
tool.



DF235 PRESENT OR STORED	INVALID PEDAL POSITION MULTIPLEX SIGNAL 1.DEF : Multiplex frames absent or values invalid (fault with the computer generating the signal or CAN connection fault)
----------------------------------	---

If the fault is still present, carry out fault finding on **injection** system (see **17B**, **Petrol injection** or **13B**, **Diesel injection**).

If the fault is still present, contact the Techline.

Kickdown: instant power request by suddenly pressing the accelerator pedal down hard.

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic
	tool.

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF236 PRESENT OR STORED	INVALID ENGINE SPEED MULTIPLEX SIGNAL
	1.DEF : Multiplex frames absent or values invalid (fault with the computer generating the signal or CAN connection fault)

NOTES

None

Run a multiplex network test (see 88B, Multiplexing).

If the fault is still present, carry out fault finding on **injection** system (see **17B**, **Petrol injection** or **13B**, **Diesel injection**).

If the fault is still present, contact the Techline.

AFTER REPAIRDeal with any other faults. Clear the fault memory.Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF237 PRESENT OR STORED	INVALID COOLANT TEMPERATURE SIGNAL
	1.DEF : Multiplex frames absent or values invalid (fault with the computer generating the signal or CAN connection fault)

NOTES

None

Run a multiplex network test (see MR 366 Megane 8, 88B, Multiplexing).

If the fault is still present, carry out fault finding on **injection** system (see **17B**, **Petrol injection** or **13B**, **Diesel injection**).

If the fault is still present, contact the Techline.

AFTER REPAIRDeal with any other faults. Clear the fault memory.Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF238 PRESENT OR STORED	INVALID RAW ENGINE TORQUE MULTIPLEX SIGNAL 1.DEF : Multiplex frames absent or values invalid (fault with the computer generating the signal or CAN connection fault)

NOTES

None

Run a multiplex network test (see 88B, Multiplexing).

If the fault is still present, carry out fault finding on the injection system (see **17B**, **Petrol injection** or **13B**, **Diesel injection**).

If the fault is still present, contact the Techline.

AFTER REPAIRDeal with any other faults. Clear the fault memory.
Switch off the ignition and carry out a road test followed by a check with the diagnostic
tool.

AUTOMATIC TRANSMISSION Fault finding - Interpretation of faults



DF239 PRESENT OR STORED	INVALID REAL ENGINE TORQUE MULTIPLEX SIGNAL 1.DEF : Multiplex frames absent or values invalid (fault with the computer generating the signal or CAN connection fault)

NOTES

None

Run a multiplex network test (see 88B, Multiplexing).

If the fault is still present, carry out fault finding on the injection system (see **17B**, **Petrol injection** or **13B**, **Diesel injection**).

If the fault is still present, contact the Techline.

AFTER REPAIRDeal with any other faults. Clear the fault memory.Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.


DF240 PRESENT	INVALID FRONT RIGHT-HAND WHEEL SPEED MULTIPLEX
	SIGNAL
OR STORED	1.DEF : Multiplex frames absent or values invalid (fault with the computer generating the signal or CAN connection fault)

NOTES	Front right-hand front wheel speed signal for the automatic transmission computer.
NOTES	Front right-hand front wheel speed signal for the automatic transmission computer.

Run a multiplex network test (see 88B, Multiplexing).

If the fault has not been resolved, carry out fault finding on the system (see 38C, ABS system).

If the fault is still present, contact the Techline.

Deal with any other faults. Clear the fault memory. AFTER REPAIR Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.



DF241 PRESENT OR STORED DF241 I.DEF : Multiplex frames absent or values invalid (fault with the computer generating the signal or CAN connection fault)	<u>AL</u>
--	-----------

NOTES	Front left-hand wl

neel speed signal for the automatic transmission computer.

Run a multiplex network test (see 88B, Multiplexing).

If the fault has not been resolved, carry out fault finding on the system (see 38C, ABS system).

If the fault is still present, contact the Techline.

Deal with any other faults. Clear the fault memory. AFTER REPAIR Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.



DF242 PRESENT INVALID REAR RIGHT-HAND WHEEL SPEED MULTIPLEX SIGNAL 1.DEF : Multiplex frames absent or values invalid (fault with the computer generating the signal or CAN connection fault)	<u>NAL</u>
--	------------

ar right-hand wheel speed signal for the automatic transmission computer.

Run a multiplex network test (see 88B, Multiplexing).

If the fault has not been resolved, carry out fault finding on the system (see 38C, ABS system). Intact

If the fault is still present, contact the Techline.

Deal with any other faults. Clear the fault memory. AFTER REPAIR Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.



DF243 PRESENT OR STORED	REAR LEFT-HAND WHEEL SPEED MULTIPLEX SIGNAL ultiplex frames absent or values invalid (fault with the computer enerating the signal or CAN connection fault)
----------------------------------	---

NOTES

Rear left-hand wheel speed signal for the automatic transmission computer.

Run a multiplex network test (see 88B, Multiplexing).

If the fault has not been resolved, carry out fault finding on the system (see 38C, ABS system).

If the fault is still present, contact the Techline.

Deal with any other faults. Clear the fault memory. AFTER REPAIR Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.

SIEMENS TA2000 Vdiag no.: 14



DF244 PRESENT OR STORED	TURBINE SPEED SENSOR SIGNAL 1.DEF: Communication disrupted 2.DEF: No signal
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault appears when the engine is running and the selector lever is at "P".
	Special notes: Use bornier Elé. 1681 for any work on the computer connectors.
Disconnect the battery. Disconnect the "modular connector" and check the cleanliness and condition of the connections. Disconnect the computer. Check the cleanliness and condition of the connections. Repair if necessary.	
Check the insulation, continuity and the absence of interference resistance to earth, to + 12 V and the following connections: (see System operation and Allocation of computer tracks on the modular connector)	
	Computer track 45 — Male modular connector track D1
	Computer track 46 All Male modular connector track D2
Repair if necessary.	
Reconnect the "modular connector". Measure the resistance of the turbine speed sensor between tracks 45 and 46 of the computer connector: Replace the sensor or the wiring if the resistance is not: 300 $\Omega \pm$ 40 Ω .	
If the fault is still present, contact the Techline.	

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
--------------	--



DF263 PRESENT OR STORED DF263 PRESENT OR STORED DF263 I.DEF : Multiplex frames absent or values invalid (fault with the computer generating the signal or CAN connection fault)	
---	--

NOTES In	nstant maximum torque signal for the automatic transmission computer.
----------	---

Carry out a test on the multiplex network (see 88B, Multiplexing).

If the fault is still present, run fault finding on the injection system (see **17B**, **Petrol injection** or **13B**, **Diesel injection**).

If the fault is still present, contact the Techline.

AFTER REPAIR	Deal with any other faults. Clear the fault memory. Switch off the ignition and carry out a road test followed by a check with the diagnostic tool.
	tool.



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no present or stored faults). Test conditions: engine off, ignition on.			
	The values indicated in this conformity check are given as examples.			

MAIN SCREEN

Order	Function	Parameter or Status checked or Action		Display and Notes	Fault finding
1	Engine speed	PR006:	Engine speed	0 rpm	If there is a fault, refer to the interpretation of this parameter.
2	Turbine speed	PR007:	Turbine speed	0 rpm	If there is a fault, refer to the interpretation of this parameter.
3	Power supply	PR008:	Computer supply voltage	10 V < X < 13 V	If there is a fault, refer to the interpretation of this parameter.
4	Gearbox oil temperature	PR004:	Gearbox oil temperature	- 40 °C < X < 140 °C	If there is a fault, refer to the interpretation of this parameter.
5	Coolant temperature	PR001:	Coolant temperature	- 40 °C < X < 120 °C	If there is a fault, refer to the interpretation of this parameter.
6	Oil pressure	PR003:	Oil pressure	X < 0.2 bar	If there is a fault, refer to the interpretation of this parameter.
	<u>.</u>	<u>.</u>			



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no present or stored faults). Test conditions: engine off, ignition on.			
	The values indicated in this conformity check are given as examples.			

MAIN SCREEN (CONTINUED)

Order	Function	Param check	eter or Status (ed or Action	Display and Notes	Fault finding
7	Gear lever position	ET012:	Gear lever position	 "P" if selector is in position "P". "N" if selector is in position "N". "R" if selector is in position "R". "D" if selector is in position "D". "M" if selector is in position "M". "M+" if selector is in position "M+". "M-" if selector is in position "M+". 	In the event of a fault, refer to the interpretation of this status.
8	Manual mode	ET097:	Manual mode	INACTIVE ACTIVE, if lever is in position "M"	In the event of a fault, refer to the interpretation of this status.
9	Old oil	ET083:	Old oil	YES NO	No fault finding procedure for this status.
10	Raw pedal position	PR136:	Raw pedal position	%	If there is a fault, refer to the interpretation of this parameter.



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no present or stored faults). Test conditions: engine off, ignition on.			
	The values indicated in this conformity check are given as examples.			

SUB-FUNCTION: CHANGING GEAR

Order	Function	Parame checke	ter or Status ed or Action	Display and Notes	Fault finding
1	Gear lever position	ET012:	Gear lever position	 "P" if selector is in position "P". "N" if selector is in position "N". "R" if selector is in position "R". "D" if selector is in position "D". "M" if selector is in position "M". "M+" if selector is in position "M+". "M-" if selector is in position "M+". 	In the event of a fault, refer to the interpretation of this status.
2	Sequential lever	ET128:	Upper sequential lever contact	INACTIVE ACTIVE, if selector lever at "M+"	In the event of a fault, refer to the interpretation of this status.
-	switch	ET127:	Lower sequential lever contact	INACTIVE ACTIVE, if selector lever at "M"	In the event of a fault, refer to the interpretation of this status.
3	Selection mode	ET097:	Manual mode	INACTIVE ACTIVE, if lever is in position "M"	In the event of a fault, refer to the interpretation of this status.



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no present or stored faults). Test conditions: engine off, ignition on.		
	The values indicated in this conformity check are given as examples.		

SUB-FUNCTION: CHANGING GEAR (CONTINUED)

Order	Function	Param chec	neter or Status ked or Action	Display and Notes	Fault finding
4	Gear engaged	ET013:	Gear engaged	"R" for reverse. "1P" for 1 st locked. "2P" for 2 nd locked. "3P" for 3 rd locked. "4P" for 4 th locked. "1G" for 1 st slipping. "2G" for 2 nd slipping. "3G" for 3 rd slipping. "4G" for 4 th slipping. "1" for 1 st unlocked. "2" for 2 nd unlocked. "3" for 3 rd unlocked. "4" for 4 th unlocked.	In the event of a fault, refer to the interpretation of this status.
5	Oil pressure	PR003:	Oil pressure	X < 0.2 bar	If there is a fault, refer to the interpretation of this parameter.
6	Engine speed	PR006:	Engine speed	0 rpm	If there is a fault, refer to the interpretation of this parameter.
7	Specified pedal position	PR135:	Specified pedal position	%	If there is a fault, refer to the interpretation of this parameter.
8	Raw pedal position	PR136:	Raw pedal position	%	If there is a fault, refer to the interpretation of this parameter.



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no present or stored faults). Test conditions: engine off, ignition on.			
	The values indicated in this conformity check are given as examples.			

SUB-FUNCTION: CHANGING GEAR (CONTINUED)

Order	Function	Parameter or Status checked or Action		Display and Notes	Fault finding
9	Accelerator pedal position for downshifting	PR124:	Accelerator pedal position for downshifting	%	If there is a fault, refer to the interpretation of this parameter.
		ET021:	Shift solenoid valve 1 control	ACTIVE INACTIVE	In the event of a fault, refer to the interpretation of this status.
10 Solen		ET022:	Shift solenoid valve 2 control	ACTIVE INACTIVE	In the event of a fault, refer to the interpretation of this status.
	Solenoid valve	ET023:	Shift solenoid valve 3 control	ACTIVE INACTIVE	In the event of a fault, refer to the interpretation of this status.
	control	ET024:	Shift solenoid valve 4 control	ACTIVE INACTIVE	In the event of a fault, refer to the interpretation of this status.
		ET025:	Shift solenoid valve 5 control	ACTIVE INACTIVE	In the event of a fault, refer to the interpretation of this status.
		ET026:	Shift solenoid valve 6 control	ACTIVE INACTIVE	In the event of a fault, refer to the interpretation of this status.



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no present or stored faults). Test conditions: engine off, ignition on.			
	The values indicated in this conformity check are given as examples.			

SUB-FUNCTION: CHANGING GEAR (CONTINUED)

Order	Function	Param chec	eter or Status ked or Action	Display and Notes	Fault finding
		ET123:	Multifunction switch S2		In the event of a fault, refer to the interpretation of this status.
11	Multifunction	ET124:	Multifunction switch S3 Lever in position " P "	In the event of a fault, refer to the interpretation of this status.	
	switch	ET125:	Multifunction switch S4	OPEN	In the event of a fault, refer to the interpretation of this status.
		ET126:	P/N multifunction switch		In the event of a fault, refer to the interpretation of this status.
12	Actuator sequential control	AC024:	Actuator sequential control	Means of controlling all the solenoid valves	In the event of a fault, refer to the interpretation of this command.
. <u> </u>		<u>.</u>			



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no present or stored faults). Test conditions: engine off, ignition on.			
	The values indicated in this conformity check are given as examples.			

SUB-FUNCTION: PRESSURE CONTROL

Order	Function	Parameter or Status checked or Action		Display and Notes	Fault finding
1	Gear engaged	ET013:	Gear engaged	"R" for reverse. "1P" for 1 st locked. "2P" for 2 nd locked. "3P" for 3 rd locked. "4P" for 4 th locked. "1G" for 1 st slipping. "2G" for 2 nd slipping. "3G" for 3 rd slipping. "4G" for 4 th slipping. "1" for 1 st unlocked. "2" for 2 nd unlocked. "3" for 3 rd unlocked. "4" for 4 th unlocked.	In the event of a fault, refer to the interpretation of this status.
2	Engine speed	PR006:	Engine speed	0 rpm	In the event of a fault, refer to the interpretation of fault DF236 "Invalid engine speed multiplex signal".
3	Oil pressure	PR003:	Oil pressure	X < 0.2 bar	If there is a fault, refer to the interpretation of this parameter.
4	Gearbox oil pressure sensor voltage	PR118:	Gearbox oil pressure sensor voltage	X = 5 V	If there is a fault, refer to the interpretation of this parameter.
5	Reference pressure	PR138:	Reference pressure	21 bar	None.



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no present or stored faults). Test conditions: engine off, ignition on.			
	The values indicated in this conformity check are given as examples.			

SUB-FUNCTION: PRESSURE CONTROL (CONTINUED)

Order	Function	Parameter or Status checked or Action	Display and Notes	Fault finding
6	Difference between reference pressure and oil pressure	PR146: Difference between specification and oil pressure	X = PR138 - PR003	None.
7	Gearbox oil pressure	PR004: Gearbox oil temperature	- 40 °C < X < 140 °C	If there is a fault, refer to the interpretation of this parameter.
8	Actuator sequential control	AC024: Actuator sequential control	Means of controlling all the solenoid valves	In the event of a fault, refer to the interpretation of this command.



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no present or stored faults). Test conditions: engine off, ignition on.			
	The values indicated in this conformity check are given as examples.			

SUB-FUNCTION: SELECTION LEVER LOCK

Order	Function	Parameter checked	r or Status or Action	Display and Notes	Fault finding
1	Gear lever position	ET012:	Gear lever position	 "P" if selector is in position "P". "N" if selector is in position "N". "R" if selector is in position "R". "D" if selector is in position "D". "M" if selector is in position "M". "M+" if selector is in position "M+". "M-" if selector is in position "M+". 	In the event of a fault, refer to the interpretation of this status.
2	Brake pedal	ET003:	Brake light contact (opening)	OPEN, if brake pedal is not depressed. CLOSED, if brake pedal is depressed.	In the event of a fault, refer to the interpretation of this status.
3	Brake pedal	ET004: Sto	op light contact (closure)	OPEN, if brake pedal is depressed, CLOSED, if brake pedal is not depressed.	In the event of a fault, refer to the interpretation of this status.
4	Actuator sequential control	AC024:	Actuator sequential control	Means of controlling all the solenoid valves	In the event of a fault, refer to the interpretation of this command.



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no present or stored faults). Test conditions: engine off, ignition on.
	The values indicated in this conformity check are given as examples.

SUB-FUNCTION: LOCK-UP/UNLOCKING

Order	Function	Parameter or Status checked or Action		Display and Notes	Fault finding
1	Engine speed	PR006:	Engine speed	0 rpm	If there is a fault, refer to the interpretation of this parameter.
2	Calculated engine torque	PR123:	Calculated engine torque	0 Nm	If there is a fault, refer to the interpretation of this parameter.
3	Speed of rotation	PR007:	Turbine speed	0 rpm	If there is a fault, refer to the interpretation of this parameter.
4	Engine/turbine speed difference	PR128:	Engine/turbine speed difference	0 rpm	If there is a fault, refer to the interpretation of this parameter.
5	Current turbine speed	PR126:	Current turbine speed	0 rpm	If there is a fault, refer to the interpretation of this parameter.
6	Reference pressure	PR138:	Reference pressure	21 bar	If there is a fault, refer to the interpretation of this parameter.
7	Oil pressure	PR003:	Oil pressure	X < 0.2 bar	If there is a fault, refer to the interpretation of this parameter.



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no present or stored faults). Test conditions: engine off, ignition on.			
	The values indicated in this conformity check are given as examples.			

SUB-FUNCTION: LOCK-UP/UNLOCKING (CONTINUED)

Order	Function	Parameter or Status checked or Action		Display and Notes	Fault finding
8	Gearbox oil pressure sensor voltage	PR118:	Gearbox oil pressure sensor voltage	X = 5 V	If there is a fault, refer to the interpretation of this parameter.
9	Oil temperature	PR004:	Gearbox oil temperature	- 40 °C < X < 140 °C	If there is a fault, refer to the interpretation of this parameter.
10	Difference between pressure setting and oil pressure	PR146:	Difference between specification and oil pressure	X = PR138 - PR003	None.
11	Oil too hot signal	ET010:	Oil too hot signal	YES, if oil temperature: X > 140 °C	In the event of a fault, refer to the interpretation of this status.
12	Actuator sequential control	AC024:	Actuator sequential control	Means of controlling all the solenoid valves	In the event of a fault, refer to the interpretation of this command.
	<u>.</u>				



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no present or stored faults). Test conditions: engine off, ignition on.			
	The values indicated in this conformity check are given as examples.			

SUB-FUNCTION: STATIONARYDECLUTCHING

Order	Function	Parameter or Status checked or Action	Display and Notes	Fault finding
1	Engine speed	PR006: Engine speed	0 rpm	If there is a fault, refer to the interpretation of this parameter.
2	Gear lever position	ET012: Gear lever position	"P" if selector is in position "P". "N" if selector is in position "N". "R" if selector is in position "R". "D" if selector is in position "D". "M" if selector is in position "M". "M+" if selector is in position "M+". "M-" if selector is in position "M+".	In the event of a fault, refer to the interpretation of this status.
3	Gear engaged	ET013: Gear engaged	"R" for reverse. "1P" for 1 st locked. "2P" for 2 nd locked. "3P" for 3 rd locked. "4P" for 4 th locked. "1G" for 1 st slipping. "2G" for 2 nd slipping. "3G" for 3 rd slipping. "4G" for 4 th slipping. "1" for 1 st unlocked. "2" for 2 nd unlocked. "3" for 3 rd unlocked. "4" for 4 th unlocked.	In the event of a fault, refer to the interpretation of this status.



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no present or stored faults). Test conditions: engine off, ignition on.	
	The values indicated in this conformity check are given as examples.	

SUB-FUNCTION: STATIONARY DECLUTCHING (CONTINUED)

Order	Function	Paran cheo	neter or Status ked or Action	Display and Notes	Fault finding
4	Brake pedal	ET003:	Brake light contact (opening)	OPEN, brake pedal released. CLOSED, brake pedal depressed.	In the event of a fault, refer to the interpretation of this status.
5	Brake pedal	ET004:	Stop light contact (closure)	CLOSED, brake pedal released. OPEN, brake pedal depressed.	In the event of a fault, refer to the interpretation of this status.
6	Actuator sequential control	AC024:	Actuator sequential control	Means of controlling all the solenoid valves	In the event of a fault, refer to the interpretation of this command.



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no present or stored faults). Test conditions: engine off, ignition on.
	The values indicated in this conformity check are given as examples.

SUB-FUNCTION: CREEPING AT IDLE SPEED

Order	Function	Parameter or Status checked or Action		Display and Notes	Fault finding
1	Oil pressure	PR003:	Oil pressure	X < 0.2 bar	If there is a fault, refer to the interpretation of this parameter.
2	Oil temperature	PR004:	Gearbox oil temperature	- 40 °C < X < 140 °C	If there is a fault, refer to the interpretation of this parameter.
3	Vehicle speed	PR105:	Vehicle speed	0 mph	If there is a fault, refer to the interpretation of this parameter.
4	Engine speed	PR006:	Engine speed	0 rpm	If there is a fault, refer to the interpretation of this parameter.
5	Speed of rotation	PR007:	Turbine speed	0 rpm	If there is a fault, refer to the interpretation of this parameter.
6	Engine/turbine speed difference	PR128:	Engine/turbine speed difference	0 rpm	If there is a fault, refer to the interpretation of this parameter.
	<u>.</u>				



NOTES	Only carry out this conformity check after a complete check with the diagnostic tool (no present or stored faults). Test conditions: engine off, ignition on.		
	The values indicated in this conformity check are given as examples.		

SUB-FUNCTION: CREEPING AT IDLE SPEED (CONTINUED)

Order	Function	Parameter or Status checked or Action	Display and Notes	Fault finding
7	Standard pedal position	PR135: Standard per position	lal %	If there is a fault, refer to the interpretation of this parameter.
8	Brake pedal	ET003: Brake light contact (opening)	OPEN, brake pedal released. CLOSED, brake pedal depressed.	In the event of a fault, refer to the interpretation of this status.
9	Brake pedal	ET004: Stop light cont (closure)	act CLOSED, brake pedal released. OPEN, brake pedal depressed.	In the event of a fault, refer to the interpretation of this status.
10	Gear engaged	ET013: Gear engag	 "R" for reverse. "1P" for 1st locked. "2P" for 2nd locked. "3P" for 3rd locked. "4P" for 4th locked. "1G" for 1st slipping. "2G" for 2nd slipping. "3G" for 3rd slipping. "4G" for 4th slipping. "1" for 1st unlocked. "2" for 2nd unlocked. "3" for 3rd unlocked. "4" for 4th unlocked. 	In the event of a fault, refer to the interpretation of this status.



Tool status	Diagnostic tool title
ET001	Solenoid valve supply
ET003	Brake light contact (opening)
ET004	Stop light contact (closure)
ET010	Oil too hot signal
ET011	Engine speed signal
ET012	Gear lever position
ET013	Gear engaged
ET020	Exchanger flow control solenoid valve control
ET021	Shift solenoid valve 1 control
ET022	Shift solenoid valve 2 control
ET023	Shift solenoid valve 3 control
ET024	Shift solenoid valve 4 control
ET025	Shift solenoid valve 5 control
ET026	Shift solenoid valve 6 control
ET072	Gear change settings
ET081	Snow mode
ET083	Old oil
ET097	Manual mode
ET108	Torque reduction
ET123	S2 multifunction switch
ET124	S3 multifunction switch
ET125	S4 multifunction switch
ET126	P/N multifunction switch
ET127	Lower sequential lever contact
ET128	Upper sequential lever contact
ET157	Gear lever unlocking
ET158	Multifunction switch

AFTER REPAIR Repeat the conformity check from the start.



ET001	SOLENOID VALVE SUPPLY

NOTES	There must be no present or stored faults.

Force the solenoid valves feed by running command AC024 "Actuator sequential control"; see "Interpretation of commands".
Disconnect the electric/hydraulic interface connector and check: The solenoid valves feed status is "ABSENT" at a voltage of 0 V :
Earth Track 1 Track 12 Track 20
The solenoid valves feed status is " PRESENT " at a voltage of + 12 V . If the status is not correct, apply the interpretation of fault DF012 "Solenoid valves feed" . Repair if necessary.

Repeat the conformity check from the start.



ET003	BRAKE LIGHT CONTACT (OPENING)

NOTES

There must be no present or stored faults.

The status displays "OPEN" with the pedal released and changes to "CLOSED" with the brake pedal depressed.

Check the cleanliness and the condition of the brake light switch connections.

Check the position, setting and correct operation of the brake light switch. (Watch out for the floor carpet which can jam the switch.)

Disconnect the battery.

Disconnect the computer. Check the cleanliness and condition of the connections.

Use the "Universal bornier **Elé. 1681**" to check the insulation, continuity and absence of interference resistance on the following connection:

Computer track 16 **track 3** brake light switch

If the correct status is not displayed, replace the switch.

AFTER REPAIR

Repeat the conformity check from the start.



ET004	STOP LIGHT CONTACT (CLOSURE)

NOTES

There must be no present or stored faults.

The status displays "CLOSED" with the pedal released and changes to "OPEN" with the brake pedal depressed.

Check the cleanliness and the condition of the brake light switch connections.

Check the **position**, **setting** and **proper functioning** of the brake light switch. (Watch out for the floor carpet which can jam the switch.)

Disconnect the battery.

Disconnect the computer. Check the cleanliness and condition of the connections.

Use the "Universal bornier Elé. 1681" to check the insulation, continuity and the absence of interference resistance on the following connection:

Repair if necessary.

If the correct status is not displayed, replace the switch.

AFTER REPAIR Repeat the conformity check from the start.



ET010	OIL TOO HOT SIGNAL

NOTES	There must be no present or stored faults.
-------	--

This status means the oil temperature is higher than normal running temperature. The status displays "NO" if the gearbox oil temperature is below 140 °C. The status displays "YES" when the gearbox oil temperature rises above 140 °C.

4

If the correct status is not displayed, use the interpretation of fault DF177 "Automatic transmission overheating".

AFTER REPAIR

Repeat the conformity check from the start.



	GEAR LEVER POSITION
ET012	
NOTES	There must be no present or stored faults.
	Check the elegations condition and attachment of the automatic transmission
"P" - "R" - "N" - "D"	multifunction switch.
	Check the lever adjustment (see 23A, Automatic transmission).
	Disconnect the battery. Disconnect the "modular connector" and check the cleanliness and condition of the
	connector "A" connections. See System operation and Allocation of computer tracks , "modular connector" connections.
	Carry out the following checks on the multifunction switch:
	Continuity:
	Lever in position "P", track A10 — — Track A7
	Lever in position "R", tracks A10, — Track A7 A11, A12
	Lever in position "N", track A11 — Frack A7
	Lever in position "D", track A12 — Frack A7
	Insulation:
	Lever in position "P", tracks A9, A11, A12
	Lever in position "R", track A9
	Lever in position "N", tracks A9,► Track A7 A10, A12
	Lever in position "D", tracks A9,

 AFTER REPAIR
 Repeat the conformity check from the start.

 DP0TA2000_V14_ET012









ET013	<u>GEAR ENGAGED</u>	
NOTES	There must be no present or stored faults.	
"1" for 1 st unlocked "2" for 2 nd unlocked "3" for 3 rd unlocked "4" for 4 th unlocked "1G" for 1 st slipping "2G" for 2 nd slipping "3G" for 3 rd slipping "4G" for 4 th slipping	"1P" for 1 st locked "2P" for 2 nd locked. "3P" for 3 rd locked "4P" for 4 th locked "R" for reverse "D" for the default position "N" for neutral position	
If the fault comes from the engaged gear, carry out fault finding on the multifunction switch. Check that statuses ET123, ET124 and ET125 operate correctly. - ET123 "Multifunction switch S2". - ET124 "Multifunction switch S3". - ET125 "Multifunction switch S4". Check multifunction switch settings.		

AFTER REPAIR

Repeat the conformity check from the start.



ET020	EXCHANGER FLOW CONTROL SOLENOID VALVE CONTROL*

NOTES

There must be no present or stored faults.

The exchanger flow control solenoid valve command status displays "**ACTIVE**" in the following conditions: – gearbox oil temperature is over **100** °C,

- engine rotation speed is greater than **2000 rpm**.

With other conditions, the solenoid valve status displays "INACTIVE".

Disconnect the computer. Check the cleanliness and condition of the connections. Check the continuity between track 2 of the computer connector and track E2 of the "modular connector". Check the continuity between track 12 of the computer connector and track E1 of the "modular connector". Check between tracks 2 and 12 of the computer connector that the resistance of shift solenoid valve no. 2 is 40 $\Omega \pm 2$ at approximately 23 °C.

Repair if necessary.

If the **resistance** is greater than **50** Ω , check the harness, computer connector and "modular connector".

If the status of the command fails to change, use the interpretation of fault **DF017 "Exchanger flow solenoid valve circuit"**.

* EV: Solenoid valve.

AFTER REPAIR

Repeat the conformity check from the start.



	SHIFT SOLENOID VALVE 1 CONTROL
ET021	

NOTES	There must be no present or stored faults.

This status displays "ACTIVE" when the gear engaged is "3" or "4" and "INACTIVE" when other gears are engaged.

Disconnect the computer. Check the cleanliness and condition of the connections. Check the continuity between track 10 of the computer connector and track B8 of the "modular connector". Check between tracks 1 and 10 of the computer connector that the resistance of shift solenoid valve no. 2 is **40** $\Omega \pm 2$ at approximately **23** °C.

Repair if necessary.

If the **resistance** is greater than **50** Ω , check the harness, computer connector and "modular connector".

If the correct status is not displayed, use the interpretation of fault DF085 "EVS1 Shift solenoid valve circuit".

AFTER REPAIR

Repeat the conformity check from the start.



ET022	SHIFT SOLENOID VALVE 2 CONTROL

NOTES

There must be no present or stored faults.

This status displays "ACTIVE" when the gear engaged is "N" or "2" or "3" or "4" and "INACTIVE" when other gears are engaged.

Disconnect the computer. Check **the cleanliness and condition** of the connections. Check the **continuity** between **track 9** of the computer connector and **track B8** of the "modular connector". Check between **tracks 1 and 9** of the computer connector that the **resistance** of shift solenoid valve no. 2 is **40** $\Omega \pm 2$ at approximately **23** °C.

If the **resistance** is greater than 50 Ω , check the harness, computer connector and "modular connector".

If the status does not function as specified, use the interpretation of fault **DF086 "EVS2 Shift solenoid valve 2** circuit".

AFTER REPAIR

Repeat the conformity check from the start.



ET023	SHIFT SOLENOID VALVE 3 CONTROL

NOTES	There must be no present or stored faults.

This status displays "ACTIVE" when the gear engaged is "P" or "N" or "1" and "INACTIVE" when other gears are engaged.

Disconnect the computer. Check the cleanliness and condition of the connections.

Check the **continuity** between **track 7** of the computer connector and **track B10** of the "modular connector". Check between **tracks 1 and 7** of the computer connector that the **resistance** of shift solenoid valve no. 3 is **40** $\Omega \pm 2$ at approximately 23 °C.

Repair if necessary.

If the resistance is greater than 50 Ω , check the harness, computer connector and "modular connector".

If the status does not function as specified, use the interpretation of fault **DF087 "EVS3 Sequence solenoid valve 3 circuit"**.

AFTER REPAIR

Repeat the conformity check from the start. Make sure that shifting up and down through each gear works properly.



ET024	SHIFT SOLENOID VALVE 4 CONTROL

NOTES	There must be no present or stored faults.

This status displays "**ACTIVE**" when the gear engaged is "1" or "2" and "**INACTIVE**" when other gears are engaged.

Disconnect the computer. Check **the cleanliness and condition** of the connections. Check the **continuity** between **track 8** of the computer connector and **track B7** of the "modular connector". Check between **tracks 1 and 8** of the computer connector that the **resistance** of shift solenoid valve no. 4 is **40** $\Omega \pm 2$ at approximately **23** °C. Repair if necessary.

If the **resistance** is greater than 50 Ω , check the harness, computer connector and "modular connector".

If the status does not function as specified, use the interpretation of fault **DF089 "EVS4 Sequence solenoid valve 4 circuit"**.

AFTER REPAIR

Repeat the conformity check from the start. Make sure that shifting up and down through each gear works properly.

DP0TA2000_V14_ET024

23A-97 www.cargeek.ir



	SHIFT SOLENOID VALVE 5 CONTROL
ET025	

NOTES

There must be no present or stored faults.

This status displays "ACTIVE" when the gear engaged is "1" and "INACTIVE" when other gears are engaged.

Disconnect the computer. Check the cleanliness and condition of the connections. Check the continuity between track 13 of the computer connector and track B5 of the "modular connector". Check between tracks 1 and 13 of the computer connector that the resistance of shift solenoid valve no. 5 is $40 \Omega \pm 2$ at approximately 23 °C.

Repair if necessary.

If the resistance exceeds 50 Ω , check the harness, computer connector and "modular connector".

If the status is still not correct, use the interpretation of fault DF088 "EVS5 Shift solenoid valve circuit".

AFTER REPAIR

Repeat the conformity check from the start. Make sure that shifting up and down through each gear works properly.



	SHIFT SOLENOID VALVE 6 CONTROL
ET026	

NOTES

There must be no present or stored faults.

This status displays "INACTIVE" with any gear engaged.

Disconnect the computer. Check the cleanliness and condition of the connections. Check the continuity between track 14 of the computer connector and track B2 of the "modular connector". Check between tracks 14 and 1 of the computer connector that the resistance of shift solenoid valve no. 6 is 40 $\Omega \pm 2$ at approximately 23 °C.

If the resistance exceeds 50 Ω , check the harness, computer connector and "modular connector".

If the status is still not correct, use the interpretation of fault DF112 "EVS6 Shift solenoid valve circuit".



AFTER REPAIR

Repeat the conformity check from the start. Make sure that shifting up and down through each gear works properly.


ET097	MANUAL MODE

NOTES

There must be no present or stored faults.

This status indicates the gear lever position. This status displays **"ACTIVE**" when the gear lever is in position **"M"**, **"M+"** or **"M-"**. This status displays **"INACTIVE**" when the gear lever is in positions **"P"**, **"R"**, **"N"** or **"D"**.

4

If the correct status is not displayed, use the interpretation of fault DF093 "One-touch switch circuits".

AFTER REPAIR

Repeat the conformity check from the start. Make sure that shifting up and down through each gear works properly.

23A

ET123 ET124 ET125	MULTIFUNCTION SWITCH S2 MULTIFUNCTION SWITCH S3
	MULTIFUNCTION SWITCH S4

NOTES	There must be no present or stored faults. Multifunction switch contact S1 is not connected on this vehicle.
-------	---

These statuses show the position of the multifunction switch for each gear lever position. The switch status can be "**OPEN**" or "**CLOSED**" (see chart below).

	S2	S3	S4
Р	CLOSED	OPEN	OPEN
R	CLOSED	CLOSED	CLOSED
N	OPEN	CLOSED	OPEN
D	OPEN	OPEN	CLOSED
М	OPEN	OPEN	CLOSED
M+	OPEN	OPEN	CLOSED
M-	OPEN	OPEN	CLOSED

If a status fails to function as specified, use the interpretation of fault DF008 "Multifunction switch intermediate position".

AFTER REPAIR

Repeat the conformity check from the start. Make sure that shifting up and down through each gear works properly.

DP0TA2000_V14_ET123/DP0TA2000_V14_ET124/DP0TA2000_V14_ET125



ET127	LOWER SEQUENTIAL LEVER CONTACT

NOTES	There must be no present or stored faults.

This indicates the status of the lower sequential lever switch. This status displays "ACTIVE" with the gear lever in position "M-". This status displays "INACTIVE" with the gear lever in a position other than "M-". Check the one-touch switch's power supply for + 12 V on track B1 and earth in track A2 of the one-touch switch. With the gear lever in position "M", measure the voltage between: One-touch switch track A3 → Earth One-touch switch track B3 → Earth If any of the measured values is + 12 V, replace the one-touch switch. If the values are 0 V, check that the gear lever positions match the instrument panel display. Repair if necessary. If the correct status is not displayed, use the interpretation of fault DF093 "One-touch switch circuits".

Repeat the conformity check from the start. Make sure that shifting up and down through each gear works properly.



ET128	UPPER SEQUENTIAL LEVER CONTACT

NOTES	There must be no present or stored faults.

This indicates the status of the lower sequential lever contact. This status displays "ACTIVE" with the gear lever in position "M+". This status displays "INACTIVE" with the gear lever in a position other than "M+". Check the one-touch switch's power supply for + 12 V on track B1 and earth in track A2 of the one-touch switch. With the gear lever in position "M", measure the voltage between: One-touch switch track A3 → Earth One-touch switch track B3 → Earth If any of the measured values is + 12 V, replace the one-touch switch. If the values are 0 V, check that the gear lever positions match the instrument panel display. Repair if necessary. If the correct status is not displayed, use the interpretation of fault DF093 "One-touch switch circuits".

Repeat the conformity check from the start. Make sure that shifting up and down through each gear works properly.



ET157	GEAR LEVER UNLOCKING

NOTES

There must be no present or stored faults.

This status displays "ACTIVE" when the gear lever is locked and "INACTIVE" when the gear lever is unlocked

Check the status with:

- Gear lever in position "P".

- Instrument panel displaying "P" for the gear lever position.

Press the brake pedal; the message on the instrument panel: "**Depress the brake pedal**" disappears. The status displays "**INACTIVE**" with the brake pedal depressed and gear lever unlocking permitted. The status displays "**ACTIVE**" with the brake pedal released and the gear lever locked in position "**P**".

This status can only be checked with the gear lever in position "P".

If the correct status is not displayed, use the interpretation of fault **DF095** "Selector lever locking electromagnet circuit".

AFTER REPAIR

Repeat the conformity check from the start. Make sure that shifting up and down through each gear works properly.

Fault finding - Parameter summary table



Tool parameter	Diagnostic tool title	
PR001	Coolant temperature	
PR003	Oil pressure	
PR004	Gearbox oil temperature	
PR006	Engine speed	
PR007	Turbine speed	
PR008	Computer supply voltage	
PR019	Engine torque	
PR105	Vehicle speed	
PR118	Gearbox oil pressure sensor voltage	
PR119	Modulating solenoid valve control time	
PR123	Calculated engine torque	
PR124	Accelerator pedal position for downshifting	
PR126	Current turbine speed	
PR128	Engine/turbine speed difference	
PR135	Standard pedal position	
PR136	Raw pedal position	
PR137	Lock-up solenoid valve control time	
PR138	Reference pressure	
PR146	Difference between specification and oil pressure	





BB001	COOLANT TEMPERATURE
PRUU1	

NOTES	Special notes: Only apply the checks if the parameter is inconsistent.

Test the multiplex network (see 88B, Multiplexing).

If parameter PR001 "Coolant temperature" is absent, refer to the interpretation of the parameter (see MR 366 Megane, 17B, Petrol injection or 13B, Diesel injection).

AFTER REPAIR

Repeat the conformity check from the start.



PR003	<u>OIL PRESSURE</u>

NOTES	There must be no present or stored faults.

Immobilise the vehicle: handbrake on and brake pedal depressed.

- Check the oil pressure values on the diagnostic tool:
- engine not running: pressure reading less than 0.2 bar,
- rp. and se. - engine at idle speed (~ 820 rpm) and selector lever at "D" or "R": pressure reading ~ 2.6 bar.
- engine speed ~ 1400 rpm and selector lever at "D" or "R": pressure reading ~ 8.7 bar.

AFTER REPAIR

Repeat the conformity check from the start.



PR004	<u>GEARBOX OIL TEMPERATURE</u>

NOTES	There must be no present or stored faults.
-------	--

Gearbox oil temperature values vary according to how the vehicle is used.

4

Check the oil temperature values on the diagnostic tool:

Minimum temperature: - 40 °C.

Maximum temperature: + 140 °C.

These values relate to normal operation of the vehicle.

AFTER REPAIR

Repeat the conformity check from the start.



PR006	ENGINE SPEED

TES

There must be no present or stored faults.

Run a multiplex network test (see 88B, Multiplexing).

After these checks, if parameter PR006 "Engine speed" is absent, refer to the interpretation of the parameter (see 17B, Petrol injection or 13B, Diesel injection).

AFTER REPAIR

Repeat the conformity check from the start.



PR007	TURBINE SPEED
NOTES	There must be no present or stored faults.

Turbine speed varies according to oil temperature and pressure. Turbine speed depends on engine speed.		
Check the turbine speed on the diagnostic tool: Selector lever in position " N ".		
Oil temperature 43 °C: engine speed ~ 762 rpm	→ turbine speed ~ 681 rpm.	
Oil temperature 45 °C : engine speed ~ 743 rpm	→ turbine speed ~ 654 rpm.	

<u>- 743 rp.</u>

AFTER REPAIR Repeat the conformity check from the start.



PR008	COMPUTER SUPPLY VOLTAGE

NOTES	There must be no present or stored faults. All electrical consumers switched off.

Carry out a complete battery and charging circuit check (see TN 6014A, "Charging circuit fault finding").

Disconnect the computer.

Check the condition and cleanliness of the connector.

Check the insulation, continuity and absence of interference resistance: earth on computer track 28 and the front left-hand side member of the vehicle.

Check the computer's 30A fuse.

Check the computer's ${\bf 5A}$ after ignition feed fuse.

With the ignition on, measure the computer feed voltage Track 56: + 12 V Track 27: + 12 V

Then check the earths:

Track 28 and track 46 Check the Protection and Switching Unit if necessary.

AFTER REPAIR

Repeat the conformity check from the start.



	ENGINE TORQUE
PR019	

There must be no present or stored faults.

Run a multiplex network test (see 88B, Multiplexing).

If parameter PR019 "Engine torque" is absent, refer to the interpretation of the parameter (see MR 366 Megane, 17B, Petrol injection or 13B, Diesel injection).

AFTER REPAIR

Repeat the conformity check from the start.



PR105	VEHICLE SPEED

NOTES	

There must be no present or stored faults.

Run a multiplex network test (see MR 366 Megane 8, 88B, Multiplexing).

If parameter PR105 "Vehicle speed" is absent, carry out fault finding on the system (see 38C, ABS system).

AFTER REPAIR

Repeat the conformity check from the start.

AUTOMATIC TRANSMISSION Fault finding - Interpretation of parameters



PR118	GEARBOX OIL PRESSURE SENSOR VOLTAGE

NOTES	There must be no present or stored faults.

ELECTRICAL CONFORMITY OF THE SENSOR:

Check **the continuity and absence of interference resistance** on the following connections:

If all these connections are correct, check for a gearbox oil pressure sensor power supply:

+ 5 V ----- Track C1 male modular connector

Repair if necessary.





PR123	

NOTES	There must be no present or stored faults.

Run a multiplex network test (see 88B, Multiplexing).

If parameter PR123 "Calculated engine torque" is absent, refer to the interpretation of the parameter (see 17B, Petrol injection or 13B, Diesel injection).

AFTER REPAIR

Repeat the conformity check from the start.



PR124	ACCELERATOR PEDAL POSITION FOR DOWNSHIFTING

NOTES

There must be no present or stored faults.

Run a multiplex network test (see 88B, Multiplexing).

If parameter PR124 "Accelerator pedal position for downshifting" is absent, refer to the interpretation of the parameter (see 17B, Petrol injection or 13B, Diesel injection).

AFTER REPAIR

Repeat the conformity check from the start.



PR126	CURRENT TURBINE SPEED

NOTES	There must be no present or stored faults.
Check the cleanliness ar Check the insulation, c following connections:	nd condition of the turbine speed sensor and its connections. Continuity and the absence of interference resistance to earth, to + 12 V and the
	Computer track 45
	Computer track 46
Repair if necessary.	
Check the turbine speed Gear lever position at "N Oil temperature 43 °C : e	on the diagnostic tool: " or "P" ngine speed ~ 681 rpm

Oil temperature 45 °C: engine speed ~ 654 rpm

AFTER REPAIR

Repeat the conformity check from the start.



PR128	ENGINE/TURBINE SPEED DIFFERENCE

NOTES

There must be no present or stored faults.

Check the **cleanliness and condition** of the engine speed sensor and its connections. Run a multiplex network test (see **88B**, **Multiplexing**).

After these checks, if parameter **PR006 "Engine speed"** is absent, refer to the interpretation of the parameter (see **17B**, **Petrol injection** or **13B**, **Diesel injection**).

Check the cleanliness and condition of the turbine speed sensor and its connections.

This parameter is the difference between parameter **PR006 "Engine speed"** and parameter **PR007 "Turbine speed"**.

Check the engine/turbine speed difference with the diagnostic tool: Engine idling:

Engine speed: ~ 743 rpm and turbine speed: ~ 654 rpm _____ difference = ~ 89 rpm.

Repair if necessary.

AFTER REPAIR Repeat the conformity check from the start.



PR135	STANDARD PEDAL POSITION

NOTES

There must be no present or stored faults.

Run a multiplex network test (see 88B, Multiplexing).

If parameter PR135 "Standard pedal position" is absent, refer to the interpretation of the parameter (see 17B, Petrol injection or 13B, Diesel injection).

AFTER REPAIR

Repeat the conformity check from the start.



	RAW PEDAL POSITION
PR136	

NOTES	There must be no present or stored faults.

Run a multiplex network test (see 88B, Multiplexing).

If parameter PR136 "Raw pedal position" is absent, refer to the interpretation of the parameter (see 17B, Petrol injection or 13B, Diesel injection).

AFTER REPAIR

Repeat the conformity check from the start.



	PRESSURE SETTING		
PR138			

NOTES	There must be no present or stored faults.
-------	--

The pressure setting is determined by the automatic transmission computer.

Check the reference pressure on the diagnostic tool:

- engine not running: pressure reading 21 bar,

- engine at idle speed (~700 rpm) and selector lever at "D" or "R": pressure reading ~2.7 bar,

- engine speed ~ 1400 rpm and selector lever at "D" or "R": pressure reading ~ 8.9 bar.

AFTER REPAIR

Repeat the conformity check from the start.



PR146	DIFFERENCE BETWEEN SETPOINT AND OIL PRESSURE

NOTES	There must be no present or stored faults.

The pressure setting values are stored in the gearbox computer memory and depend on how the vehicle is used. The oil pressure is regulated according to the pressure setting. The oil pressure values must always be close to the pressure settings.

This parameter is the difference between parameter **PR138** "**Pressure setting**" and parameter **PR003** "**Oil pressure**".

- engine not running: reference pressure reading **21 bar**.

oil pressure reading = 0 bar.

- engine at idle speed (~700 rpm) and selector lever at "D" or "R": reference pressure reading ~2.7 bar.

oil pressure reading = ~ 2.6 bar.

engine speed ~ 1400 rpm and selector lever at "D" or "R": reference pressure reading ~ 8.9 bar.
 oil pressure reading = ~ 8.7 bar.

AFTER REPAIR

Repeat the conformity check from the start.



COMMANDS AND CLEARING:

Before using these clearing commands, engine and vehicle speeds must be zero and the selector lever must be in position "**P**" or "**N**".

AC024 "Actuator sequential control"

This command activates the shift solenoid valves EVS1 to EVS6 simultaneously to check that they operate correctly.

RZ004 "Fault memory"

This command clears present and stored faults from the automatic transmission computer.

RZ005 "Self-adapting programs"

This command deletes the self-adapting programs in the automatic transmission computer. After running this command, carry out a road test with the vehicle before returning it to the customer. This is because the automatic transmission may malfunction during the time taken for the self-adapting programs to re-install.

AFTER REPAIR

Repeat the conformity check from the start.



AC024	ACTUATOR SEQUENTIAL CONTROL
NOTES	Check fuse 30 A for the permanent power supply of the computer in the Protection and Switching Unit. Check fuse 5 A for the after ignition power supply of the computer in the Protection and Switching Unit.

Replace the fuses if necessary. Check the cleanliness and condition of the connections.

Engine speed zero and selector lever in position "P" or "N".

This command enables all the automatic transmission solenoid valve actuators to be operated.

Check the insulation, continuity and absence of interference resistance on the following connections:
Computer Track 12
Computer Track 26
Computer Track 1 — Frack B3 modular connector.
To activate solenoid valve EVS1: Computer Track 10 Track B11 modular connector
To activate solenoid valve EVS2: Computer Track 9 Track B8 modular connector
To activate solenoid valve EVS3: Computer Track 7
To activate solenoid valve EVS4: Computer Track 8
To activate solenoid valve EVS5: Computer Track 13 Track B5 modular connector
To activate solenoid valve EVS6: Computer Track 14 Track B2 modular connector
Test the solenoid valves then check the presence of faults on the computer.





NOTES Only refer to "Customer complaints" after carrying out a complete fault finding procedure with the diagnostic tool and the conformity check.

NO DIALOGUE WITH THE COMPUTER	ALP1
ENGINE STARTING FAULTS	ALP2
AUTOMATIC TRANSMISSION OPERATING FAULTS	ALP3
AUTOMATIC TRANSMISSION MALFUNCTION WHEN	ALP4
ERRATIC GEAR CHANGES	ΔΙΡ5
REVERSING LIGHTS INOPERATIVE	ALP6
OIL PRESENT UNDER THE VEHICLE	ALP7

SIEMENS TA2000 Vdiag no.: 14



ALP1	Ν	lo dialogı	e with the computer
NOTES	None		
Try the diagnostic tool of	n another vehicle.		
Check: - the connection between the diagnostic tool and socket (connection and cable in good condition), - the power supply to the computer, - the engine and passenger compartment fuses.			
Check that the CLIP sensor is fed via tracks 16 (+ 12 V), 4 and 5 (earth) of the diagnostic socket, as indicated by the illumination of two red warning lights on the sensor. Make sure that the CLIP sensor is connected to the computer's USB port. Make sure that the CLIP sensor is communicating properly with the vehicle's computers; this can be seen by the two green diodes on the sensor lighting up.			
Use the diagnostic socke	et to check the following tra	acks:	
	track 1	\rightarrow	+ After ignition
	track 16	\rightarrow	+ Battery feed
	tracks 4	\rightarrow	Earth
Repair if necessary.			
Disconnect the automatic of interference resistar	c transmission computer co nce of the following connec	onnector to c ctions:	heck the insulation, continuity and the absence
	Computer track 27	>	+ After ignition feed
	Computer track 56	>	+ Battery feed
	Computer track 28	>	Earth
	Computer track 38		track 6 diagnostic socket (CAN H)
	Computer track 39		track 14 diagnostic socket (CAN L)
Repair if necessary.			
If the fault is still present	, contact the Techline.		





ALP2	Engine starting faults	
NOTES	Only refer to "Customer complaints" after carrying out a complete fault finding procedure with the diagnostic tool and the conformity check.	
Make sure that the diagr engaged. Adjust the gear lever cal	nostic tool report, gear lever positions and instrument panel all indicate the same gear	
The engine will only star	t when the selector lever is at " P " or " N ".	
Check the battery charge Check the multifunction Check the gear lever co	e and the condition of the terminals (oxidation). switch mounting and that it is working. ntrol cable, adjust it if necessary (see 23A, Automatic transmission).	
Switch off the ignition an are in good condition an	d disconnect the automatic transmission computer connector. Make sure that the fuses d replace them if necessary.	
Ensure that the ignition s	switch is working properly.	
Check the power circuit of the starter relay and the starter.		
Carry out fault finding or	the injection system.	
If the engine still doesn't	start, contact the Techline.	

AFTER REPAIR

Carry out a road test followed by a complete check with the diagnostic tool.



ALP3	Automatic transmission operating fault

NOTES	Only refer to "Customer complaints" after carrying out a complete fault finding procedure with the diagnostic tool and the conformity check.
-------	--

Using the diagnostic tool, check the consistency between the display and the selector lever positions (ignition on and engine stopped).
Check the level, smell and colour of the oil and for the presence of particles in the oil.
 Check the mountings of the multifunction switch. Check the multifunction switch control wire (see 23A, Automatic transmission, Multifunction switch). Carry out fault finding with the diagnostic tool: Check the following points: With the engine stopped, check the oil pressure value: 0 bar. With the engine running, oil temperature higher than 20 °C, vehicle stationary and selector lever at "D", the oil pressure increases with the engine/turbine speed. Example: engine speed ~ 750 rpm → pressure: ~ 3 bar. angine speed ~ 1400 rpm → pressure: ~ 9 bar. If the pressure remains static, replace the oil pressure sensor. Check the line pressure using a pressure gauge (see 23A, Automatic transmission, Line pressure reading). If the oil pressure value is incorrect, there may be one or more causes: Clogged strainer or faulty pump. An internal leak (slave cylinders, brakes, clutch), carry out a road test to check there is no slipping. A hydraulic control valve fault may cause jerking or malfunctions when driving.

AFTER REPAIR

Carry out a road test followed by a complete check with the diagnostic tool.



ALP3

CONTINUED

Refer to the procedure and the safety instructions for carrying out a setting point check on the torque converter. Selector lever in position "**D**".

Theoretical engine speed at setting point: 2300 ± 150 rpm.

Oil pressure at engine speed ~ 1400 rpm ------> 9 bar.

If the setting point value is incorrect, there may be one or more causes:

- the torque converter,

- the converter lock-up solenoid valve,

- internal oil leak.

Note:

A setting point which is too low may be due to a lack of engine power.

Carry out a road test, observing the engine speed on the instrument panel and the displays on the diagnostic tool.

If the fault is still present, contact the Techline.

AFTER REPAIR	Carry out a road test followed by a complete check with the diagnostic tool.





ALP4	Automatic transmission malfunction when changing gears
NOTES	Only refer to "Customer complaints" after carrying out a complete fault finding procedure with the diagnostic tool and the conformity check.

Automatic transmission faults may be noted during gear changing without any fault being stored in the computer. These malfunctions may be linked to: - Connection faults (**insulation**: generates a fault, **resistance**) in the shift solenoid valve control wiring (**EVS1 to**

Connection faults (insulation: generates a fault, resistance) in the shift solenoid valve control wiring (EVS1 to EVS6).

Check the tightness and condition of the clips on all the solenoid valve control wiring connections from the computer to each solenoid valve.

- Use command AC024 "Actuator sequential control" to find any faults.
- Hydraulic distributor faults (hydraulic slide valve seizing, strainer/distributor seal) preventing the shift solenoid valves from working.

Check the oil's condition (colour, burnt or not) its level and pressure: increasing with engine/turbine speed. – Loss of pressure when changing gear (clutch brakes/receivers leak)

Read the values of the following parameters (selector lever in position "D" or "R": vehicle stationary and handbrake on) on the CLIP tool:

- PR003 "Oil pressure",
- PR006 "Engine speed",
- PR007 "Turbine speed",
- PR138 "Pressure setting",
- PR008 "Computer feed voltage".

These parameters are associated with automatic transmission operation.

If one of the values is incorrect, note the fault it causes.

Replace the faulty part if necessary and carry out a check.

If the fault is still present, contact the Techline.

AFTER REPAIR

Carry out a road test followed by a complete check with the diagnostic tool.



ALP5	Erratic gear changes	
NOTES	Only refer to "Customer complaints" after carrying out a complete fault finding procedure with the diagnostic tool and the conformity check.	
Run a multiplex network Check the presence of th – PR135 "Standard per – PR136 "Raw pedal per	test (see MR 366 Megane 8, 88B, Multiplexing). ne following parameters: dal position", osition".	
Carry out a road test usir	ng the diagnostic tool, making sure that status ET013 "Gear engaged" functions normally.	
If the customer complain (Closed)" is "NO". If not, adjust the brake lig	it occurs with the brake pedal released, check that status ET004 "Brake light switch ght switch and the brake pedal.	
Make sure that the instru	ument panel display of the gear engaged matches the gear lever position.	
Check the automatic transmission wiring harness (shift solenoid valve activation). Replace it if necessary.		
Check that the gear leve Check that the multifunc	r cable is working properly and adjust it if necessary. tion switch is working correctly.	
If the fault is still present	, contact the Techline.	

AFTER REPAIR

Carry out a road test followed by a complete check with the diagnostic tool.



ALP6	Reversing lights inoperative	
NOTES	Only refer to "Customer complaints" after carrying out a complete fault finding procedure with the diagnostic tool and the conformity check.	
Check: - the condition of the fuses in the UPC. - the condition of the bulbs. - the condition of the bulb contacts. Repair if necessary. - the rear lights earth. Rear right-hand light track 3 and rear left-hand light track 4 .		
Switch off the ignition an Switch the ignition on ag connector.	nd disconnect the modular connector. Jain and check the presence of + 12 V after ignition feed on track A2 of the modular	
Switch off the ignition an side) with the selector le Check that the gear leve If the continuity is poor, i If the continuity is good, Protection and Switching	In the continuity between tracks A1 and A2 of the modular connector (gearbox ever in position "R" . For cable is correctly adjusted and check the instrument panel display. The replace the multifunction switch. Check the continuity between track A1 of the modular connector and track 2 of the gunit brown 12-track connector.	
Switch on the ignition. With the selector lever in position "R", check the presence of + 12 V after ignition feed on: track 2 of the Protection and Switching Unit brown 12-track connector, track 2 of the rear right-hand light, track 5 of the rear left-hand light.		

AFTER REPAIR

Carry out a road test followed by a complete check with the diagnostic tool.



ALP7	Oil present under the vehicle

NOTES	Only refer to "Customer complaints" after carrying out a complete fault finding procedure with the diagnostic tool and the conformity check.
-------	--

Check the colour of the oil under the vehicle to determine the source of the leak (automatic transmission fluid is red).

Clean the engine and gearbox.

Check the oil levels in the engine and gearbox. Top up if necessary (see **23A**, **Automatic transmission**, **Fill-up**).

If there is no gearbox leak, look for a leak on the engine side.

If the leak is from the gearbox:

- Locate the source of the leak and carry out the necessary repairs.

- Replace any faulty parts.

Check the oil level.

AFTER REPAIR Carry out a

Carry out a road test followed by a complete check with the diagnostic tool.